

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

26 Tie-rod - replacement

- 1 Remove the <u>steering gear</u> boot as described in <u>Section 24</u>.
- 2 Unscrew the tie-rod from the end of the steering gear.
- 3 Install the new locking plate to the <u>steering gear</u>, making sure it is locating tabs are correctly seated in the steering gear grooves.
- 4 Screw in the tie-rod and tighten it to the specified torque.
- 5 Reinstall the steering boot as described in Section 24.

© 2024 Haynes Manuals, Inc. Contact us