

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

Specifications

Lubrication

Recommended oil	See <u>Chapter 1</u>
Capacity (from dry)	See Chapter 1
	Ft-lbs
Torque specifications	
Transmission-to-engine bolts	
Hexagon head bolts	
M8 bolts	18
M10 bolts	36
M12 bolts	55
Torx head bolts	
M8 bolts	16
M10 bolts	32
M12 bolts	53
Oil drain plug	37
Oil filler/level plug	37
Output flange-to-output shaft nut*	
Step 1	125
Step 2	Fully loosen nut
Step 3	89
Transmission crossmember-to-body bolts	
M8 bolts	15
M10 bolts	31
Transmission mount-to-transmission nuts	
M8 nuts	15
M10 nuts	31

* Coat the threads of the nut with thread-locking compound.

© 2024 Haynes Manuals, Inc. Contact us