

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

18 Windshield/headlight washer system(s) check

Check that each of the washer jet nozzles are clear and that each nozzle provides a strong jet of washer fluid. The headlight jets should be aimed to spray at a point slightly above the center of the headlight. On the windshield washer nozzles where there are two jets, aim one of the jets slightly above then center of the windshield and aim the other just below to ensure complete coverage of the windshield. If necessary, adjust the jets using a pin.

© 2024 Haynes Manuals, Inc. Contact us