

Go to VTX Admin:

EMAX 900TX 0/200 -

Packet Rate

200Hz(-112dBm)

Telem Ratio

Std (1:64)

Switch Mode

Wide

Model Match

Off (ID: 0)

> TX Power (50mW)

> VTX Admin (F:1 Alt A:1:AUX3)

> WiFi Connectivity

> Backpack

[BLE Joystick]

[Bind]

c_fr_vtx FCC915 f8b826

Band (here F) and **Channel** (here 1) is the default band and channel, you can change it as you want.

VtxSecondary - is the switch which controls alternative video channels.

AUX1 - CH5, **AUX2** - CH6, and so on. e.g. for channel 10 it will be **AUX6**

AltCh/AltBand - are alternative bands and channels to switch to. There are 4 of them.

Depending on the value of VtxSecondary channel video will be switched to one of them.

Channel Value	Mode
1000-1166	default (Band, Channel)
1167-1333	AltCh/AltBand 0
1334-1500	AltCh/AltBand 1
1501-1666	AltCh/AltBand 2
1667-1833	AltCh/AltBand 3
1834-2000	AltCh/AltBand 3

If any AltBand is not set it will be equal to the default Band/Channel.

EMAX 900TX 0/200 -

Band

F

Channel

1

Pwr Lvl

-

Pitmode

Off

[Send VTx]

VtxSecondary

AUX3

AltBand0

A

AltCh0

1

AltBand1

B

AltCh1

2

AltBand2

E

If any AltBand is not set it will be equal to the default Band/Channel.

Drone should have similar settings in cli, if ELRS telemetry is not used.