

Go to VTX Admin:

EMAX 900TX		0/200 -
Packet Rate	200Hz(-112dBm)	
Telem Ratio	Std (1:64)	
Switch Mode	Wide	
Model Match	Off (ID: 0)	
> TX Power (50mW)		
> VTX Admin (F:1 Alt A:1:AUX3)		
> WiFi Connectivity		
> Backpack		
[BLE Joystick]		
[Bind]		
c_fr_vtx FCC915	f8b826	

Band (here F) and **Channel** (here 1) is the default band and channel, you can change it as you want.

VtxSecondary - is the switch which controls alternative video channels.

AUX1 - CH5, **AUX2** - CH6, and so on. e.g. for channel 10 it will be **AUX6**

AltCh/AltBand - are alternative bands and channels to switch to. There are 4 of them.

Depending on the value of VtxSecondary channel video will be switched to one of them.

Channel Value	Mode
1000-1200	default (Band, Channel)
1201-1400	AltCh/AltBand 0
1401-1600	AltCh/AltBand 1
1601-1800	AltCh/AltBand 2
1801-2000	AltCh/AltBand 3

If any AltBand is not set it will be equal to the default Band/Channel.

EMAX 900TX		0/200 -
Band	F	
Channel	1	
Pwr Lvl	-	
Pitmode	Off	
[Send VTx]		
VtxSecondary	AUX3	
AltBand0	A	
AltCh0	1	
AltBand1	B	
AltCh1	2	
AltBand2	E	

If any AltBand is not set it will be equal to the default Band/Channel.

Drone should have similar settings in cli, if ELRS telemetry is not used.

