Playback Troubleshooting

Playback Troubleshooting

This guide provides solutions for common video playback issues in GCXONE. Follow troubleshooting steps in order for best results.

No Recordings Available

Symptoms:

- Timeline shows no recordings
- "No recordings available" message
- Timeline is empty or grayed out

Recording Not Enabled

- Access device web interface
- Navigate to Recording Settings
- Enable recording (continuous or event-based)
- Verify recording schedule is configured and save settings

Recording Period Outside Retention

- Verify retention period configured on device
- Check if requested time period is within retention
- Adjust retention period if needed and check storage capacity

No Recordings for Selected Time

- Verify recording schedule covers requested time
- Check if device was offline during that period
- Look for recording gaps on timeline and try a different time period

Storage Issues

- Check storage space available
- Verify storage device is healthy
- Check for storage errors in device logs and replace if needed

Timeline Not Synchronized

Symptoms:

- Events appear at wrong times

- Multiple cameras show different times
- Timeline misaligned between cameras

Time Synchronization Issues

- Verify NTP is configured on all devices
- Check NTP server: timel.nxgen.cloud
- Restart device after NTP configuration

Time Zone Mismatch

- Verify time zone is configured correctly on devices
- Check that time zone in GCXONE matches devices
- Re-sync time after time zone change

Device Time Incorrect

- Compare device time to accurate time source
- Manually set time if significantly off
- Enable NTP for automatic sync

Playback Won't Start

Symptoms:

- Playback button doesn't respond
- Loading spinner appears but video doesn't start
- Error message when trying to play

Device Offline

- Verify device shows Online status in GCXONE
- Check network connectivity to device
- Restart device if offline

Network Connectivity Issues

- Test network connectivity by pinging the device IP
- Check firewall rules allow playback ports
- Verify RTSP and HTTP ports are accessible
- Check network latency and packet loss

Insufficient Permissions

- Verify user has playback permissions
- Check role settings in user management
- Request admin to grant permissions if needed

Poor Playback Quality

Symptoms:

- Video is pixelated or blurry
- Low resolution playback
- Poor image quality

Low Quality Setting

- Increase playback quality in GCXONE
- Change from Low or Medium to High quality
- Check device recording quality settings

Bandwidth Limitations

- Check bandwidth availability
- Reduce concurrent playback streams
- Use Local Mode for on-site access

Using Wrong Stream

- Verify using primary stream and not sub-stream
- Check device stream configuration
- Ensure recording uses high quality stream

Frequent Buffering

Symptoms:

- Playback pauses frequently
- Loading spinner appears often
- Choppy playback

Insufficient Bandwidth

- Check available bandwidth
- Reduce playback quality
- Limit concurrent streams and use Local Mode if available

Network Latency or Packet Loss

- Test network latency by pinging the device IP
- Check for packet loss and optimize network routing

Device Performance

- Check device CPU and memory usage
- Reduce concurrent operations on device
- Restart device if overloaded and update firmware

Event Markers Not Showing

Symptoms:

- Timeline doesn't show event markers
- Events not visible on playback timeline
- Cannot navigate to events

Event Markers Disabled

- Enable event markers in GCXONE settings
- Verify event types are enabled
- Refresh timeline after enabling

No Events Recorded

- Verify events are being forwarded to GCXONE
- Check event configuration on device
- Test event generation

Timeline View Settings

- Check timeline zoom level — you may need to zoom in
- Verify marker density settings
- Try a different timeline view

Can't Export Video Clips

Symptoms:

- Export button doesn't work
- Export fails or shows errors
- Exported clips don't download

Export Permissions

- Verify user has export and clip download permissions
- Check role settings and request admin to grant permissions if needed

Export Settings Issue

- Verify export settings are configured
- Check export format and codec settings
- Verify storage location is accessible and check export size limits

Export Process Failed

- Check error messages for details
- Try a smaller export segment or different export format
- Retry the export operation

Multi-Camera Playback Issues

Symptoms:

- Synchronized playback not working
- Cameras out of sync
- Cannot view multiple cameras together

Time Synchronization

- Verify NTP is configured on all cameras
- Check time alignment between cameras and verify time zones match

Playback Sync Settings

- Enable synchronized playback mode
- Check that playback controls are linked
- Try re-selecting cameras for sync

Network Performance

- Check bandwidth for multiple streams
- Reduce quality if needed and use Local Mode for better performance
- Limit the number of synchronized cameras

Still Having Issues?

1. Gather information including device type and model, recording configuration, time synchronization status, error messages, and network configuration
2. Review GCXONE logs for playback errors and check device logs for recording issues
3. Contact Support and submit a support ticket with the gathered information