# Solid State Physics

## Alessio Cimma

# April 3, 2025

# Contents

| 1  | 10-03-25: — Introduction (Forneris) 1.1 Correction of the test   | <b>2</b><br>2   |
|----|--|-----------------|
| 2  | 12-03-25: — Tight binding model (Rigid Spheres) (Forneris)   | 4               |
| 3  | 13-03-25: — Continuation of Tight model (Forneris) 3.1 Direct & Indirect lattice                             | <b>7</b><br>7   |
| 4  | 17-03-25: — Direct & Indirect band gap (Forneris) 4.1 Electro-Magnetic fields in materials                   | <b>8</b>        |
| 5  | 19-03-25: — Electrical properties (Olivero) 5.1 Charge carriers & Doping                                     | <b>10</b><br>10 |
| 6  | <b>21-03-25:</b> — Drift & Diffusion (Olivero) 6.1 PN Junction   | <b>12</b><br>13 |
| 7  | 24-03-25: — EM waves in materials (Forneris) 7.1 Free electrons - plasma oscillation                         | <b>14</b><br>14 |
| 8  | 25-03-25: — EM waves in materials continuation (Forneris)  | 15              |
| 9  | 25-03-25: — Direct & Reverse bias (Olivero)  | 16              |
| 10 | 28-03-25: — Interactions of bound electrons with light (Forneris) 10.1 Ligh scattering                       | <b>18</b><br>19 |
| 11 | 28-03-25: — Continuation on depletion zones (Olivero)  11.1 Differences between direct and indirect band gap | 20<br>20<br>20  |
| 12 | 31-03-25: — Transmission and absorption (Forneris)   | 21              |
| 13 | 01-04-25: — Raman (Forneris)   | 22              |

| 14 03-04-25: — SRH (Olivero)         | 23 |
|--------------------------------------|----|
| 14.1 Final Formula                   | 24 |
| 15 03-04-25: — LAB Theory (Forneris) | 25 |

## 1 10-03-25: — Introduction (Forneris)

#### 1.1 Correction of the test

Linearly polarized light:

$$\vec{\mathcal{E}} = \mathcal{E}_0 \hat{e}_x \cos(\omega t) \tag{1}$$

Remember that the  $\vec{B}$  and  $\vec{\mathcal{E}}$  fields are  $\perp$ . We can obtain the value of the speed of light as:

$$c = \frac{1}{\sqrt{\mu_0 \varepsilon_0}} \tag{2}$$

Since we want to consider a linearly polarized plane, we consider the 1D case. We can then derive all informations about the period, frequency and pulse.

Band diagram of a crystal: We have regions where some energies are permitted and others where they are prohibited. The difference in the prohibited regions generate the difference between metals, semiconductors and insulators. The band diagram is a function of the crystal structure.

- Metals: valence band occupied at lowest energy.
- Semiconducotrs: valence band not occupied at lowest energy, and there is a small gap between the valence and conduction bands.
- Insulators: valence band not occupied at lowest energy, and there is a large gap between the valence and conduction bands.

The energy gap is the difference between the valence and conduction bands. From the following equation we can obtain the value of the energy gap:

$$E_T = k_B T \simeq 0.026 \text{eV} \ (@ 300 \text{K})$$
 (3)

Between 1 and 3 eV we have the energy gap for semiconductors, while for insulators it is greater than 3 eV. Remember that the probability follows:

prob. 
$$\propto e^{k_B T/E_g}$$
 (4)

This means that the definition of semiconductor or not depends on the temperature.

What is a photon: A photon is a wave-particle duality. And we can obtain its energy from the following equation:

$$E = h\nu = \frac{hc}{\lambda} = \frac{1240}{\lambda} \text{eV} \tag{5}$$

Another important information is its momentum:

$$p = \hbar \hat{k} \tag{6}$$

What is a phonon: A phonon is a quantized vibration of the crystal lattice (elementary quantum of lattice vibration). It is a wave-particle duality. The energy of an individual phonon is:

$$E = \hbar\Omega = E_{\Omega,n} = \left(\frac{1}{2} + n\right)\hbar\Omega, \ n \in \mathbb{N}$$
 (7)

The phonon density is given by:

$$\rho_{\Omega} \propto \frac{1}{\exp\left[\frac{\hbar\Omega}{KT}\right] - 1} \tag{8}$$

**Snell's law:** The refraction index is the relative speed of light in a medium. The refraction index is given by:

$$n = \frac{c}{v} \tag{9}$$

If we want to now how much the light is refracted, we can use Snell's law:

$$n_1 \sin(\theta_1) = n_2 \sin(\theta_2) \tag{10}$$

**Quantum states superposition:** Let's consider a system that can be in many different states. The total wavefunction is given by:

$$|\Psi\rangle = \sum_{i=1}^{N} c_i |\psi_i\rangle \tag{11}$$

**Photon absorbtion:** This phenomenon depends mostly on the energy of the photon and the energy gap of the material  $(h\nu \geq E_q)$ .

**P-type semiconductor:** We have acceptors creating new energy levels in the forbidden gap. The acceptors are positive ions. The energy levels are close to the valence band, effectively lowering the band gap. If I call  $N_a$  the number of acceptors, the hole density is  $\rho \simeq N_a$  and most importantely p >> n.

Ohm's law (Macro & Micro): The current is given by:

$$I = \frac{V}{R} \tag{12}$$

In microscopic terms, the current is given by the Drude's model.

## 2 12-03-25: — Tight binding model (Rigid Spheres) (Forneris)

**Introduction:** It's a formal way to describe the Band structure of crystals using a quantum mechanical approach. We can define a wavefunction for an electron bounded to the wavefunction (orbitals).

$$\hat{H}_{at} |\Psi\rangle = E_0 |\Psi\rangle \tag{13}$$

Next we move from a single atom to the periodic lattice.

**Atomic radius:** This can be considered the first thing that changes when using different elements. Consequentially the interatomic distance changes. We can use the rigid sphere model, where the sum of 2 radii gives us the interatomic distance. Since usually all the distances are expressed as chemical bonds, we will have the following type of radii, based on the bond nature:

- Ionic Radius (NaCl)
- Covalent Radius (Si, Ge)
- Metallic Radius (Metallic Na)
- Van der Waals Radius

Na example: Na values for different radii are 154pm for ionic and 186pm for metallic, which has a difference  $\sim 20\%$ . So the choice strongly depends on the usage.

If we consider the electronic configuration we have  $[Na] = (1S)^2 (2S)^2 (2P)^6 (3S)^1$ , which are 4 different wavefunctions. We can also consider the Hamiltonian as:

$$\hat{H} = \hat{T} + \hat{V}(x) \tag{14}$$

$$\hat{T} = \frac{\hat{p}^2}{2m} \tag{15}$$

$$\hat{V}(x) = -\frac{1}{4\pi\varepsilon} \frac{Ze^2}{x} \tag{16}$$

While the  $\Psi$  is considered as a product of a Radial component and Angular component:

$$\Psi(\vec{x}) = R_{n,l}(r) \cdot Y_{l,m}(\theta, \phi) \tag{17}$$

Additionally we replace the value of the radius with a new term  $\rho$  which is related to the Hydrogen radius ( $a_0$  is the Bohr radius  $\sim 53 \mathrm{pm}$ ). Just to have more relative values:

$$r \to \rho = \frac{r}{a_0} \tag{18}$$

From the notes we can note that we have essentially 2 different classes of electrons: localized and not localized (core and valence), this is because by plotting the Radial probability we see how the most external electrons are way out the ionic radius, so we can consider them as a 'lattice electron'. We can then divide the orbitals into 'core', 'valence' and 'lattice'. In addition we consider that  $\Psi$  are different superpositions of orbitals wavefunctions.

$$|\Psi\rangle \to |\varphi\rangle$$
 (19)

Where the  $\varphi$  is a repetition of  $\Psi$  that create the crystal structure. We can see that the different  $\Psi$  are overlapping between each other. And each  $\Psi$  is just traslated in space:

$$|\Psi_i\rangle = |\Psi(x = x_i)\rangle \tag{20}$$

Overlapping, bonding and anti-bonding: In the overlapped  $\Psi$  we can have a bonding or anti-bonding configuration of electrons. If this is taken to infinity we generate bands. We recover the LCAO model, generalizing  $|\varphi\rangle$  as a linear combination of  $|\Psi\rangle$ :

$$|\varphi(x)\rangle = \underbrace{\frac{1}{A}}_{\text{paymelization}} \cdot \sum_{i=1}^{N} \underbrace{c_i}_{\text{weights}} |\Psi(x - x_i)\rangle$$
 (21)

If in this simple example we have identical atoms,  $|c_i|^2 = 1$ ;  $\forall i$ . Limit cases: maximally symmetric with  $c_i = 1$ ;  $\forall i$  and  $c_i = (-1)^i$ ;  $\forall i$  which is the maximally antisymmetric case.

$$|\varphi_{+}(x)\rangle = \frac{1}{A} \sum_{i=1}^{N} |\Psi(x - x_i)\rangle$$
 (22)

$$|\varphi_{-}(x)\rangle = \frac{1}{A}(-1)^{i} \sum_{i=1}^{N} |\Psi(x - x_{i})\rangle$$
(23)

To interpolate between them we will use  $c_j$  which is a phase defined as  $e^{i\phi_j}$  where  $\phi_j$  ranges between 0 and  $j\pi$ .

**Potential:** We can also describe how consequentially the potential changes:

$$V_{\rm at} \propto -\frac{1}{x} \tag{24}$$

And with infinity of these equation we have overlaps, so we actually see the sum of all of them. (they go lower and smoother because values are negative). So how do we write the  $\hat{H}_{\text{crystal}}$ ?

$$\hat{H}_{\text{crystal}} = \hat{T} + \hat{V}_{\text{crystal}} \tag{25}$$

$$\hat{V}_{\text{crystal}} = \hat{V}_{\text{crystal}} + \underbrace{\left[\sum_{i=1}^{N} \hat{V}_{\text{at}}(x - x_i) - \sum_{i=1}^{N} \hat{V}_{\text{at}}(x - x_i)\right]}_{=0}$$
(26)

This means that we can actually rewrite it as:

$$\hat{H}_{\text{single}} = \underbrace{\frac{p^2}{2m} + \sum_{i=1}^{N} \hat{V}_{\text{at}}(x - x_i)}_{\text{Isolated}} + \underbrace{\left[\hat{V}_{\text{crystal}}(x - x_i) - \sum_{i=1}^{N} \hat{V}_{\text{at}}(x - x_i)\right]}_{\hat{V}_{\text{Perturbation}}}$$
(27)

So essentially we are considering the fact that the crystal exist and exchanges some energy as a perturbation of the isolated atom, which can be seen as a veery slow correction term that looks like a small sine negative wave. (look at Obsidian images) which has its maximum in the interatomic space (max distance between atoms). Of course the infinite limit goes like this:

$$\lim_{d \to \infty} \hat{V}_{\text{pert}}(x, d) = 0 \tag{28}$$

What happens when we switch again to the linear combination  $|\varphi\rangle$ ? Well,  $|\varphi\rangle$  is an eigenfunction of the Hamiltonian of the crystal, so it gives us the possibility to collapse it perfectly into the corresponding eigenvalue, which we couldn't do with the  $|\Psi\rangle$ , since being the isolated atom, it couldn't resolve the crystal perturbation:

Eigenvalue = 
$$(E_0 + \Delta E)$$
 (29)

$$\Delta E = \int \langle \varphi(x) | \hat{V}_{\text{pert.}} | \varphi(x) \rangle$$
 (30)

$$\frac{\Delta E}{E_0} \ll 1 \tag{31}$$

## 3 13-03-25: — Continuation of Tight model (Forneris)

When we consider functions that are very broad, they can sum such that the  $|\varphi_{+}\rangle$  almost creates a continuous line, which means that's as if the  $\lambda \to \infty$ . But for the rest nothing changes, the periodicity stays the same nonetheless.

1° Brillouin zone: This is the smallest zone of the crystal where i can define the physical properties that describe the properties of all the crystal. It is defined in the reciprocal space because everything ranges from:

$$k \in \left[0, \frac{\pi}{d}\right] \tag{32}$$

Where the range indicates the frequency range assumed by k, so 0 is the  $\varphi_+$  and the other the negative wavefunction. We can take a step further and calculate the  $\Delta E_{\pm}$  which means the maximum difference in energy for both the + version and the - version.

$$\Delta E_{\pm} = \int dx \langle \varphi_{\pm} | \hat{V}_{\text{pert}} | \varphi_{\pm} \rangle \tag{33}$$

The question is which delta energy will be greater? We must consider that the + one, has a smaller excursion, but the higher area covered. So in conclusion, yeah, the  $\Delta E_+ < \Delta E_-$ .

If we compare and plot the  $\Delta E$  with the interatomic distance, we notice the difference between the 2 tends both to 0, this is because at extreme distances, there are no overlaps. While as long as they differ, we have an energy band, indicating the Difference between the maximum excursion of energy generated from the different frequency of the wavefunction. It generates the pictures we studied with Scarano, where we have the continues variation of energy when travelling inside the Brillouin zone.

#### 3.1 Direct & Indirect lattice

**Direct / Bravais:** In the direct lattice we have the position of the nodes and they can be reached by using traslation vectors multiplied an integer number of times.

**Indirect** / **Reciprocal:** All represented using the wave vector  $\vec{k}$ , all the positions can again be reached by using a complex number times the base vectors.

**Primitive cell:** Smallest amount of space needed to describe the whole crystal by just applying a range of traslations. You can see some examples / exercises in the Obsidian file. Next follows a representation of energy bands, DOS and points of itnerest.

## 4 17-03-25: — Direct & Indirect band gap (Forneris)

In the indirect energy gap the jump is not straight, or more correctly, there's a change in the momentum of the electron, which will change its position. The momentum is calcualted as:

$$p_{\gamma} = \hbar \vec{\chi} \longrightarrow \chi = \frac{2\pi}{\lambda}$$
 (34)

This means that the photon is not carrying enough momentum to make the transition happen (3-4 orders of magnitude off). It's only enough to make the promotion, but not enough to move it.

**Phonons:** These are the answer to the momentum check. According to the conservation of energy we must have:

- $E_i + h\nu + \hbar\Omega = E_f$ , meaning that the initial energy + photon's energy + phonon's energy gives us the final energy.
- $\hbar k_i + \hbar \chi + \hbar K = \hbar k_f$ , meaning that the initial wave vector + the phonon's momentum (we can neglect the photon's momentum).

The energy of a phonon is:

$$\hbar\Omega = hc \ \Delta\left(\frac{1}{\lambda}\right) \sim 10^{-2} eV \tag{35}$$

Which is negligible in the energy calculation. See it like this: photons are very high frequency (high energy) but very small (low momentum), the phonons on the other hand are very low frequency (low energy) but big particles (high momentum). Since they have a small frequency, it's easy to find a phonon which vibrates at the right (low) frequency to get the right energy and jump, making the prohibited transition happen.

#### 4.1 Electro-Magnetic fields in materials

We will focus on electric changes through interactions. We will have *elastic* and *inelastic* interactions. Most of them will be considered as dipoles. For example we can start with:

Coulomb's law: It describes the interaction between two charges (in void).

$$\vec{F} = \frac{q_1 q_2}{4\pi\varepsilon_0 r^2} \hat{r} \tag{36}$$

The  $\varepsilon_0$  refers to vacuum, so in a material we will have a different magnitude of the force. Additionally the electric field associated to a charge is:

$$\vec{\mathcal{E}}_1 = \frac{q_1}{4\pi\varepsilon_0 r^2} \hat{r} \to \vec{F} = q_2 \vec{\mathcal{E}}_1 \tag{37}$$

$$-\nabla V = \vec{\mathcal{E}} \tag{38}$$

General writing:

$$\vec{\nabla}\vec{\mathcal{E}} = \frac{\rho}{\varepsilon_0} \tag{39}$$

And remember,  $\vec{\mathcal{E}}$  has its source from the + and sinks into the -.

**Dipoles:** We will not focus on understanding why and how some things happens, but remember that dipoles create EMW when oscillating and charges generate a EMW when moving (each of them have their associated equations).

Maxwell's equations: Quick recap of the equations, we will use them in the future to explain some behaviours in the materials. Also we saw how they are interlinked.

- $\nabla \cdot \mathcal{E} = \frac{\rho}{\varepsilon_0}$
- $\nabla \cdot B = 0$
- $\nabla \wedge \vec{B} = \mu_0 \vec{j} + \mu_0 \varepsilon_0 \frac{\partial \mathcal{E}}{\partial t}$
- $\nabla \wedge \mathcal{E} = -\frac{\partial \vec{B}}{\partial t}$

Combaining them we can obtain this bad boy, that relates everything with everything:

$$\nabla^2 \mathcal{E} = \frac{1}{c^2} \frac{\partial^2 \mathcal{E}}{\partial t^2} \qquad \mu_0 \varepsilon_0 = \frac{1}{c^2}$$
 (40)

**Displacement field:** It's introduced as  $\vec{D} = \varepsilon \vec{\mathcal{E}} = \varepsilon_0 \varepsilon_r \vec{\mathcal{E}} + \vec{P}$  where  $\vec{P}$  is the polarization field.

$$\vec{P} = \varepsilon_0(\varepsilon_r - 1)\vec{\mathcal{E}} \tag{41}$$

So it's like the additional response we got from the material reacting to the wave.

$$\vec{P} = n_c \hat{p} \tag{42}$$

We have  $n_c$  density of dipoles and  $\hat{p}$  microscopic ddipole moment. Essentially it measures how well the cahrges are aligned with the electric field.

#### Magnetic strength field:

$$\vec{H} = \frac{\vec{B}}{\mu} \tag{43}$$

Where  $\vec{B}$  is the magnetic induction field. This considers the material effect on the magnetic field. We can consider both electric and magnetic field as separate issues for their description. In the obsidian file there's the formula derivation, resulting in:

$$\vec{\nabla} \wedge \vec{H} = \vec{\gamma} + \frac{\partial \vec{D}}{\partial t} \tag{44}$$

This has consequences on the Drude's model, since it describes how the electric and magnetic field interact when current goes through a wire.

#### 5 19-03-25: — Electrical properties (Olivero)

Bands, electron states in crystals. This is mainly all we need to know. Bloch theorem which describes delocalized electrons in crystals. This plots the energy of the electron and the momentum (k which is also the k in  $p = \hbar k$ ).

What is interesting is that at almost  $0^{\circ}$ K we got all the electrons in the valence band. So in ideal conditions an insulator or something with a band gap do not let pass any current. But at room temperature, something passes.

When talking about 'free' charges, we refer to charges that move under the action of an Electrical field. The value of n and p are expressed in  $[cm^{-3}]$ , they are concentrations.

We will use the Fermi-Dirac statistical distribution for electrons. Quick recap: We have E on the x, and Probability function on the y. The form of this function depends on the  $E_F$  Fermi's energy. It's the 'Scalino Function'. Combining this with the DOS function we obtain that the  $E_F$  is considered to be in the middle of the forbidden gap.

The Fermi-Dirac is applied to states. If they do not exist in the forbidden gap, regardless of the distribution, we will not have electrons there. This statistic is the following:

$$f(E) = \frac{1}{\exp\left[\frac{E - E_F}{kT}\right] + 1} \tag{45}$$

$$g(E) = DOS \tag{46}$$

$$q(E) f(E) = \text{Electrons per unit of Volume}$$
 (47)

We do not derive the g(E)f(E), but let's just say we have a square root dependency on the energy. Just a side note, the g(E) is already the product of the energy band and the f(E).

The important formulas we need to know are:

#### 5.1 Charge carriers & Doping

$$\begin{cases} n^{-} = N_{c} \exp\left(\frac{E_{F} - E_{C}}{kT}\right) \\ p^{+} = N_{v} \exp\left(\frac{E_{V} - E_{F}}{kT}\right) \end{cases}$$

$$(48)$$

 $N_c$  are the actual states that can be occupied in the conduction band and there are about  $10^{19}$  if them in a cubic cm, while we have  $\sim 10^{22}$  atoms. This means that the actual free electrons are  $10^{10}$  (from f(E)g(E)). This means that the free electrons generated from the doping ( $\sim 10^{14}$ ) make this intrinsic free electrons negligible. For Silicon additionally we know that the  $E_g$  is 1.12eV. These are given from doping elements from the III and the VI element groups. This means that n and p are not equal, we will refer to  $n_i$  as  $n_i = n = p$ , which in an intrinsic semiconductor:  $n_i^2 = np$ , since the product needs to be the same, by the 'law of mass action' if one increases the other one decreases.

**Donors and Acceptors energy levels:** They are a little it higher and lower the conductive and valence band. They can help (thanks to heat) to make little jumps and complete the transition. (VI close to conduction band, and III close to valence band). The distances depend on the temperature!

So an assumption we can make is that at room temperature (300K) we can use the 'full ionization hypothesis' which says that all impurities are ionized, which means that  $N_D = N_D^+$ . Remember:

$$1C\ 1V = 1J\tag{49}$$

$$1.6 \cdot 10^{-19} C \ 1V = 1e1V = 1eV \tag{50}$$

Majority and Minority carriers: Usually  $n_i^2 = 10^{20} cm^{-6}$ , but by the law of mass etc,  $pn = n_i^2$ . And if from doping we have that n for example  $\sim 10^{14}$ , we have that the minority charge is  $\sim 10^6$ . They are negligible. As well as the intrinsic  $\sim 10^{10}$  free electrons. In this case we can see as if the Energy levels gets closer to one of the bands. The degenerate doping is when we have so much doping that the semiconductor start behaving as a conductor (The Fermi's level is inside one of the bands, conduction I suppose).

As a final note, we need 'shallow' levels and not 'deep' levels, so that get as close as possible to the conduction bands. And nothing (for now) beats Phosporous and Borum for Silicon.

## 6 21-03-25: — Drift & Diffusion (Olivero)

These are the methods by which a charge can move thorugh a material. We have tre Drude model which we will not derive, but we know has as consequence (remember, same sign):

#### Drude's Model:

$$v_{\rm drift} \propto \mathcal{E}$$
 (51)

We introduce the mobility  $\mu$ , which is measured as  $[\mu] = [v]/[\mathcal{E}] = cms^{-1}/Vcm^{-1} = cm^{2}V^{-1}s^{-1}$ :

$$v_{\text{drift, p}} = \mu_p \mathcal{E}$$
 (52)

$$v_{\text{drift. n}} = \mu_n \mathcal{E}$$
 (53)

We can introduce the current density j as:

$$J = i/S \to i = q/\Delta t \tag{54}$$

To write it with v:

$$j_{\text{drift, p}} = (+e)pv_{\text{drift, p}} = ep\mu_p \mathcal{E} = \sigma_p \mathcal{E}$$
  

$$j_{\text{drift, n}} = (-e)nv_{\text{drift, n}} = en\mu_n \mathcal{E} = \sigma_n \mathcal{E}$$
(55)

Meaning that the total j is:

$$j_{\text{total}} = j_n + j_p \tag{56}$$

This is not equal to 0, because the face the same direction (electrons are negative, so they generate a positive current in the opposite direction). The energy on the other hand changes as:

$$E = (-e)V (57)$$

Since this energy can be seen as the energy levels, if they are not horizontal, the Fermi level will change as well (intrinsic Fermi level).

**Diffusion:** Another case is when we have a disparity of charge for whatever reason they try to diffuse to homogenise.

$$j_{\text{diff.}} \propto -eD_p \partial p / \partial x = Acm^{-2} = C[D]cm^{-3}cm^{-1} \rightarrow [D] = cm^4 C^{-1}Cs^{-1}cm^{-2} = cm^2 s^{-1}$$
 (58)

So the concentration is negative since we go from a place with lots of holes into a place with low holes. That's why we have the "-", it's beacuse the current goes into the opposite direction of the gradient. Also he have the Diffusion parameters that tells us (based on the material analyzed) how easy the electrons or holes move. If they are 0, we are in intrinsic semiconductor with no diffusion.

If the concentration of carriers is not constant, the distance between a band and Fermi level will not be constant. We also have a relation between  $\mu$  and D:

$$D = \frac{kT\mu}{e} \tag{59}$$

#### 6.1 PN Junction

We have lot of positive charge carriers and low negative charge carriers, but overall the piece of semiconductor is neutral, since the electrons are bounded to their atoms. The same things goes for bot donors and acceptors.

If we put them together a depletion zone generates, where free holes and free electrons recombine, leaving only fixed charges. Thi generates a built-in electrical field pointing from positive to negative zone.

Also, if we are in equilibrium, the ferm levels are horizontal. Now the difficult thing is to describe what happens in the juntion. The point is that indipendetely of the charge carrier, when they move the overall current goes into one direction, from high density to low density.

If intereseted, the built-in votlage is:

$$V_{bi} = \frac{kT}{e} \ln \left( \frac{N_D N_A}{n^2} \right) \tag{60}$$

The approximation called 'sharp junction approximation' describes in a sharp way the total gharge across the junction. In this course is not done, but its possible to calculate where does the depletion zone ends for both parts.

$$x_n = \sqrt{\frac{2\varepsilon_0\varepsilon_r V_{bi}}{eN_D \left(1 + \frac{N_D}{N_A}\right)}} \tag{61}$$

#### 7 24-03-25: — EM waves in materials (Forneris)

EM waves in materials:

$$\underbrace{\vec{p}}_{\text{Polarization field}} = \underbrace{n_c}_{\text{density of micr. dipols}} \cdot \underbrace{\hat{p}}_{\text{micr. dipole moment}}$$
(62)

Displacement field:

$$\vec{D} = \varepsilon_0 \mathcal{E} + \vec{P} \tag{63}$$

Now we can rewrite the Displacement field as:

$$\vec{D} = \varepsilon_0 \varepsilon_r \mathcal{E} \tag{64}$$

We also can introduce:

$$\vec{H} = \frac{\vec{B}}{\mu_0 \mu_r} \tag{65}$$

And lastly rewrite the Maxwell equations (previous section). We can then use the Ohm's law to express how the charges are moving in the material:

$$V = RI \tag{66}$$

$$\vec{j} = \underbrace{\sigma}_{\text{conductivity}} \vec{\mathcal{E}} \tag{67}$$

As an anticipation, this conductivity will depend on the frequency of the EM. So the dipols of the material will oscillate when interacting with it, but also the opposite happens: the dipols will change the EM.

So to proceed we can combine two equations and get:

$$\vec{\nabla} \left( \vec{\nabla} \vec{\mathcal{E}} \right) = -\frac{\partial}{\partial t} \left( \vec{\nabla} \times \vec{B} \right) \tag{68}$$

Continua una dimostrazione sulle wave equations for materials, fai riferimento ai file obsidian. It seems that the result will be similar to the description of the prism and rainbows. We obtain at the end the refractive index. Lambert-Beer law.

#### 7.1 Free electrons - plasma oscillation

Using Drude's model we can have a point charge when we apply a static electric field.

## 8 25-03-25: — EM waves in materials continuation (Forneris)

Tried fixing Fra's Laptop.

#### Plasma Frequency:

$$\omega_p^2 = \frac{q^2 n_c}{m\varepsilon_0} = [s^{-2}] \tag{69}$$

This is the natural osc. frequency (collective osc. frequency) of electrons in a material. So now we can substitute in some previous equations (check obsidian, i think this is about refractive index) with this new frequency.

$$\frac{i\sigma(\omega)}{\omega\varepsilon_0} = \frac{iq^2n_c\tau}{m\varepsilon_0\omega} \left[ \frac{1}{1 - i\omega\tau} \right] = i\frac{\omega_p^2}{\omega^2} \left[ \frac{\omega\tau}{1 - i\omega\tau} \right]$$
 (70)

$$\eta^2 = \varepsilon_r + \frac{\omega_p^2}{\omega^2} \left[ \frac{i\omega\tau}{1 - i\omega\tau} \right] \tag{71}$$

$$\eta = \frac{c}{v} \tag{72}$$

Limit cases for  $\omega \tau$ : Obsidian.

## 9 25-03-25: — Direct & Reverse bias (Olivero)

Recap of the last lecture.

**Biased junction:** Remember that we use a coordinate system where we apply +1V from the source to the p part first thus reducing the  $\Delta V$  in the junction.

So when we apply a POSITIVE voltage, the BIAS voltage will DECREASE:  $V_{bi} \rightarrow V_{bi} - V$ , so that the  $\Delta V$  will diminuish. The opposite will happen changing a sign or the origin of the voltage.

Capacitance: We can measure the electrical capacitance: let's say we are in an asymmetrical doping, so that  $N_A \gg N_D \to N_D/N_A \ll 1$ . By mantaining the charge neutrality,  $x_p \ll x_n$ . This will change the triangle plot, by changing the size of each zone. It will reduce the  $x_p$  region and/or enlarge the  $x_p$  zone.

Now, remember the formula for the capacitance for 2 planes:

$$C = \frac{Q}{V}$$
 More general definition  $\rightarrow$   $C = \frac{\partial Q(V)}{\partial V}$  (73)

So lets start from the charge Q:

$$Q = \underbrace{(eN_D)}_{vol. \ density} \cdot \underbrace{S}_{surface} \cdot \underbrace{\sqrt{2eN_D\varepsilon_0\varepsilon_r(V_{bi} + V)}}_{width}$$

$$(74)$$

$$C = \underbrace{S \cdot \sqrt{\frac{eN_D \varepsilon_0 \varepsilon_r}{2(V + V_{bi})}}}_{derivative \ of \ Q}$$

$$\tag{75}$$

We can at the end linearize the formula by plotting  $1/C^2$  instead of C, getting us something like:

$$\frac{1}{C^2} = aV + b \tag{76}$$

This lets us know the value experimentally  $N_D$  from a:

$$N_D = \frac{2}{S^2 e \varepsilon_0 \varepsilon_r Q} \tag{77}$$

Once we have  $N_D$ , we also can determine b, which is the  $V_{bi}$ .

**Applied V:** What happens when we apply a voltage to the junction?

$$V_{bi} - V = \frac{k_B T}{e} \ln \left( \frac{p_p}{p_n} \right) \tag{78}$$

Notice that we don't have  $p_{p0}$  and  $n_{n0}$ , because we are not in initial conditions. What will happen is that the amount of holes in  $x_n$  will increase the lower the  $\Delta V$  gets. In this conditions we can say that the concentration of  $p_{p0}$  and  $p_p$  is almost equal, but there's a big change in  $p_n$ .

Weak injection conditions:

$$p_n = p_{n0} \underbrace{\exp\left(\frac{eV}{k_B T}\right)}_{V>0 \to ris<1} \tag{79}$$

• Reverse bias:  $p_n < p_{n0}$ 

• Direct bias:  $p_n > p_{n0}$ 

Far from the depletion zone, we have only diffusion at equilibrium.

**Continuity equation:** To describe the current that passes in direct bias near the depletion zone we use the continuity equation:

$$\frac{\partial p_p}{\partial t} + \frac{\partial j_p}{\partial x} = -qU \tag{80}$$

Where U is the net recombination rate. Normally it is 0, but in direct bias the generation has an additional term:

$$G_{new} = G + \Delta G \tag{81}$$

Which are the carriers moved in from the  $\Delta V$ .

**Diffusion Lenght**  $L_P$ : Obsidian files.

# 10 28-03-25: — Interactions of bound electrons with light (Forneris)

$$\eta = \sqrt{\left(\varepsilon_r + \frac{i\sigma(\omega)}{\varepsilon_0 \omega}\right)} \tag{82}$$

The first term in the parenth. is the polarizability and the second describes the free electron. So in free electron, it oscillates due to the energy of the wave, what about the bound-electron? It still oscillates, but now that is bound, it has a descrete set of energy in which it can move. So only certain amount of energy in the waves can be absorbed. This explanation is based on the Tight-Binding model, where  $e^-|\varphi\rangle$ .

We now consider the wavefunction of the crystal perturbated by the EMW, so we now have:

$$\hat{H}_{\rm em}(t) = \hat{H}_{\rm crystal} + \hat{V}_{\rm em}(t) \tag{83}$$

$$|\Phi(x,t)\rangle = \frac{1}{B} \sum_{E_l} b_e(l) |\Phi_e(l)\rangle \tag{84}$$

This says that based on the probability of the jump occurring, energy and so on we can calculate the probability of the electron to be found in an excited state.

$$|\Psi(x,t)\rangle = \frac{1}{B} [b_1(t) |\Phi_1(x)\rangle + b_2(t) |\Phi_2(x)\rangle]$$
 (85)

We now considered the most basic case, but this equation can describe all the possible transition, even the recombination (low), not only jump (high).

Unfortunately, we can't use the stationary Schrödinger, so we will use the time evolution:

$$i\hbar \frac{\partial}{\partial t} |\Phi(x,t)\rangle = \hat{H}_{elm}(t)\Phi(x,t)$$
 (86)

To solve it follow the steps:

- Plus the equation  $|\hat{H}_{elm}\Psi(x,t)\rangle$  in the Schrödinger equation's.
- Find the expression relation for  $b_l(t)$
- Assumptions on  $\hat{V}_{elm}$  strength ( $\hat{V}_{elm} \ll \hat{V}_{crystal}$ )

Now we need to connect it to refractive index:

$$\vec{D} = \varepsilon_0 \varepsilon_r \vec{\mathcal{E}} = \varepsilon_0 \mathcal{E} + \underbrace{\vec{P}}_{Polarization}$$
(87)

$$\vec{p} = \varepsilon_0(\varepsilon_r - 1)\vec{\mathcal{E}} \tag{88}$$

$$\varepsilon_r = 1 + \frac{\vec{p}}{\varepsilon_0 \vec{\mathcal{E}}} \tag{89}$$

$$\vec{p} = n_{b\vec{p}} \tag{90}$$

So it's the density of micropoles generated by bound electrons.

. . .

$$\varepsilon_r(\omega) = 1 + \sum_{l \neq G} F_l \frac{\hbar^2 \omega_b^2}{(E_l - E_G)^2 - \hbar^2 \omega^2}$$
(91)

Where the G is the ground state, l is the higher energy state and  $F_l$  us the strength of the interaction (selection rule). The denominator is the resonance equation. Get the conclusions from Obsidian.

#### 10.1 Ligh scattering

We have:

• Elastic: delayed emission  $(10^{-12} - 10^{-7} \text{s})$  is the principle one (Rayleigh scattering)

• Inelastic:  $h\nu \neq h\nu'$ 

### 11 28-03-25: — Continuation on depletion zones (Olivero)

When talking about the net recombination rate, we must always remember that:

$$U_p = U_n \tag{92}$$

Doesn't matter if we are in equilibrium or not, this is due to the charge neutrality, an electron cannot disappear without roombining with a hole.

So even if the different diffusion currents are not constant, the total current is. We can consider constant the current in the depletion region. This is because the width of the depletion region is extremely narrow (2 orders of magnitude) respect to the exponential decay, so it doesn't change that much. This effect is called transparency of the deplation region (respect to the transfer of external charges). We can check that by doing the substitutions in the  $j_{\text{diff.}}$  at the one of the limits of the depletion zone.

By exploiting this thing, we can calculate the remaining diffusion current for the other charge carrier and obtain our results. Obtaining:

$$i(V) = i_o \left[ e^{\frac{eV}{kT}} - 1 \right] \tag{93}$$

From this equation we can calculate the  $D_p$  and  $D_n$ .

#### 11.1 Differences between direct and indirect band gap

. . .

#### 11.2 Introduction of Shockley-Read-Hall theory

This is based on the concept of traps that are found at mid-band level, they can generate both holes and electrons (based on the POV). We start by the fact that most probably the  $R_n \propto n$ , but also a term referred to the density of traps charged such that they can accept an electron or hole:  $R_n \propto n \cdot N_T^+$ . The final result has a proportional factorthat contains the probability of trapping an electron per unit of concentration:

$$R_n = r_n \cdot n \cdot N_T^+ \tag{94}$$

$$G_n = g_n \cdot N_T^0 \tag{95}$$

We don't care about the concentration, because since we have virtually infinite amount of concentration of holes where to put the electron generated, it will not anyhow impact the generation rate.

$$R_p = r_p \cdot p \cdot N_T^0 \tag{96}$$

$$G_p = g_p \cdot N_T^+ \tag{97}$$

The probability of finding  $N_T$  neutral or positive will depend on  $E_T$ , which will depend on the Fermi-Dirac distribution. So:

$$N_T^0 = N_T \cdot f_{\rm FD}(E_T) \tag{98}$$

# 12 31-03-25: — Transmission and absorption (Forneris)

We have absorption with  $\lambda$  smaller than the gap energy, transmission with  $\lambda$  between gap and plasma frequency and reflection with  $\lambda$  bigger than plasma frequency.

Beginning of Raman: Obsidian...

# 13 01-04-25: — Raman (Forneris)

Even Fra is not taking notes, useless lecture, read the slides about Raman and Sensors.

#### 14 03-04-25: — SRH (Olivero)

Thorugh traps level some jumps can occour. We can talk about the rate at which a certain number of trap events happen in a certain  $\Delta t$ .

$$R_n = r_n n N_T^+ \tag{99}$$

To better express  $r_n$  we can use some microscopic parameters as it follows: ome electron in the crystal with a certain concentration of positive trap levels  $N_T^+$ . We can describe a probability in terms of a surface area, called  $\sigma[cm^2]$ . We can also say that the electron has a certain speed due to the thermal excitation. In addition we introduce a  $\tau_{tap}$  which it the mean time that an electron can move before getting caught by a trap.

$$v_{th} \cdot \tau_{trap} = l \tag{100}$$

$$V_{cil} = \sigma \cdot l \tag{101}$$

$$N_T^+ = \frac{1}{\sigma \cdot l} \tag{102}$$

Since a rate is definied as objects per second:

$$R_n = \frac{1}{\tau_{trap}} n \tag{103}$$

$$R_n = \sigma_{trap} v_{th} N_T^+ n \tag{104}$$

$$R_n = r_n N_T^+ n \tag{105}$$

Remember that:

$$N_T = N_T^0 + N_T^+ (106)$$

And each one of these terms is enabling to just on type of carriers.

**Fermi-Dirac:** We should also add the contribuition of the Fermi-Dirac distribuition at a certain energy (the traps one).

$$R_n = r_n N_T (1 - \underbrace{f}_{f_{FD}(E_T)}) n \tag{107}$$

We also want to condense the first two terms:

$$\underbrace{v_{th}\sigma_{trap}}_{T_n}N_T = \frac{1}{\tau_n} \tag{108}$$

Which is very similar to the  $\tau_{trap}$ , the only difference is that we consider all types of traps. And this is given from the f term. So the  $\tau_n$  is an absolute value, not depending from the Fermi level, while  $\tau_{trap}$  is  $\tau_n$  to which f was applied.

We can make the same thought process for the other rates (holes and electrons from both VB and CV). We than unite them obtaining an hilarious series of  $\frac{1}{\tau}f_{np}$ . Derivation in Obsidian files.

#### Final Formula 14.1

$$U = \frac{pn - n_i^2}{\tau_p(n + n_T)\tau_n(p + p_T)}$$
 (109)

But if we know that in a pn junction we have the following, and in this case they are similar:

$$U = \frac{\Delta p}{\tau} \tag{110}$$

$$n_{n0} = N_D$$
  $p_{n0} = \frac{n_i^2}{N_{n0}} = \frac{n_i^2}{N_D}$  (111)

$$n_{n0} = N_D p_{n0} = \frac{n_i^2}{N_{n0}} = \frac{n_i^2}{N_D} (111)$$

$$p_n = p_{n0} + \Delta p \underbrace{n_n \simeq n_{n0}}_{\text{Weak injection}} = N_D (112)$$

So we can rewrite U as (many terms  $\sim 0$  because  $N_D \gg n_i$ ):

$$U = \frac{\Delta p}{\tau_p} \tag{113}$$

Which was the initial expression, that approximates the diffusion current of the carriers.

# 03-04-25: — LAB Theory (Forneris)

Encription lecture