65.Engine Wiring Harness and Transmission Cord A: LOCATION

Connector				Connecting to		
No.	Pole	Color	Area	No.	Description	
E2	54	Black	A-3	B21	Bulkhead wiring harness	
E3	16	Brown	A-4	B22		
E4	2	Blue	A-3		Purge control solenoid valve	
E5	2	Dark gray	B-2		Fuel injector No. 1	
E6	2	Dark gray	A-2		Fuel injector No. 3	
E8	2	Black	A-3		Engine coolant temperature sensor	
E10	3	Black	B-4		Crankshaft position sensor	
E11	1	_	B-3		Oil pressure switch	
E14	2	Black	B-4		Knock sensor	
E16	2	Dark gray	B-4		Fuel injector No. 2	
E17	2	Dark gray	B-4		Fuel injector No. 4	
E18	6	Dark gray	A-3		EGR control valve	
E21	3	Black	A-3		Manifold absolute pressure sensor	
E24	4	Light gray	B-2		Front oxygen (A/F) sensor	
E25	4	Black	B-2		Rear oxygen sensor	
E31	3	Black	B-2		Ignition coil No. 1	
E32	3	Black	C-4		Ignition coil No. 2	
E33	3	Black	A-2		Ignition coil No. 3	
E34	3	Black	B-4		Ignition coil No. 4	
E35	3	Light gray	C-4		Intake camshaft position sensor LH	
E36	3	Light gray	B-1		Intake camshaft position sensor RH	
E37	2	Black	C-4		Intake oil control solenoid LH	
E38	2	Black	B-1		Intake oil control solenoid RH	
E51	5	Light gray	B-4		Tumble generator valve actuator LH	
E55	5	Light gray	A-3		Tumble generator valve actuator RH	
E57	6	Black	B-4		Electronic throttle control	
E62	3	Light gray	B-2		Exhaust camshaft position sensor RH	
E63	2	Black	B-1		Exhaust oil control solenoid RH	
E65	3	Light gray	C-4		Exhaust camshaft position sensor LH	
E66	2	Black	C-4		Exhaust oil control solenoid LH	
E75	2	Black	B-3		Engine oil temperature sensor	
E130	1	*	C-3		Oil level switch	
E163	5	Black	A-3		ISG	
★: White o	r natural col	or				

Connector				Connecting to		
No.	Pole	Color	Area	No.	Description	
T3	16	Brown	C-3	B12	- Bulkhead wiring harness	
T4	12	Light gray	C-3	B11		
T7	9	Black	D-3		Inhibitor switch	
T11	10	*	D-3		Control valve body	
T32	20	Gray	C-2	B603	Bulkhead wiring harness	
T33	3	Black	D-3		Front wheel speed sensor	
AT4	3	Dark gray	D-4		Secondary speed sensor	
AT5	3	Light gray	D-3		Turbine speed sensor	
AT6	3	Black	D-4		Secondary pressure sensor	

Connector				Connecting to		
No.	Pole	Color	Area	No.	Description	
HV1	_	_	D-4		Drive motor	
HV11	3	Orange	D-4	HV12	Electric oil pump harness	
HV12	3	Orange	D-4	HV11	Power cable	

