
## 4. Electrical Component Location

## A: LOCATION



- (1) VDC CM
- (2) Power steering CM
- (3) Drive motor CM
- (4) High voltage battery (battery energy CM)
- (5) Electric oil pump inverter
- (6) Auto headlight beam leveler CM
- (7) Steering angle sensor
- (8) Combination meter
- (9) A/C control panel
- (10) MFD
- (11) Body integrated unit
- (12) Data link connector

- (13) TCM
- (14) Airbag CM
- (15) Hybrid powertrain CM
- (16) ECM
- (17) Keyless access CM