## 70.Rear Wiring Harness LH

## A: LOCATION

Connector				Connecting to				
No.	Pole	Color	Area	No.	Description			
R3	20	*	D-2	B99	Bulkhead wiring harness			
R4	1	Black	C-2		Parking brake switch			
R5	20	*	D-2	B92	Bulkhead wiring harness			
R9	3	*	C-4		Front door switch LH			
R10	8	*	C-4	D22	Rear door cord LH			
R41	4	*	C-3		Seat heater LH			
R81	19	Black	C-2	R82	Rear wiring harness RH			
R107	2	*	C-3		Seat belt switch LH			
R123	2	Yellow	D-2	AB62	Front door cord LH			
R167	24	*	D-2	i102	Instrument panel wiring harness			
R168	20	*	C-2		F/B			
R339	10	*	D-3	i2	Instrument panel wiring harness			
★: White o	★: White or natural color							

Connector				Connecting to		
No.	Pole	Color	Area	No.	Description	
AB17	24	Yellow	D-1		Airbag CM	
AB19	4	Yellow	C-3		Side airbag module LH	
AB21	2	Black	C-4		Pretensioner LH	
AB23	4	Yellow	C-4		Side airbag sensor LH	
AB35	2	Black	C-2		F/B	

