14.Rear Window Glass

A: REMOVAL

1) Disconnect the ground cable from battery. <Ref. to NT-5, BATTERY, NOTE, Note.>


NOTE

For the 12 volt engine restart battery of HEV model, disconnect the ground terminal from 12V engine restart battery sensor.

- 2) Disconnect the rear defogger connector.
- 3) Remove the glass rear window in the same procedure as for the glass front window. <Ref. to GW-35, REMOVAL, Windshield Glass.>


B: INSTALLATION

1) Fabricate the cartridge nozzle tip as shown and set the sealant gun with the adhesive.



2) Smoothen and clean the adhesive surfaces of the glass - rear window and body using the same procedures as for the glass - front window. <Ref. to GW-38, INSTALLATION, Windshield Glass.>


3) Attach the dam rubber - rear to the glass - rear window.



4) Attach the molding - rear window to the glass - rear window.


CAUTION:

Be careful to attach the molding - rear window so that the molding has no loose or undulating part.



- (1) Align the molding rear window (A) to the upper ends (a) of the glass rear window (C).
- (2) Install the molding rear window from both corners of the upper edge toward the center (b).
- (3) Install the molding rear window from both corners of the upper edge toward the lower side (c).
- (4) Firmly apply the double sided tape (B) of the molding rear window evenly to the surface of the glass rear window.

- 5) Install the glass rear window in the same procedure as for the glass front window. <Ref. to GW-38, IN-STALLATION, Windshield Glass.>
 - (1) Apply the primer to the adhesive surface of glass rear window side and body side using sponge.
 - (2) Apply adhesive to the end back surface of the glass rear window.



- (a) Application of primer (glass side)
- (c) Adhesive

(e) Dam rubber - rear

- (b) Application of primer (body side)
- (d) Molding rear window
- (3) Insert the locating pins rear window into the rear panel holes, and install the glass rear window.
- (4) Lightly press the entire perimeter of the glass rear window for tight fit.
- (5) Make flush the adhesive surface jutted out using spatula.
- 6) After completion of all work, allow the vehicle to stand for about 24 hours.

NOTE:

- When opening/closing the door after the glass rear window was bonded, always lower the glass assembly door first, and then open/close it carefully.
- Move the vehicle slowly.
- For minimum drying time and vehicle standing time before driving after bonding, follow instructions or instruction manual from the adhesive manufacturer.
- 7) Connect the rear defogger connector.
- 8) After curing of adhesive, pour the water on external surface of vehicle to check that there are no water leaks.

NOTE:

When a vehicle is returned to the user, tell him or her that the vehicle should not be subjected to heavy impact for at least three days.