
3. Electrical Component Location

A: LOCATION



- (1) Engine control module (ECM)
- (2) Cruise control command switch
- (3) Stop light and brake switch
- (4) Cruise indicator light and cruise set indicator light
- (5) Transmission control module (TCM) (CVT model)
- (6) Inhibitor switch (CVT model)
- (7) Neutral position switch (MT model)
- (8) Clutch switch (MT model)