72.Door Cord RH

A: LOCATION

Connector				Connecting to		
No.	Pole	Color	Area	No.	Description	
D1	8	Black	C-2	B30	Bulkhead wiring harness	
D12	2	*	C-2		Front door speaker RH	
D13	6	Dark gray	C-2		Front power window motor RH	
D15	10	*	B-2		Outer mirror assembly RH	
D17	8	*	B-2		Front power window sub-switch	
D18	10	*	B-3		Front door lock actuator RH	
D28	8	*	B-4	R13	Rear wiring harness RH	
D29	2	*	B-4		Rear door speaker RH	
D30	6	Dark gray	B-4		Rear power window motor RH	
D31	8	*	B-4		Rear power window sub-switch RH	
D32	10	*	A-4		Rear door lock actuator RH	
D56	6	*	B-3		Outer handle RH	
D83	28	*	C-2	i76	Instrument panel wiring harness	
D125	5	*	B-2		Passenger's seat door lock switch	

Connector				Connecting to		
No.	Pole	Color	Area	No.	Description	
AB63	2	Yellow	C-1	R124	Rear wiring harness RH	
AB64	2	Yellow	B-3		Front door impact sensor RH	

