

3. Power Supply Circuit

A: WIRING DIAGRAM

- 1. WITHOUT PUSH BUTTON START
- Engine room side


P-SUP-01







· Passenger room side


P-SUP-02










RELAY HOLDER RELAY HOLDER









No.	Load
MB-1	VDC CM
MB-2	VDC CM
MB-3	Wiper relay
MB-4	Sub fan relay
MB-5	Mirror heater LH
IVID-3	Mirror heater RH
	Rear defogger A/C control panel
MB-6	Body integrated unit
MB-7	Main fan relay 2
MB-8	Main fan motor
MB-9	ECM
MB-10	
MB-11	Main fan relay 2
	Main fan relay 2
MB-12 MB-13	Body integrated unit
	Body integrated unit
MB-16	Front combination light LH
MD 47	Front combination light RH
MB-17	Daytime running light relay
MB-18	Body integrated unit
MB-19	Horn
MB-20	Horn
MB-21	Horn switch
MD 00	Body integrated unit
MB-22	A/F, oxygen sensor relay
MB-23	Main relay
MD 04	IG relay
MB-24	Electronic throttle control relay
MB-25	Fuel pump relay TCM
MB-26	
MD 07	Self shut relay
MB-27	ECM
MD 00	Data link connector
MB-28	Key warning switch
	Turn signal and hazard unit
MB-29	Body integrated unit
IVIB-29	Spot map light
	Room light
	Body integrated unit Immobilizer antenna
MD 00	
MB-30	Power window circuit breaker
MB-32	Tail & illumination relay
AI T 4	Daytime running light relay
ALT-1	Combination meter
ALT-2	ECM Chartes releved
ST-1	Starter relay 1
CT O	Clutch start switch
ST-2	Starter relay 1
FB-1	Trailer connector


No.	Load
FB-3	Stop light and brake switch
	Brake relay
FB-4	Wiper deicer relay
FB-5	Seat heater relay
FB-6	Body integrated unit
FB-8	Blower motor relay
FB-9	Front fog light relay
	Front fog light relay LH
	Front fog light relay RH
FB-10	Audio
	MFD
	Navigation unit
FB-12	Keyless entry CM
	TPMS & keyless entry CM
	Trunk room light (4 door model)
	Luggage room light (5 door model/XV model)
FB-18	Combination meter
	Body integrated unit
	Impact sensor
	Air mix door actuator LH (with left/right inde-
	pendent air conditioner)
	Air mix door actuator RH (with left/right inde-
	pendent air conditioner)
	Mode door actuator
	Air mix door actuator (without left/right independent air conditioner)
	Security CM
	A/C control panel
	Stereo camera
FB-19	Remote control mirror switch
FB-20	Seat heater relay
	Rear view mirror
FB-21	Rear accessory power supply socket
FB-22	Front accessory power supply socket
FB-25	Audio
	Navigation unit
	AUX input terminal
FB-28	A/C control panel
FB-29	Body integrated unit
FB-32	Clutch switch
	Impact sensor
	Data link connector
	Stop light and brake switch
	Wiper deicer relay
	Sunroof motor assembly
	Sunroof switch
	Sunroof switch (tilt)
FB-34	Turn signal and hazard unit
1	


No.	Load
FB-35	Inhibitor switch
	Back-up light switch
	Auto headlight beam leveler CM
FB-36	Combination meter
	MFD
FB-38	ECM
	TCM
	Body integrated unit
	Fuel pump relay
	Stereo camera
FB-41	Airbag CM
FB-42	Power window relay
	Wiper relay
FB-44	VDC CM
	Steering angle sensor
	Power steering CM
FB-45	A/C control panel
FB-46	A/C relay
	Sub fan relay
	Pressure switch
	Blower motor relay
FB-47	Occupant detection control module
FB-48	TPMS & keyless entry CM
BAT-1	Power steering CM

2. WITH PUSH BUTTON START

• Engine room side


P-SUP(P)-01








· Passenger room side

o-SUP(P)-02











1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20


1 2 3 4 5 6 7 8 9 10 11 12

1 2 3 4 5 6 7 8

1 2 3 4 5 6 7







No	Load
No.	=++++
MB-1	VDC CM
MB-2	VDC CM
MB-3	Wiper relay
MB-4	Sub fan relay
MB-5	Mirror heater LH
	Mirror heater RH
	Rear defogger
140.0	A/C control panel
MB-6	Body integrated unit
MB-7	Main fan relay 2
MB-8	Main fan motor
MB-9	ECM
MB-10	Main fan relay 2
MB-11	Main fan relay 2
MB-12	Body integrated unit
MB-13	Body integrated unit
MB-16	Front combination light LH
	Front combination light RH
MB-17	Daytime running light relay
MB-18	Body integrated unit
MB-19	Horn
MB-20	Horn
MB-21	Horn switch
	Body integrated unit
MB-22	A/F, oxygen sensor relay
MB-23	Main relay
	IG relay
MB-24	Electronic throttle control relay
MB-25	Fuel pump relay
MB-26	TCM
	Self shut relay
MB-27	ECM
	Data link connector
MB-28	Turn signal and hazard unit
	Body integrated unit
MB-29	Spot map light
	Room light
	Body integrated unit
	Immobilizer antenna
MB-30	Power window circuit breaker
MB-31	Accessory relay
	IG relay 1
	IG relay 2
MB-32	Tail & illumination relay
	Daytime running light relay
MB-33	Keyless access CM
	ID code box
ALT-1	Combination meter
ALT-2	ECM
ST-2	Starter relay 1
01.2	Clartor rolly 1

No.	Load
FB-1	Trailer connector
FB-3	Stop light and brake switch
	Brake relay
FB-4	Wiper deicer relay
FB-5	Seat heater relay
FB-6	Body integrated unit
FB-7	Remote engine start CM
FB-8	Blower motor relay
FB-9	Front fog light relay
	Front fog light relay LH
	Front fog light relay RH
FB-10	Audio
	MFD
	Navigation unit
FB-12	Keyless entry CM
	TPMS & keyless entry CM
	Trunk room light (4 door model)
	Luggage room light (5 door model/XV model)
FB-18	Combination meter
	Body integrated unit
	Impact sensor
	Air mix door actuator LH (with left/right inde-
	pendent air conditioner)
	Air mix door actuator RH (with left/right inde-
	pendent air conditioner)
	Mode door actuator
	Air mix door actuator (without left/right independent air conditioner)
	dent air conditioner)
	Security CM A/C control panel
	Steering lock CM
	<u> </u>
FB-19	Stereo camera Remote control mirror switch
	Seat heater relay
FB-20	Rear view mirror
FB-21	Rear accessory power supply socket
FB-22	Front accessory power supply socket
FB-25	Audio
1-D-20	Navigation unit
	AUX input terminal
FB-28	A/C control panel
FB-29	Body integrated unit
FB-32	Impact sensor
	Data link connector
	Stop light and brake switch
	Wiper deicer relay
	Sunroof motor assembly
	Sunroof switch
	Sunroof switch (tilt)
	Remote engine start CM
	riemote engine start OW

No.	Load
FB-34	Turn signal and hazard unit
FB-35	Inhibitor switch
	Back-up light switch
	Auto headlight beam leveler CM
FB-36	Combination meter
	MFD
FB-38	ECM
FB-38	
	TCM
	Body integrated unit
	Fuel pump relay
	Keyless access CM
	Stereo camera
FB-41	Airbag CM
FB-42	Power window relay
	Wiper relay
FB-43	Steering lock CM
FB-44	VDC CM
	Steering angle sensor
	Power steering CM
FB-45	A/C control panel
FB-46	A/C relay
	Sub fan relay
	Pressure switch
	Blower motor relay
FB-47	Occupant detection control module
FB-48	TPMS CM
BAT-1	Power steering CM