
## 50.Starter System


## **A: WIRING DIAGRAM**

## 1. WITHOUT PUSH BUTTON START



WI-48316

## 2. WITH PUSH BUTTON START



WI-48317