## 1. General Description

## A: SPECIFICATION

Refer to "Body Repair Manual" for general description of body structure, reference points and reference dimensions.

## **INSTRUMENTATION/DRIVER INFO**



		Page
1.	General Description	2
2.	•	
3.	· · · · · · · · · · · · · · · · · · ·	
4.	Multi-function Display (MFD) System	13
5.	· • · · · ·	
6.	Speedometer	23
7.		24
8.	Fuel Gauge	25
9.	ECO Gauge	26
	Multi-function Display (MFD)	
	Steering Switch	