## 8. Diagnostics with Phenomenon

## **A: INSPECTION**

Refer to "Diagnostics with Phenomenon" of "PEDESTRIAN ALERT SYSTEM (DIAGNOSTICS)" section. <Ref. to PA(diag)-16, Diagnostics with Phenomenon.>

## PEDESTRIAN ALERT SYSTEM (DIAGNOSTICS)

## PA(diag)

		Page
1.	Basic Diagnostic Procedure	2
2.	Check List for Interview	3
3.	General Description	4
4.	Electrical Component Location	5
5.	Control Module I/O Signal	6
6.	Subaru Select Monitor	7
7.	Read Diagnostic Trouble Code (DTC)	9
8.	Clear Memory Mode	10
9.	Read Current Data	11
10.	System Operation Check Mode	
11.	List of Diagnostic Trouble Code (DTC)	13
12.	Diagnostic Procedure with Diagnostic Trouble Code (DTC)	14
13.	Diagnostics with Phenomenon	16