Diagnostics with Phenomenon

17. Diagnostics with Phenomenon

A: INSPECTION

Refer to "Diagnostics with Phenomenon" in the "HYBRID ELECTRIC VEHICLE (DIAGNOSTICS)" section. <Ref. to HEV(diag)-341, Diagnostics with Phenomenon.>

Diagnostics with Phenomenon

HYBRID ELECTRIC VEHICLE (DIAGNOSTICS)

HEV(diag)

		Page
1.	Basic Diagnostic Procedure	
2.	Check List for Interview	5
3.	General Description	8
4.	Electrical Component Location	9
5.	Control Module I/O Signal	10
6.	General Scan Tool	15
7.	Subaru Select Monitor	18
8.	Read Diagnostic Trouble Code (DTC)	24
9.	Clear Memory Mode	25
10.	All Readiness Diagnostic Code(s)	
11.	Inspection Mode	27
12.	Drive Cycle	32
13.	Read Current Data	
14.	Freeze Frame Data Display	63
15.	System Operation Check Mode	
16.	List of Diagnostic Trouble Code (DTC)	
17.	Fail-Safe Chart	87
18.	Diagnostic Procedure with Diagnostic Trouble Code (DTC)	94
19.	Diagnostics with Phenomenon	