69.Rear Wiring Harness RH

A: LOCATION

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
R1	20	★	C-1	B97	Bulkhead wiring harness
R2	20	★	C-2	B98	
R12	3	★	B-3		Front door switch RH
R13	8	★	B-3	D28	Rear door cord RH
R32	2	★	C-5		Rear accessory power supply socket
R43	8	★	C-4		Seat heater switch
R44	4	★	C-3		Seat heater RH
R82	19	Black	C-3	R81	Rear wiring harness LH
R98	24	★	C-1	i53	Instrument panel wiring harness
R124	2	Yellow	C-1	AB63	Front door cord RH
R284	8	★	C-5		AUX input terminal
R382	10	★	C-2	i195	Instrument panel wiring harness

★ : White or natural color

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
AB18	24	Yellow	D-3		Airbag CM
AB24	4	Yellow	C-3		Side airbag module RH
AB26	2	Black	B-3		Pretensioner RH
AB28	4	Yellow	B-3		Side airbag sensor RH
AB30	2	Yellow	B-3		Lap seat belt pretensioner RH
AB53	3	Dark gray	C-4	AB59	Occupant detection harness
AB59	3	★	C-3	AB53	Rear wiring harness
AB60	2	Yellow	C-3		Buckle switch
AB61	10	Black	C-3		Occupant detection control module

★ : White or natural color

WI-42299