
4. Electrical Component Location

A: LOCATION



- (1) Occupant detection control module
- (3) Airbag ON/OFF indicator light
- (4) Buckle switch (passenger's seat)

(2) Occupant detection sensor