67.Instrument Panel Wiring Harness LH

A: LOCATION

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
i2	10	*	D-1	R339	Rear wiring harness LH
i5	20	*	C-2		F/B
i10	40	*	B-3		Combination meter
i51	2	*	A-4		Sunload sensor
i55	2	*	B-4		Temperature and humidity sensor
i79	6	*	C-2		Illumination control switch
i84	35	Black	B-1		Body integrated unit
i101	28	*	C-1	D84	Front door cord LH
i102	24	*	D-1	R167	Rear wiring harness LH
i122	12	Black	A-4		MFD
i150	14	*	B-4		Push button ignition switch (with push button start)
i158	4	*	B-1		Side tweeter LH
i166	4	*	B-2		J/C
i167	4	*	B-2		
i171	31	*	C-1		Body integrated unit
i229	12	*	C-2	B551	Bulkhead wiring harness LH
i230	17	*	C-2	B552	
i231	20	*	C-2	B553	
i232	8	*	B-3		- J/C
i233	8	*	B-4		
i234	4	*	C-2		VDC OFF switch
i264	12	*	C-5		Pedestrian alert CM

