## **62.Bulkhead Wiring Harness (In Engine Compartment) LH A: LOCATION**

Connector				Connecting to			
No.	Pole	Color	Area	No.	Description		
B8	5	Light gray	B-4		Front wiper motor		
B10	4	Light gray	C-3		Pressure switch		
B15	2	Light gray	B-3		Front ABS wheel speed sensor LH		
B16	2	Gray	B-3		Brake fluid level switch		
B143	20	*	B-3		M/B		
B144	9	Brown	B-2				
B145	7	Brown	B-3				
B146	2	Black	D-3		Front washer motor		
B147	2	Gray	D-3		Rear washer motor		
B186	8	*	B-3		M/B		
B360	16	Gray	B-3	F109	Through joint connector		
B361	14	Gray	B-3	F108			
B396	2	Brown	D-2		Washer fluid level sensor		
B523	2	Light gray	C-3		Battery temperature sensor		
B564	21	Black	B-3		Relay holder		
B565	3	Black	B-3		Brake booster pressure sensor 1		
B571	2	*	B-3		M/B		
B600	3	Black	B-3		Brake booster pressure sensor 2		
★: White or natural color							

	Connector				Connecting to	
Ī	No.	Pole	Color	Area	No.	Description
	AB13	2	Yellow	C-1		Front sub sensor LH

