## 74.Rear Wiring Harness and Rear Gate Cord

## A: LOCATION

	Con	nector			Connecting to		
No.	Pole	Color	Area	No.	Description		
R16	3	*	C-4		Rear door switch RH		
R22	3	*	C-1		Rear door switch LH		
R26	6	Gray	C-4		Rear combination light RH		
R28	6	Gray	C-2		Rear combination light LH		
R29	3	Black	C-2		Rear vehicle height sensor		
R38	8	*	B-4	D34	Rear gate cord		
R39	14	Gray	B-4	D35			
R58	4	Gray	C-2		Fuel pump assembly		
R59	2	*	C-2		Fuel sub level sensor		
R72	2	Light gray	C-3		Rear ABS wheel speed sensor RH		
R73	2	Light gray	C-2		Rear ABS wheel speed sensor LH		
R80	8	*	B-2		Keyless entry CM		
R97	1	*	B-2		Antenna feeder cord		
R141	2	Light gray	C-2		Luggage room light		
R211	12	*	B-2		TPMS CM		
R296	5	*	B-2		Receiver (with push button start)		
R298	3	*	C-3		Keyless access interior antenna (center)		
R299	6	*	C-4		Keyless access exterior antenna (rear)		
R400	8	Gray	C-2		ELCM		
R454	8	*	C-4	R436	Inverter harness		
R455	4	*	C-4	R446	Electric oil pump inverter		
R456	4	*	C-4		J/C		
R457	4	*	C-4				
R459	14	*	C-2	R444	Inverter harness		
★: White o	r natural col	or					

No. D34	Dolo			Connecting to	
D34	Pole	Color	Area	No.	Description
207	8	*	B-4	R38	Rear wiring harness RH
D35	14	Gray	B-4	R39	
D39	2	*	B-3		High-mounted stop light
D43	4	*	A-4		Rear wiper motor
D44	2	*	A-4		License plate light RH
D46	4	*	A-4		Rear gate lock actuator & latch switch
D47	2	Brown	A-4		Rear gate opener button
D48	1	Black	B-2		Rear defogger
D77	4	*	A-4		Rear lock button & rear gate opener button
D80	8	*	A-4	D81	Rear gate cord
D81	8	*	A-4	D80	
D85	4	*	A-3		Rearview camera
D89	1	Black	B-4		Rear defogger
D137	2	*	A-4		License plate light LH

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
AB31	2	Black	B-2		Curtain airbag module LH
AB32	4	Yellow	C-1		Curtain airbag sensor LH
AB33	2	Black	B-4		Curtain airbag module RH
AB34	4	Yellow	C-3		Curtain airbag sensor RH
AB41	2	Yellow	C-2		Satellite safing sensor

