65.Rear Wiring Harness and Trunk Lid Cord

A: LOCATION

Connector					Connecting to			
No.	Pole	Color	Area	No.	Description			
R16	3	*	B-3		Rear door switch RH			
R19	2	*	B-3		High-mounted stop light			
R20	2	Black	B-4		Trunk room light			
R22	3	*	B-1		Rear door switch LH			
R24	12	*	B-5	R60	Trunk lid cord			
Doo	6	*	B-5		Rear combination light RH (4 door model)			
R26		Gray			Rear combination light RH (5 door model/XV model)			
R28	6	*	C-3		Rear combination light LH (4 door model)			
		Gray			Rear combination light LH (5 door model/XV model)			
R29	3	Black	C-3		Rear vehicle height sensor			
R58	4	*	C-4		Fuel pump assembly			
R59	2	*	C-3		Fuel sub level sensor			
R60	12	*	B-5	R24	Rear wiring harness RH			
R65	1	Black	B-2		Rear defogger			
R66	2	*	B-5		High-mounted stop light (rear spoiler)			
R72	2	Light gray	B-2		Rear ABS wheel speed sensor RH			
R73	2	Light gray	C-2		Rear ABS wheel speed sensor LH			
R76	2	*	C-4		License plate light LH			
R77	2	*	C-4		License plate light RH			
R80	8	*	C-3		Keyless entry CM			
R97	1	*	B-2		Antenna feeder cord			
R174	1	*	B-4		Rear defogger			
R186	3	*	C-4		Trunk lid lock actuator & switch			
R211	12	*	C-2		TPMS CM			
R221	12	*	C-3		TPMS & keyless entry CM			
R294	2	Brown	C-4		Trunk opener button			
R296	5	*	C-3		Receiver			
R297	3	*	B-3		Keyless access interior antenna (rear)			
R298	3	*	B-3		Keyless access interior antenna (center)			
R299	6	*	C-4		Keyless access exterior antenna (rear)			
R400	8	Gray	C-3		ELCM			
★: White o	★ : White or natural color							

Connector				Connecting to		
No.	Pole	Color	Area	No.	Description	
AB31	2	Black	B-2		Curtain airbag module LH	
AB32	4	Yellow	B-1		Curtain airbag sensor LH	
AB33	2	Black	B-4		Curtain airbag module RH	
AB34	4	Yellow	B-3		Curtain airbag sensor RH	
AB41	2	Yellow	C-3		Satellite safing sensor	

