60.Bulkhead Wiring Harness (In Compartment)

A: LOCATION

	Conn	ector			Connecting to
No.	Pole	Color	Area	No.	Description
B27	4	*	B-4		Blower Resistor (manual A/C)
B30	8	Black	C-5		Front door cord RH
B31	10	Gray	C-1	AB1	Airbag wiring harness
B32	8	*	B-2		Turn signal and hazard unit
B40	16	Black	C-1		Data link connector
B41	2	*	C-2		Power window circuit breaker
B52	24	*	D-1		F/B
B54	48	Black	B-2		TCM
B57	4	*	B-4		Power transistor (auto A/C)
B65	4	*	B-2		Stop light and brake switch
B68	14	*	B-3		Roll connector
B70	10	*	B-3		Combination switch
B71	20	*	B-3		Combination Switch
B72	6	*	C-3		Ignition switch
B77	6	*	C-4		Mode door actuator (auto A/C)
B83	8	*	B-4		J/C
B87	2	*	B-5		Blower motor
B88	2	Brown	C-4		Evaporator sensor (auto A/C)
D00	3	*	C-4		Evaporator sensor (manual A/C)
B89	2	Black	B-5		Blower diode
B90	20	*	B-5	R50	Roof cord
B92	20	*	D-1	R5	Rear wiring harness LH
B97	20	*	C-5	R1	Rear wiring harness RH
B99	20	*	D-1	R3	Rear wiring harness LH
B101	8	Black	C-1		Front door cord LH
B106	2	*	C-3		Clutch start switch
B107	2	Blue	C-3		Clutch switch
B116	8	*	C-4		AT select lever
B122	8	*	B-5		J/C
B123	2	Black	C-1	B124	Key lock
B124	2	Black	C-1	B123	Toy took
B134	34	*	C-4		
B135	35	*	C-5		- ECM
B136	35	*	C-5		<u> </u>
B137	31	*	C-5		
B150	24	*	C-1		Auto headlight beam leveler CM
B151	6	*	B-5	R430	Roof cord
B152	10	Gray	D-1		
B158	8	*	D-1		- F/B
B159	9	Brown	D-2		
B162	2	*	D-2		
B163	6	Black	B-5		Intake door actuator
B180	4	*	C-2		Remote engine start CM (without push button start)
	8	*	C-2	_	Remote engine start CM (with push button start)
B181	2	*	C-2	B182	Bulkhead wiring harness
B182	2	*	C-2	B181	

Bulkhead Wiring Harness (In Compartment)

WIRING SYSTEM

Connector				Connecting to		
No.	Pole	Color	Area	No.	Description	
B220	44	*	B-5		Delevi helden	
B225	44	*	C-2		Relay holder	
B231	5	*	B-3		Steering angle sensor	
B235	6	*	C-4		Air mix door actuator LH (with left/right independent air conditioner)	
B239	6	*	B-4		Air mix door actuator (without left/right independent air conditioner)	
D239					Air mix door actuator RH (with left/right independent air conditioner)	
B280	34	*	C-1		Dody intograted unit	
B281	35	*	C-2		Body integrated unit	
B315	6	Black	C-4		Accelerator pedal position sensor	
B358	2	*	C-4		AT select lever illumination	
B367	8	*	C-2		Impact sensor	
B386	4	*	B-5		Blower motor relay	
B415	7	Black	C-3		Immobilizer antenna	
B422	5	*	B-3		ID code box	
B424	7	Black	C-3		Steering lock CM	
B426	4	Black	C-2		Accessory relay	
B475	4	*	D-1		Wiper relay unit	
B550	20	*	D-2		Fuse holder	
B551	12	*	C-2	i229		
B552	17	*	C-2	i230	Instrument panel wiring harness LH	
B553	20	*	D-2	i231		
B555	2	*	C-3		Key warning switch	
B556	2	*	C-4	AB65	Airbag wiring harness	
B557	2	*	C-3		Key lock solenoid	
B558	7	*	B-3		Combination switch	
B559	5	*	B-3		Security CM	
B572	18	*	C-2			
B573	28	*	C-2		Keyless access CM	
B574	30	*	C-2		7	
B575	22	*	C-1	B576		
B576	22	*	C-1	B575	Bulkhead wiring harness	
B577	10	*	C-1	B578		
B578	10	*	C-1	B577		
B579	2	*	C-4		Keyless access interior antenna (front)	
B583	12	*	B-5	i237	Instrument panel wiring harness RH	
B584	20	*	B-5	i238		
	r natural col	1			-	

Connector					Connecting to		
No.	Pole	Color	Area	No.	Description		
AB1	10	Gray	C-1	B31	Bulkhead wiring harness		
AB2	4	Yellow	B-3	AB7	Driver's airbag module		
AB6	30	Yellow	C-4		Airbag CM		
AB9	4	Yellow	C-4		Passenger's airbag module		
AB65	2	*	C-4	B556	Bulkhead wiring harness		
AB66	2	Black	D-2		Driver's knee airbag module		
★: White o	r natural col	or		•	•		

