SECTION INDEX	
A/C /HEATER	221
A/C REFRIGERANT CAPACITIES	221
ABS/BRAKES	
AIR BAG SYSTEM	
AIR CLEANER	
BACK WINDOW	
CENTER CONSOLE	
CLEAR COAT IDENTIFICATION	
CONVERTIBLE TOP	
COOLING	
COWL & DASH	
CRUISE CONTROL SYSTEM	
ELECTRICAL	
EMISSION SYSTEM	
ENGINE MOUNTS	
ENGINE/TRANS	225
EXHAUST	226
FRONT BUMPER	220
FRONT DOOR	
FRONT FENDER	222
FRONT INNER STRUCTURE	222
FRONT LAMPS	220
FRONT STEERING LINKAGE/GEAR	224
FRONT SUSPENSION	223
FUEL TANK	
HARDTOP	
HOOD	
INFORMATION LABELS	
INSTRUMENT PANEL	
LUGGAGE LID	
PAINT CODE LOCATION	
QUARTER PANEL	
REAR BODY	
REAR BUMPER	
REAR DRIVE AXLE	
REAR CHARENCOM	
REAR SUSPENSIONROCKER/PILLARS/FLOOR	
SEAT	
SEAT BELTS SPECIAL CAUTIONS	
STEERING PUMP	
STEERING WHEEL/COLUMN	
UNDERHOOD DIMENSIONS	
WHEEL	
WINDSHIELD	
WINDOI IILLD	220

SPECIAL CAUTIONS

AIR BAGS

Refer to Procedure Explanation 29 for Supplemental Restraint/Air Bag Special Cautions.

SUSPENSION

Manufacturer advises that some new fasteners must be used whenever old fasteners are loosened or removed.

PAINT CODE LOCATION

CLEAR COAT IDENTIFICATION

All metallic colors are clear coat


INFORMATION LABELS

Illustration Located in Next Column

16 10 035-02541

abel, Emission 1990-91 w/Calif Emission w/o Calif Emission 1992 NA01-69-036D NA04-69-036C NA75-69-036 NB11-69-036 N.A. N.A. NB38-69-036 N.A. NA01-57-K91 KA78-57-K91 NA01-69-044 NA75-69-044 NB38-69-044 NA75-61-439 9 Label, Vacuum Diaphragm Canada abel, Spare Tire Label, Spare Tire
English
French
Label, Fuel Warning
Label, Unleaded Fuel
Label, Battery
Label, Battery BF68-69-073B


FRONT BUMPER



90-96 UB39-50-795 97 N.A. NA01-56-145 R NA01-50-2A0B L NA01-50-1A07 R NA01-50-1C0 R/L NA01-50-0G9 R/L NA01-50-0G9 R/L BF82-50-233 R/L NA01-50-160 R/L B92-50-922 NA01-50-070 NA01-50-114 6 Fastener, Lwr Seal (8) 9 Plate, Outer Support Seal, Cover Guide, Air w/ABS Cover, Air Guide (3) Fastener (2) Cover, Under Fractener (2) Cover, Under Fracket, Frame Emplem 1990-93 Light Gray Dark Gray 1994-97 NA23-50-420A NA01-50-420B NA01-50-101A BF67-50-033 NA01-50-180A FB01-50-144 R/L NA01-50-18X

FRONT LAMPS

HEADLAMP



	Ring, Retaining		NA01-51-033A
3	Ring, Mounting¶	I I	NA01-51-032 NA01-51-034
4	Spring, Adjust¶		NA01-51-034
	Screw, Adjust¶ (2/Side)	R/L	
٠	¶Included w/Lamp As		14/101 31 007
6	Sealed Beam	R/L	0000-11-6024-HL
7		Ř	
	,	Ë	NA01-50-751
	Screw, Headlamp (4/Side)	R/L	
8	Lid, Lamp	R	NA01-51-SH1B
	, ,	L	NA01-51-SH2B
			9074-00-512
			BS34-51-S25A
9	Hinge Assy		NA01-51-SC0B
			NA01-51-SD0B
10	Housing, Hinge¶		NA01-51-SC5B
	B		NA01-51-SD5B
11	Bracket, Hinge¶		NA01-51-SC1A
10	Con Hinnell	L D/L	
12	Cap, Hinge¶ ¶Included w/Hinge A		KA01-51-SD6
10			NAO1 E1 CAE
	Rod, Retractable		NA01-51-SA5 NA01-51-SAX
14	Motor Assy	ח	NA01-51-SBX
15	Boot, Motor¶	D/I	NA01-51-669
16	Bolt, Motor¶		FB01-51-665
10	¶Included w/Motor As		1 001 01 000
17	Protector, Lamp Front		NA01-51-SJ2A
	Protector, Lamp	''L	
19	Protector, Lamp Rear	Ř	
	. rotottor, zamp ricai	Ë	
		_	

PARK/SIGNAL LAMP

Illustration Located in Next Column


1 Lamp Assy

220


6 Label, VIN

Labor Times Shown are for Replacement with New OEM Undamaged Parts on New Undamaged Vehicles.
Comments or suggestions? Need assistance? Call 1-800-854-7030 or 858-578-6550. Ext. 8220. Fax 1-888-256-7969 or 858-549-0629.

5 Seal, Upper




madpl1_g01_




222

Labor Times Shown are for Replacement with New OEM Undamaged Parts on New Undamaged Vehicles.

Comments or suggestions? Need assistance? Call 1-800-854-7030 or 858-578-6550. Ext. 8220. Fax 1-888-256-7969 or 858-549-0629.




madpl1_g01_




224

Labor Times Shown are for Replacement with New OEM Undamaged Parts on New Undamaged Vehicles.

Comments or suggestions? Need assistance? Call 1-800-854-7030 or 858-578-6550. Ext. 8220. Fax 1-888-256-7969 or 858-549-0629.




madpl1_g01_




226

Labor Times Shown are for Replacement with New OEM Undamaged Parts on New Undamaged Vehicles.

Comments or suggestions? Need assistance? Call 1-800-854-7030 or 858-578-6550. Ext. 8220. Fax 1-888-256-7969 or 858-549-0629.



madpl1_g01_




228

Labor Times Shown are for Replacement with New OEM Undamaged Parts on New Undamaged Vehicles.

Comments or suggestions? Need assistance? Call 1-800-854-7030 or 858-578-6550. Ext. 8220. Fax 1-888-256-7969 or 858-549-0629.

MAZDA MIATA 1990-97					
Artvin Red	R NA52-69-120C-18 L NA52-69-180C-18 R NA52-69-120C-PZ	L NB87-68-450D-80 w/o CD Player			
Brilliant Black	R NA52-69-120C-PZ L NA52-69-180C-PZ	Black R NB85-68-420-00 L NB85-68-450D-00			
Chaste White	R NA52-69-120C-PT L NA52-69-180C-PT	Tan R NB85-68-420-80 L NB85-68-450-80			
Classic Red	R NA52-69-120C-SU L NA52-69-180C-SU	¶Order by Application			
Laguna Blue	R NΔ52-69-120C-6W	2 W/Strip, Front Inner Belt¶ R/L NA02-58-821 3 W/Strip, Rear Inner Belt¶ R/L NA01-58-821A ¶Included w/Trim Panel Assy	3-/////-2		
Montego Blue	L NA52-69-180C-6W R NA52-69-120C-M8 L NA52-69-180C-M8 R NA52-69-120C-HU	4 Armrest/Grip 1990-93			
Neo Green	L NA52-69-180G-HU	Black R BF70-69-370C-00 L BF70-69-390C-00			
Satellite Blue	R NA52-69-120C-A5 L NA52-69-180C-A5	Tan R BF70-69-370C-88 L BF70-69-390C-88			
INTE	RIOR TRIM	1994-95 R N026-69-070-00 L N026-69-D90-00			
		1996-97 Black R BF70-69-370C-00			
		L BF70-69-390C-00 Tan R BF70-69-370C-88	7		
_	3	L BF70-69-390C-88 5 Grille, Speaker 1990-93	35-1173		
2	1	Black R NA01-68-4H0-00 L NA01-68-4W0-00			
		Tan R NA01-68-4H0-88 L NA01-68-4W0-88	₽		
FY	35.1172	1994-96¶ R N020-68-4E6 L N020-68-4V6	Mazda (Tint) 90-96 R NB39-58-661A L NA01-59-661 97 R NB39-58-661A		
		1997 Man Windows R/L A004-68-5H0-00	L NB39-59-661A		
	4	Pwr Windows w/CD Player R/L BR72-68-3S0A-60	3 W/Strip, Vent Glass R NA01-58-651B L NA01-59-651B 4 Channel, Division R NA01-58-604B		
	The state of the s	w/o CD Player R/L A004-68-5H0-00 ¶Order by Application	L NA01-59-604B 5 Guide, Glass R NA01-58-603D		
		Speaker, Radio R/L 0000-81-084A-01 1990-93 R/L 0000-81-084A-01 1994-96 R/L 0000-81-7501	6 Regulator, Window		
(1994-96 R/L 0000-81-7501 1997 R/L NB42-66-960	Manual R NA01-58-560J L NA01-59-560J		
4 Paral Assa Trins		HARDWARE	Power R NA02-58-560L I NA02-59-560I		
1 Panel Assy, Trim 1990-93 Man Windows			Motor, Regulator-Serviced w/Pwr Window Regulator 7 Handle, Regulator 90-93 R/L B092-58-580-00 94-97 R/L S084-58-580A-00		
Black	R NA01-68-420C-00	5	94-97 R/L S084-58-580A-00 8 Escutcheon, Handle R/L B001-58-582A-00		
Black/Tan	R NA01-68-420C-00 L NA01-68-450C-00 R NA01-68-420C-88 L NA01-68-450C-88	4—6	CONVERTIBLE TOP		
Pwr Windows Black	R N019-68-420A-00	6 8			
Black/Tan	L N019-68-450A-00 R N019-68-420A-88	l ///- a ///—11	1		
1994	L N019-68-450A-88	10	2		
Pwr Windows w/Sensory Sound Plastic Kickplate		9			
Black	R N031-68-420C-00 L N031-68-450B-00				
Tan	R N031-68-420B-88 L N031-68-450B-88				
Stainless Steel Kickplate Black)				
Tan	R N021-68-420C-00 L N021-68-450C-00 R N021-68-420C-00	7 0	035-02754		
w/o Sensory Sound Plastic Kickplate	L N021-68-450E-88	2 035-02753			
Plastic Kickplate Black	R N030-68-420D-00	1 Handle, Inside 90-96 R NA01-58-330A-00	1 Cover Assy, Top Outer Black		
Tan	L N030-68-450D-00 R N030-68-420C-88	L NA01-59-330C-00 97 R NA01-58-330C-00	Tan NA02-R1-210F 2 Window, Back¶		
Stainless Steel Kickplate Black	L N030-68-450B-88	L NA01-59-330C-00 2 Cover, Inside Handle R/L NA01-58-303-00	Black NAY1-R1-240G Blue N0Y5-R1-240A		
Tan	R N026-68-420B-00 L N026-68-450C-00 R N026-68-420B-88	3 Latch, Door R NA01-58-310B	Tan NAY2-R1-240D ¶Included w/Ton Outer Cover Assy		
Man Windows	R N026-68-420B-88 L N026-68-450B-88	Striker, Door-See Quarter Panel Section 4 Cylinder Kit, Lock 90-94 R NA01-76-210E	Cloth, Repair Top Black NAY1-R1-211		
w/Sensory Sound Black	R N029-68-420B-00	L N001-76-220E 95 R N001-76-210F	Blue N0Y5-R1-211 Tan NAY2-R1-211		
Tan	L N029-68-450B-00 R N029-68-420B-88 L N029-68-450B-88	L N001-76-220E 96-97 R N001-76-210E			
w/o Sensory Sound		L N001-76-220E 5 Handle, Outside R NA01-58-410D L NA01-59-410D	Illustration Located in Next Column		
Black	R N028-68-420C-00 L N028-68-450C-00 R N028-68-420B-88	6 Hinge, Upper R B156-59-240 L B156-59-240 7 Hinge, Lower R B156-58-240 L B156-59-240	3 Cover, Top Inner NA01-R1-96XD		
Tan 1995-96¶	L N028-68-450B-88	7 Hinge, Lower R B 156-58-240	3 Cover, Top Inner NA01-R1-96XD 4 Frame, Cover NA01-R1-100E 5 Weatherstrip, Header NA01-R1-711B 6 Handle, Top NA01-R1-331		
Man Windows w/Sensory Sound	R N036-68-420A-00	8 Shim, Hinge (2/Side) R/L B092-58-201A 9 Check, Door R/L NA01-58-270B 10 Weatherstrip, Door R NA01-58-760J	7 Latch, Top R NA01-R1-331 L NA01-R1-320L		
w/o Sensory Sound	R N036-68-420A-00 L N036-68-450A-00 R N028-68-420C-00	L NA01-59-760J	8 Striker, Latch R NA01-R1-361H		
Pwr Windows	L N028-68-450C-00	11 Welt, Seam R/L NA01-68-911-00	L NA01-R1-371H 9 Hook, Upper Pin R/L NA01-R1-38XB 10 Base, Pin Hook R/L FB67-R1-91YC		
w/Sensory Sound	R N035-68-420A-00 L N035-68-450A-00 R N034-68-420-00	GLASS & PARTS	11 Plate Set, Front NA01-R1-291A 12 Plate Set, Rear Center NA01-R1-581D		
w/o Sensory Sound	R N034-68-420-00 L N034-68-450-00	Westerfan Land IV N. 10 I	13 Plate Set, Rear Outer R NA01-R1-582B L NA01-R1-592B		
1997 Man Windows	D ND96 69 490 00	Illustration Located in Next Column	15 W/Strip, Frame Front R NA01-R1-201		
w/CD Player w/o CD Player	R NB86-68-420-00 L NB86-68-450-00 R NB84-68-420-00	1 Glass, Front Door Mazda (Tint) 90-96 R NA01-58-510	L NA01-R1-471 16 W/Strip, Frame Center R NA01-R1-462		
Pwr Windows	L NB84-68-450-00	L NB39-58-510 97 R NB39-58-510	L NA01-R1-472 17 W/Strip, Frame Rear R NA01-R1-463 L NA01-R1-473		
w/CD Player Black	R NB87-68-420-00	L NB39-59-510 2 Glass, Vent	Retainer, Weatherstrip 18 Front R NA01-R1-4/13		
Tan	L NB87-68-450-00 R NB87-68-420D-80	. ,	n indit nimothi-4110		
1401					

madpl1_g01_




230

Labor Times Shown are for Replacement with New OEM Undamaged Parts on New Undamaged Vehicles.

Comments or suggestions? Need assistance? Call 1-800-854-7030 or 858-578-6550. Ext. 8220. Fax 1-888-256-7969 or 858-549-0629.

Door, Fuel




madpl1_g01_

Procedure Explanation Pages Must Be Used with the Above Text for an Accurate Damage Report.

Comments or suggestions? Need assistance? Call 1-800-854-7030 or 858-578-6550. Ext. 8220. Fax 1-888-256-7969 or 858-549-0629.

231



232

Labor Times Shown are for Replacement with New OEM Undamaged Parts on New Undamaged Vehicles.

Comments or suggestions? Need assistance? Call 1-800-854-7030 or 858-578-6550. Ext. 8220. Fax 1-888-256-7969 or 858-549-0629.