


Digital Signal Processing for Music

Part 18: Sample Rate Conversion (SRC)

alexander lerch




sample rate conversion

introduction

sample rate conversion

WP:" changing the sampling rate of a discrete signal to obtain a new discrete representation of the underlying continuous signal."



sample rate conversion

introduction

sample rate conversion

WP:" changing the sampling rate of a discrete signal to obtain a new discrete representation of the underlying continuous signal."

typical applications

- audio file/media conversion
- word clock synchronization (multiple devices)
- DJing/scratching

sample rate conversion

introduction

● terminology

- *synchronous*
 - clock rates are coupled
 - resampling factor stays constant
- *asynchronous*
 - clock rates are independent
 - resampling factor may change

● ideal result

- spectrum in the used band unchanged
- spectral periodicity (determined by sample rate) changed

sample rate conversion

introduction

● terminology

- *synchronous*
 - clock rates are coupled
 - resampling factor stays constant
- *asynchronous*
 - clock rates are independent
 - resampling factor may change

● ideal result

- spectrum in the used band unchanged
- spectral periodicity (determined by sample rate) changed

sample rate conversion

upsampling by inserting zeros

- task: **upsample by integer factor L**

- 1 insert $L - 1$ zeros between all samples
- 2 apply anti-imaging filter

sample rate conversion

upsampling by inserting zeros


- task: **upsample by integer factor L**
 - ① insert $L - 1$ zeros between all samples
 - ② apply anti-imaging filter

sample rate conversion

upsampling by inserting zeros

- task: **upsample by integer factor L**

- 1 insert $L - 1$ zeros between all samples
- 2 apply anti-imaging filter




sample rate conversion

upsampling by inserting zeros

- task: **upsample by integer factor L**

- 1 insert $L - 1$ zeros between all samples
- 2 apply anti-imaging filter



sample rate conversion

downsampling by removing samples

- task: **downsample by integer factor M**

- 1 apply anti-aliasing filter
- 2 take every M th sample

sample rate conversion


downsampling by removing samples

- task: **downsample by integer factor M**
 - apply anti-aliasing filter
 - take every M th sample

sample rate conversion

downsampling by removing samples

- task: **downsample by integer factor M**
 - apply anti-aliasing filter
 - take every M th sample










sample rate conversion

downsampling by removing samples

- task: **downsample by integer factor M**

- apply anti-aliasing filter
- take every M th sample



sample rate conversion

resampling by rational factor

- task: **convert sample rate to any other (coupled) sample rate**

- convert sample rate ratio to integer factors
e.g.: $48/44.1 \Rightarrow L = 160, M = 147$
- insert zeros
- apply anti-imaging filter
- apply anti-aliasing filter
- remove samples

sample rate conversion

resampling by rational factor

- task: **convert sample rate to any other (coupled) sample rate**
 - ① convert sample rate ratio to integer factors
e.g.: $48/44.1 \Rightarrow L = 160, M = 147$
 - ② insert zeros
 - ③ apply anti-imaging filter
 - ④ apply anti-aliasing filter
 - ⑤ remove samples

sample rate conversion


resampling by rational factor

- task: **convert sample rate to any other (coupled) sample rate**
 - ① convert sample rate ratio to integer factors
e.g.: $48/44.1 \Rightarrow L = 160, M = 147$
 - ② insert zeros
 - ③ apply anti-imaging filter
 - ④ apply anti-aliasing filter
 - ⑤ remove samples

sample rate conversion

resampling by rational factor


- task: **convert sample rate to any other (coupled) sample rate**
 - convert sample rate ratio to integer factors
e.g.: $48/44.1 \Rightarrow L = 160, M = 147$
 - insert zeros
 - apply anti-imaging filter
 - apply anti-aliasing filter
 - remove samples



sample rate conversion

sinc interpolation 1/2

- perfect reconstruction of the sampled spectrum is possible with ideal filter
- ⇒ resampling should be possible by time domain convolution with sinc



$$x(i - \alpha) = \sum_{m=-\infty}^{\infty} x(m) \frac{\Omega_C}{\pi} \frac{\sin(\Omega_C(i - \alpha - m))}{\Omega_C(i - \alpha - m)}$$

Ω_C is the cutoff frequency of the ideal lowpass


sample rate conversion

sinc interpolation 1/2

- perfect reconstruction of the sampled spectrum is possible with ideal filter
- ⇒ resampling should be possible by time domain convolution with sinc

$$x(i - \alpha) = \sum_{m=-\infty}^{\infty} x(m) \frac{\Omega_C}{\pi} \frac{\sin(\Omega_C(i - \alpha - m))}{\Omega_C(i - \alpha - m)}$$

Ω_C is the cutoff frequency of the ideal lowpass



sample rate conversion

sinc interpolation 2/2

- practical implementation: **windowed sinc**

sample rate conversion

polynomial interpolation

● interpolation methods

- can be interpreted as filters with time-variant filter coefficients
- not based on traditional filter design methods

● polynomial interpolation

$$f(t) = \sum_{k=0}^{\mathcal{O}} x_k p_k(t)$$

$$p_k(t) = \prod_{j=0}^{\mathcal{O}} \frac{t - t_j}{t_k - t_j}$$

sample rate conversion

polynomial interpolation

- **interpolation methods**

- can be interpreted as filters with time-variant filter coefficients
- not based on traditional filter design methods

- polynomial interpolation

$$f(t) = \sum_{k=0}^{\mathcal{O}} x_k p_k(t)$$

$$p_k(t) = \prod_{j=0}^{\mathcal{O}} \frac{t - t_j}{t_k - t_j}$$

sample rate conversion

polynomial interpolation example

$$x(t) = \frac{1}{t}$$

$$\text{nodes: } t = [2, 4, 5]$$

$$p_0(t) = \frac{(t-4)(t-5)}{(2-4)(2-5)} = \frac{(t-4)(t-5)}{6}$$

$$p_1(t) = \frac{(t-2)(t-5)}{(4-2)(4-5)} = -\frac{(t-2)(t-5)}{2}$$

$$p_2(t) = \frac{(t-2)(t-4)}{(5-2)(5-4)} = \frac{(t-2)(t-4)}{3}$$

$$f(t) = \sum_{k=0}^{\infty} x_k p_k(t)$$

$$\begin{aligned}\Rightarrow f(t) &= p_0 \frac{1}{2} + p_1 \frac{1}{4} + p_2 \frac{1}{5} \\ &= 0.025t^2 - 0.275t + 0.95.\end{aligned}$$

sample rate conversion

polynomial interpolation example

$$x(t) = \frac{1}{t}$$

nodes: $t = [2, 4, 5]$

$$p_0(t) = \frac{(t-4)(t-5)}{(2-4)(2-5)} = \frac{(t-4)(t-5)}{6}$$

$$p_1(t) = \frac{(t-2)(t-5)}{(4-2)(4-5)} = -\frac{(t-2)(t-5)}{2}$$

$$p_2(t) = \frac{(t-2)(t-4)}{(5-2)(5-4)} = \frac{(t-2)(t-4)}{3}$$

$$f(t) = \sum_{k=0}^{\infty} x_k p_k(t)$$

$$\begin{aligned}\Rightarrow f(t) &= p_0 \frac{1}{2} + p_1 \frac{1}{4} + p_2 \frac{1}{5} \\ &= 0.025t^2 - 0.275t + 0.95.\end{aligned}$$

sample rate conversion

polynomial interpolation example

$$x(t) = \frac{1}{t}$$

nodes: $t = [2, 4, 5]$

$$p_0(t) = \frac{(t-4)(t-5)}{(2-4)(2-5)} = \frac{(t-4)(t-5)}{6}$$

$$p_1(t) = \frac{(t-2)(t-5)}{(4-2)(4-5)} = -\frac{(t-2)(t-5)}{2}$$

$$p_2(t) = \frac{(t-2)(t-4)}{(5-2)(5-4)} = \frac{(t-2)(t-4)}{3}$$

$$f(t) = \sum_{k=0}^{\mathcal{O}} x_k p_k(t)$$

$$\begin{aligned}\Rightarrow f(t) &= p_0 \frac{1}{2} + p_1 \frac{1}{4} + p_2 \frac{1}{5} \\ &= 0.025t^2 - 0.275t + 0.95.\end{aligned}$$

sample rate conversion

polynomial interpolation example

$$x(t) = \frac{1}{t}$$

nodes: $t = [2, 4, 5]$

$$p_0(t) = \frac{(t-4)(t-5)}{(2-4)(2-5)} = \frac{(t-4)(t-5)}{6}$$

$$p_1(t) = \frac{(t-2)(t-5)}{(4-2)(4-5)} = -\frac{(t-2)(t-5)}{2}$$


$$p_2(t) = \frac{(t-2)(t-4)}{(5-2)(5-4)} = \frac{(t-2)(t-4)}{3}$$

$$f(t) = \sum_{k=0}^{\mathcal{O}} x_k p_k(t)$$

$$\begin{aligned}\Rightarrow f(t) &= p_0 \frac{1}{2} + p_1 \frac{1}{4} + p_2 \frac{1}{5} \\ &= 0.025t^2 - 0.275t + 0.95.\end{aligned}$$

sample rate conversion

polynomial interpolation example



sample rate conversion

special case: linear interpolation

- 1st order → 2 points

$$x(t) = \frac{1}{t}$$

nodes: $t = [2, 4]$

$$p_0(t) = \frac{(t - 4)}{(2 - 4)} = \frac{(4 - t)}{2}$$

$$p_1(t) = \frac{(t - 2)}{(4 - 2)} = \frac{(t - 2)}{2}$$

$$f(t) = \sum_{k=0}^{\infty} x_k p_k(t)$$

$$\begin{aligned}\Rightarrow f(t) &= p_0 \frac{1}{2} + p_1 \frac{1}{4} \\ &= -\frac{1}{8}t + \frac{3}{4}.\end{aligned}$$

sample rate conversion

special case: linear interpolation

- 1st order → 2 points

$$x(t) = \frac{1}{t}$$

nodes: $t = [2, 4]$

$$p_0(t) = \frac{(t - 4)}{(2 - 4)} = \frac{(4 - t)}{2}$$

$$p_1(t) = \frac{(t - 2)}{(4 - 2)} = \frac{(t - 2)}{2}$$

$$f(t) = \sum_{k=0}^{\infty} x_k p_k(t)$$

$$\begin{aligned}\Rightarrow f(t) &= p_0 \frac{1}{2} + p_1 \frac{1}{4} \\ &= -\frac{1}{8}t + \frac{3}{4}.\end{aligned}$$

sample rate conversion

special case: linear interpolation

- 1st order → 2 points

$$x(t) = \frac{1}{t}$$

nodes: $t = [2, 4]$

$$p_0(t) = \frac{(t - 4)}{(2 - 4)} = \frac{(4 - t)}{2}$$

$$p_1(t) = \frac{(t - 2)}{(4 - 2)} = \frac{(t - 2)}{2}$$

$$f(t) = \sum_{k=0}^{\sigma} x_k p_k(t)$$

$$\begin{aligned}\Rightarrow f(t) &= p_0 \frac{1}{2} + p_1 \frac{1}{4} \\ &= -\frac{1}{8}t + \frac{3}{4}.\end{aligned}$$

sample rate conversion

special case: linear interpolation

- 1st order → 2 points

$$x(t) = \frac{1}{t}$$

nodes: $t = [2, 4]$

$$p_0(t) = \frac{(t - 4)}{(2 - 4)} = \frac{(4 - t)}{2}$$


$$p_1(t) = \frac{(t - 2)}{(4 - 2)} = \frac{(t - 2)}{2}$$

$$f(t) = \sum_{k=0}^{\infty} x_k p_k(t)$$

$$\begin{aligned}\Rightarrow f(t) &= p_0 \frac{1}{2} + p_1 \frac{1}{4} \\ &= -\frac{1}{8}t + \frac{3}{4}.\end{aligned}$$



sample rate conversion

special case: linear interpolation



$$\hat{x} = x_l \cdot (1 - frac) + x_r \cdot frac$$

sample rate conversion interpolation comparison



sample rate conversion

downsampling audio examples

| | orig (48 kHz) | ds (6 kHz, w/o filt) | ds (6 kHz, w/ filt) |
|----------|---------------|----------------------|---------------------|
| sax | | | |
| big band | | | |

sample rate conversion

summary

- resampling: estimate different sample points of underlying continuous signal
- as with sampling, proper filtering has to take place
- some interpolation approaches have filter “built-in”
- perfect reconstruction impossible (infinite sinc), however, perceptually artifact-free resampling is possible
 - main issue: filter cut-off and steepness vs. aliasing