

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
(A)				BEARING, BALL, 5206	C9	43	19
ALTERNATOR ASSY.	B9	18	5	BEARING, BALL, 6303	C9	43	20
ALTERNATOR ASSY., PULSE	B8	16	8	BEARING, HEAD PIPE LOWER	E8	69	19
ARM ASSY., SHOCK	G5	110	13	BEARING, HEAD PIPE UPPER	E8	69	18
	G5	110	14	BEARING, NEEDLE, 19 16	F5	86	30
ARM COMP., CAM CHAIN TENSIONER	B5	11	15	BEARING, NEEDLE, 20MM	C6	37	26
ARM COMP., GEARSHIFT	G1	102	3	BEARING, NEEDLE, 30X35X17	B8	17	15
ARM COMP., NEUTRAL STOPPER	C7	38	10	BEARING, NEEDLE, 35X42X30	B7	15	18
ARM COMP., SHIFT DRUM STOPPER	C7	38	11	BEARING, RADIAL BALL, 16003	B7	15	17
ARM, RR BRAKE	F2	80	9	BEARING, RADIAL BALL, 16012C3	F4	85	27
ARM, VALVE ROCKER	B4	9	6	BEARING, RADIAL BALL, 5206	C9	43	21
AXLE, FR. WHEEL	F1	78	3	BEARING, RADIAL BALL, 57 34C3	F4	85	28
AXLE, RR. WHEEL	F2	80	1	BEARING, RADIAL BALL, 6302UU	F1	79	18
				BEARING, RADIAL BALL, 6303U	F3	83	10
				BEARING, RADIAL BALL, 6304	C2	28	32
				BEARING, RADIAL BALL, 6305	C6	37	29
					F4	85	29
(B)					C7	39	25
BAG, TOOL	H1	126	2	BEARING, 16005	G4	109	25
BAG, TOOL, 200MM	H1	126	2	BEARING, 30203J	C1	26	1
BALL, STEEL, #5	E11	75	68	BLOCK SET, CYLINDER	C1	26	1
BAND B1, WIRE	E3	59	5	BODY, KEY	F8	92	13
	G9	118	12	BOLT ASSY., FR. SHOCK	E10	73	35
BAND, INSULATOR	B2	4	9	BOLT 2, STUD, 6X32	B2	5	20
	B3	7	9		B3	7	16
BAND, L. EX. PIPE	F12	100	8	BOLT-FLANGE, 6X12	G10	121	31
BAND, L. MUFFLER	F12	100	10	BOLT-WASHER, 6X25	B8	17	17
BAND, R. EX.	F12	100	7		G10	121	32
BAND, R. MUFFLER	F12	100	9	BOLT, BATTERY SETTING	F9	95	3
BAND, SELF LOCK	E7	67	17	BOLT, CAM CHAIN GUIDE A	B5	11	7
BAR ASSY., SIDE STAND	G3	106	4	BOLT, CAP, 6X20	F6	89	20
BAR COMP., L. FOOTPEG	G2	104	12	BOLT, CONNECTING ROD	C4	33	7
BAR COMP., R. FOOTPEG	G2	104	3	BOLT, DRAIN PLUG, 12MM	B12	24	20
BAR, L. PILLION FOOTPEG	G2	105	17	BOLT, FLANGE SOCKET, 6X25	H4	132	13
BAR, R. PILLION STEP	G2	104	16	BOLT, FLANGE SOCKET, 8X85	C9	43	14
BAR, SEAT LOCK	F7	90	5	BOLT, FLANGE, 10X190	G5	111	23
BAR, STEP HOLDER	G2	105	20	BOLT, FLANGE, 10X20	G2	105	30
BASE COMP., CONTACT	E7	67	4	BOLT, FLANGE, 10X220	G12	125	24
BASE, AIR CLEANER	C11	46	24	BOLT, FLANGE, 10X345	G12	125	23
BASE, HEAD COVER	B1	2	3	BOLT, FLANGE, 10X38	F4	85	22
BASE, TURN SIGNAL	G7	114	2	BOLT, FLANGE, 10X48	G5	111	25
BATTERY	F9	95	1	BOLT, FLANGE, 10X50	E12	77	26
BATTERY ASSY.	F9	95	1	BOLT, FLANGE, 10X53	G5	111	22
BEARING A, CONNECTING ROD	C4	33	8	BOLT, FLANGE, 10X62	G5	111	21
BEARING A, CRANKSHAFT	C4	33	10	BOLT, FLANGE, 10X65	G12	125	22
BEARING B, CONNECTING ROD	C4	33	8	BOLT, FLANGE, 10X82	G5	111	24
BEARING B, CRANKSHAFT	C4	33	10	BOLT, FLANGE, 12X40	B8	17	12
BEARING C, CONNECTING ROD	C4	33	8		B9	19	10
BEARING C, CRANKSHAFT	C4	33	10	BOLT, FLANGE, 12X45	B8	17	12
BEARING D, CONNECTING ROD	C4	33	8		B9	19	10
BEARING D, CRANKSHAFT	C4	33	10	BOLT, FLANGE, 6X10	E8	69	21
BEARING E, CONNECTING ROD	C4	33	8		E12	77	28
BEARING E, CRANKSHAFT	C4	33	10		F8	93	28
BEARING, BALL, 16005	C7	39	25		F11	99	33
					G6	113	19

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
BOLT, FLANGE, 6X10	G9	119	26	BOLT, FLANGE, 6X60	B10	21	23
	G11	122	40		C1	27	25
	G11	122	42	BOLT, FLANGE, 6X70	B10	21	24
	G12	125	34		B12	25	25
BOLT, FLANGE, 6X100	C1	27	27	BOLT, FLANGE, 6X90	C1	27	26
BOLT, FLANGE, 6X12	B2	5	25	BOLT, FLANGE, 8X14	B8	17	20
	B9	19	12	BOLT, FLANGE, 8X15	F7	91	15
	C1	27	18	BOLT, FLANGE, 8X16	E1	54	12
	C2	28	31		G2	105	29
BOLT, FLANGE, 6X14	G10	121	31		G12	125	33
	B6	12	25	BOLT, FLANGE, 8X19	E7	67	12
	C8	41	29	BOLT, FLANGE, 8X22	F6	89	25
	E9	70	2	BOLT, FLANGE, 8X25	F2	80	12
BOLT, FLANGE, 6X16	B6	12	24		F7	91	22
	C6	37	28		G6	113	20
	C7	39	30	BOLT, FLANGE, 8X27	F4	85	21
	C8	41	30	BOLT, FLANGE, 8X32	C7	39	29
	G1	103	24		G4	109	29
BOLT, FLANGE, 6X20	B7	15	20	BOLT, FLANGE, 8X37	F12	101	19
	B9	19	13		F12	101	20
	F7	91	21	BOLT, FLANGE, 8X45	C1	27	28
	F12	101	18	BOLT, FLANGE, 8X49	E12	77	24
	G1	103	23	BOLT, FLANGE, 8X50	C2	28	29
BOLT, FLANGE, 6X22	B10	21	21	BOLT, FLANGE, 8X55	E12	77	25
	C8	41	28	BOLT, FLANGE, 8X60	G12	125	20
	C8	41	31	BOLT, FLANGE, 8X65	C9	43	26
BOLT, FLANGE, 6X25	B11	22	11	BOLT, FLANGE, 8X80	C2	28	30
	C8	41	32	BOLT, FR. DISK, 8X57	F1	79	15
	G11	122	41	BOLT, FR. DISK, 8X59	F1	79	15
BOLT, FLANGE, 6X28	B6	13	9	BOLT, HEX. SOCKET, 8X32	E7	67	14
	B10	21	22	BOLT, HEX. SOCKET, 8X50	G6	113	14
	B12	25	26	BOLT, HEX., 6X12	F5	86	37
	C1	27	19	BOLT, HEX., 6X16	B12	24	13
	C9	43	27		F4	85	23
BOLT, FLANGE, 6X32	B6	13	10		F7	91	18
	C1	27	20		G2	105	23
BOLT, FLANGE, 6X35	B6	13	11		G6	113	17
	B9	19	14		G8	116	6
	C8	41	33	BOLT, HEX., 6X20	G9	119	24
	E1	55	15	BOLT, HEX., 6X8	E11	74	61
	F8	93	29	BOLT, HOLDING	F6	88	8
BOLT, FLANGE, 6X40	B9	19	15	BOLT, L. RR. SWINGARM PIVOT	G4	109	19
	C1	27	21	BOLT, OIL	B2	4	15
	G3	107	15	BOLT, OIL CONTROL	B2	5	16
	G11	122	43	BOLT, OIL, 10X22	E5	62	17
BOLT, FLANGE, 6X45	B12	25	24		E6	65	16
	C1	27	22	BOLT, OIL, 10X34	E5	62	18
	C1	27	23	BOLT, PANEL STOPPER	G4	109	20
BOLT, FLANGE, 6X50	C1	27	24	BOLT, PIN	E12	77	14
BOLT, FLANGE, 6X52	B2	4	10	BOLT, R. CONTROL LEVER PIVOT	E5	62	15
	B3	7	10		E6	64	14
BOLT, FLANGE, 6X54	B2	4	11	BOLT, R. RR. SWINGARM PIVOT	G4	109	18
	B3	7	11	BOLT, RECESSED, 5X12	E1	55	14
BOLT, FLANGE, 6X55	B10	21	15	BOLT, SIDE STAND PIVOT	G3	106	10

Description Index						
Description	Grid	Page	Ref. No.	Description	Grid	Page Ref. No.
BOLT, SIDE STAND RUBBER SET	G3	106	11	BOOT, PISTON CASE	E10	73 30
BOLT, SLOT, 5X12	E1	54	14	BOSS, OIL FILTER	B11	23 12
BOLT, SOCKET	E10	73	48	BOX ASSY., FUSE	F8	92 5
	G2	105	22		F8	92 6
BOLT, SOCKET, 10X25	G12	125	21	BOX ASSY., PILOT	E2	57 17
BOLT, SOCKET, 10X30	E8	69	15	BOX ASSY., PILOT LOWER	E2	57 19
	G12	125	25	BOX ASSY., PILOT UPPER	E2	57 18
BOLT, SOCKET, 10X35	G2	105	21	BOX ASSY., SPEEDOMETER GEAR	F1	79 9
BOLT, SOCKET, 10X40	E12	77	23	BOX ASSY., TOOL	F8	92 12
BOLT, SOCKET, 6X22	E5	62	16	BRACKET ASSY., CAM CHAIN TENSIONER	B5	10 3
	E6	65	15	BRACKET COMP., CAM CHAIN TENSIONER		
BOLT, SOCKET, 6X23	E5	62	16	HOLDER	B5	11 16
	E6	64	15	BRACKET COMP., L	E1	54 8
BOLT, SOCKET, 7X38	E7	67	13	BRACKET COMP., L FR	E12	77 9
BOLT, SOCKET, 8MM	E10	73	47	BRACKET COMP., L STEP	G2	104 5
BOLT, SOCKET, 8X11	F4	85	19	BRACKET COMP., R	E1	54 9
BOLT, SOCKET, 8X16	G7	115	20	BRACKET COMP., R FR	E12	77 20
BOLT, SOCKET, 8X17	E10	73	49	BRACKET COMP., R STEP	G2	104 4
BOLT, SOCKET, 8X22	C9	43	13	BRACKET, L ELECTRIC PARTS	G9	118 15
BOLT, SPECIAL FLANGE, 8X16	E1	54	12	BRACKET, L RR. TURN SIGNAL	G7	115 17
BOLT, SPECIAL FLANGE, 8X26	E1	54	13	BRACKET, LICENSE PLATE	G6	112 13
BOLT, SPECIAL FLANGE, 8X28	G1	103	15	BRACKET, R ELECTRIC PARTS	G9	118 13
BOLT, SPECIAL FLANGE, 8X45	F12	101	21	BRACKET, R RR. TURN SIGNAL	G7	115 16
BOLT, SPECIAL 6X29	B1	2	5	BRACKET, SIDE STAND RUBBER	G3	106 9
BOLT, SPECIAL 7X18	C7	39	20	BRAKE PAD KIT	E12	77 NI
BOLT, STUD, 10X50	F4	85	20	BRAKE SHOE KIT	F2	81 NI
BOLT, STUD, 6X32	B2	5	20	BRAKE SHOE SET	F2	81 NI
	B3	7	16	BREATHER ASSY.	F4	84 4
BOLT, STUD, 6X45	B2	5	20	BRIDGE, CALIPER BRACKET	E12	77 12
	B3	7	16	BRIDGE, FORK TOP	E7	67 8
BOLT, STUD, 6X50	B2	5	20	BULB	E2	56 1
	B3	7	16	BULB, HEADLIGHT	E1	54 5
BOLT, STUD, 8X50	E11	74	62	BULB, TAILLIGHT	G8	116 4
BOLT, TIE ROD	G1	103	14	BULB, TURN SIGNAL	G7	115 18
BOLT, UBS, 10X34	F3	82	7		G7	115 19
BOLT, UBS, 7X15	B5	11	17	BULB, WEDGE BASE	E2	56 1
BOLT, UBS, 8X100	C9	43	11	BULB, WEDGE BASE 12V3W	E2	56 2
BOLT, UBS, 8X151	B2	4	12	BULB, 12V60/55W H4	E1	54 5
	B3	7	12	BUSH	E6	64 3
BOLT, UBS, 8X60	C9	43	15	BUSH, GUIDE	E9	71 13
BOLT, UBS, 9X108	C1	27	11	BUSH, SLIDER	E9	71 14
BOLT, UBS, 9X177	B2	4	14		E10	72 15
	B3	7	14			
BOLT, UBS, 9X88	C1	26	8			
	C1	26	9			
BOLT, UBS, 9X91	B2	4	13			
	B3	7	13			
BOLT, UBS, 9X98	C1	27	10			
BOOT	E12	77	15			
BOOT COMP., RR. SHOCK	G5	111	20			
BOOT, JOINT	G4	109	14			
BOOT, MASTER CYLINDER	E4	61	12			
	E6	64	12			
BOOT, PIN	E12	77	16			

Description Index						
Description	Grid	Page	Ref. No.	Description	Grid	Page Ref. No.
CALIPER ASSY., L FR	E12	76	3	CASE, HEADLIGHT	E1	54 6
CALIPER ASSY., R FR	E12	77	17	CASE, RR. COWL	F7	90 9
CALIPER COMP., L	E12	76	4	CASE, THERMOSTAT	C8	40 2
CALIPER COMP., R	E12	77	18	CENTER, CLUTCH	B7	14 4
CAM RR. BRAKE	F2	80	7	CHAIN, CAM	B5	10 2
CAM, DAMPER	G4	108	2	CHAIN, OIL PUMP	B11	23 5
CAMSHAFT COMP., FR. EX.	B4	8	4	CHAMBER COMP., EX.	F12	100 3
CAMSHAFT COMP., FR. IN.	B4	8	2	CHAMBER SET, FLOAT	C12	48 4
CAMSHAFT COMP., RR. EX.	B4	8	5	CIRCLIP	E5	62 20
CAMSHAFT COMP., RR. IN.	B4	6	3	CIRCLIP, INTERNAL, 18MM	E6	65 18
CANISTER COMP.	H4	132	3	CIRCLIP, INTERNAL, 50MM	E10	73 33
CAP	G5	110	4	CIRCLIP, 25MM	C6	37 25
CAP A, CONNECTING	C8	40	7	CLAMP	B10	20 12
CAP ASSY. 1, COIL WIRE	G8	117	5		F8	93 25
CAP ASSY. 2, COIL WIRE	G8	117	6	CLAMP A, WATER HOSE	C8	40 11
CAP ASSY. 4, COIL WIRE	G8	117	7	CLAMP A, WATER PIPE	C8	41 14
CAP ASSY., VALVE	E10	73	37	CLAMP B, WATER HOSE	C8	40 12
CAP B, CONNECTING PIPE	C8	40	8	CLAMP B, WATER PIPE	C8	41 17
CAP COMP., FUEL FILLER	F6	89	13	CLAMP, ALTERNATOR CORD	B9	19 8
CAP COMP., RADIATOR	G10	120	7	CLAMP, CABLE	G6	112 10
CAP, AIR VALVE	G5	110	5	CLAMP, COIL WIRE	G9	118 14
CAP, BLEEDER SCREW	B10	20	14	CLAMP, DRAIN TUBE	F11	98 17
	C8	41	21	CLAMP, PULSER CORD	B6	13 5
	E12	76	2	CLAMP, RECTIFIER WIRE	F8	92 3
CAP, BREATHER	F4	84	4	CLAMP, TUBE	F11	99 31
CAP, L LOCK NUT	G4	109	23	CLAMP, TUBE VENT	F11	98 11
CAP, MAIN GALLERY	C1	26	4	CLAMP, WATER HOSE	C8	40 11
CAP, MAIN STAND PIPE	G12	125	18		C8	40 12
CAP, MASTER CYLINDER	E4	61	8		G10	121 25
	E6	64	8		G11	123 2
CAP, OIL FILTER	B6	13	3	CLAMP, WIRE	G12	124 14
CAP, R LOCK NUT	G4	109	22	CLIP, AIR VENT TUBE	G9	118 17
CAP, RESERVE TANK	G10	121	14	CLIP, BREATHER TUBE	C1	26 5
CAP, SOCKET BOLT	E7	67	18		C11	47 42
CAP, SOCKET BOLT, 8MM	E11	74	60		F10	97 1
	G6	113	16		F11	98 23
CAP, STARTING CLUTCH ROLLER SPRING	B8	16	7		H4	132 1
CAP, SWINGARM SIDE	G4	109	16	CLIP, CLUTCH CABLE	G5	110 1
CAP, TAPPET ADJUSTING HOLE	F4	84	1	CLIP, HARNESS	G9	118 11
CARBURETOR ASSY.	C10	45	16	CLIP, HIGH TENSION CORD	C1	26 6
CARBURETOR ASSY. 1	C10	45	17	CLIP, OVER FLOW TUBE	G8	117 1
CARBURETOR ASSY. 2	C10	45	18	CLIP, PISTON PIN, 15MM	B7	15 19
CARBURETOR ASSY. 3	C10	45	19	CLIP, PISTON PIN, 18MM	C5	35 12
CARBURETOR ASSY. 4	C10	45	20	CLIP, PULSER WIRE	B8	17 9
CASE ASSY., L PISTON	E10	73	43	CLIP, TUBE, B10	C11	47 40
CASE ASSY., SIDE GEAR	C9	42	3		H4	133 17
CASE COMP., L LOWER	E10	73	42	CLIP, TUBE, B12	C11	47 41
CASE COMP., R LOWER	E10	72	18		F6	89 24
CASE COMP., SIDE GEAR	C9	42	4	CLIP, TUBE, B7	C11	47 39
CASE, AIR CLEANER	F10	97	8		F6	89 23
CASE, COUPLER HOLDER	E8	68	9	CLIP, TUBE, B8	H4	133 16
CASE, FINAL GEAR	F4	84	3	CLIP, TUBE, C11	G11	122 39
CASE, FUSE	G9	118	10	CLIP, TUBE, C12	F11	99 32
CASE GUIDE	G5	110	15	CLIP, TUBE, D8.5	H4	133 18

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
CLIP, TUBE, 10.5MM	B1	2	19	COVER, COUPLER HOLDER	E8	68	11
	H4	133	19	COVER DAMPER	G4	108	5
CLIP, WIRE HARNESS	B10	20	12	COVER DUST	G1	102	5
COIL COMP., IGNITION	G8	117	2	COVER FAIRING BRACKET	G11	123	5
	G8	117	3	COVER FUSE	F10	96	13
COLLAR A, ENGINE HANGER	G12	124	15	COVER FUSE BOX	F8	92	7
COLLAR B, ENGINE HANGER	G12	124	16	COVER GEAR CASE	F4	84	6
COLLAR B, RR. DISTANCE	F4	85	18	COVER HANDLE	E7	67	7
COLLAR C, ENGINE HANGER	G12	125	17	COVER INDICATOR SWITCH	B9	18	3
COLLAR COMP., FR. AXLE DISTANCE	F1	78	5	COVER L. CANISTER	H4	132	5
COLLAR BUSH	G5	110	7	COVER L. ELECTRIC PARTS	G9	118	19
COLLAR, CANISTER MOUNTING	H4	132	11	COVER L. FR. SIDE	F11	99	26
COLLAR, CHAIN CASE	G2	104	1	COVER L. RADIATOR	G10	121	20
COLLAR, CONNECTING ROD	G5	111	17	COVER, LOWER	E2	57	20
COLLAR, FR. FENDER	F8	92	11		E8	68	14
COLLAR, FR. WHEEL SIDE	F1	78	4	COVER, MAGNETIC SWITCH TERMINAL	F9	95	7
COLLAR, FUEL TANK FR. MOUNTING	F6	89	11		F9	95	9
COLLAR, FUEL TANK SETTING	F6	89	19	COVER, R. CANISTER	H4	132	4
COLLAR, GEAR CHANGE PEDAL PIVOT	G1	102	2	COVER, R. ELECTRIC PARTS	G9	118	18
COLLAR, GEARSHIFT DRUM STOPPER	C7	38	12	COVER, R. FR. SIDE	F11	99	25
COLLAR, GEARSHIFT PEDAL PIVOT	G1	102	2	COVER, R. RADIATOR	G10	121	19
COLLAR, HEADLIGHT CASE	E1	54	7	COVER, RADIATOR HOSE	G10	121	24
COLLAR, MUFFLER MOUNTING	F12	101	15	COVER, RESERVE TANK	G10	120	11
COLLAR, PISTON	E10	72	19	COVER, RR.	B10	20	1
COLLAR, RADIATOR MOUNTING	G10	120	9	COVER, RUBBER	E1	54	4
	G10	121	22	COVER, SPEEDOMETER	E2	57	9
COLLAR, RESERVE TANK SETTING	G10	120	12	COVER, STARTING MOTOR TERMINAL	F9	95	8
COLLAR, RR. AXLE DISTANCE	F3	82	2	COVER, TACHOMETER	E2	57	14
COLLAR, RR. COVER	B10	20	2	COVER, THERMOSTAT	C8	40	3
COLLAR, RR. WHEEL SIDE	F2	80	2	COWL SET, HR.	F7	90	7
COLLAR, SHOCK ARM	G5	110	9	CRANKSHAFT COMP.	C4	33	9
	G5	111	16	CUP, PISTON	B10	20	11
COLLAR, SPLINE, 25X12.5	C6	37	16	CYLINDER ASSY., CLUTCH MASTER	E6	64	1
COLLAR, SPLINE, 25X9.5	C6	36	7	CYLINDER ASSY., CLUTCH SLAVE	B10	20	7
COLLAR, SPRING	E9	71	3	CYLINDER ASSY., FR. BRAKE MASTER	E4	61	6
COLLAR, STAND RUBBER SETTING	G3	106	8	CYLINDER SET, MASTER	E5	62	13
COLLAR, 20X11.8	C6	36	4				
COLLAR, 25.2X7	B7	15	13				
COLLAR, 25X10	C6	36	9				
COLLAR, 25X12	C6	36	13				
COTTER, VALVE	B4	9	15				
COVER A, CYLINDER HEAD	B1	2	1				
COVER ASSY., R. CRANKCASE	B6	13	1				
COVER B, CYLINDER HEAD	B1	2	2				
COVER B, TERMINAL	F10	96	10				
COVER COMP., WATER PUMP	B10	20	5				
COVER SET, L. SIDE	F8	93	19				
COVER SET, R. SIDE	F8	93	16				
COVER SET, VALVE	F5	87	6				
COVER, AIR CLEANER BASE	F11	98	13				
COVER, AIR CLEANER CASE	F10	97	6				
	F10	97	7				
COVER, ALTERNATOR	B9	18	1				
COVER, CLUTCH	C9	42	1				

(D)

DIAGRAM, VACUUM HOSE ROUTING	F8	93	21
DIAPHRAGM	E4	61	11
	E6	64	11
DISK, CLUTCH FRICTION	B7	14	5
DISK, L. FR. BRAKE	F1	79	14
DISK, R. FR. BRAKE	F1	79	13
DRIVER 1, PLUS SCREW	H1	126	13
DRIVER 3, MINUS SCREW	H1	126	14
DRUM ASSY., GEARSHIFT	C7	38	5
DRUM, GEARSHIFT	C7	38	6
DUCT, AIR CLEANER IN	F10	97	10
DUST SEAL	E12	77	8
	G5	111	27
DUST SEAL, BRAKE CAM	F2	80	6

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
DUST SEAL, CONNECTING ROD PIVOT	G5	111	29	GASKET, FR. FORK DRAIN VALVE	E10	73	50
DUST SEAL, FR. FORK	E10	73	53	GASKET, HEAD COVER	B1	2	4
DUST SEAL, STEERING HEAD	E8	68	5		D1	50	3
	E8	68	6	GASKET, INDICATOR SWITCH COVER	B9	18	4
DUST SEAL, 26X40X5	G4	109	26		D1	51	4
DUST SEAL, 40X50X5	F1	79	17	GASKET, LENS	G7	114	6
				GASKET, MUFFLER	F12	100	11
					F12	100	12
				GASKET, OIL PAN	B11	23	2
					D1	51	1
				GASKET, OIL STRAINER	B11	23	8
				GASKET, PISTON CASE	E10	72	16
				GASKET, R. COVER	B6	13	2
					D1	51	2
				GASKET, SEAL	G8	116	1
				GASKET, SIDE GEAR CASE	C9	42	5
					D1	51	5
				GASKET, WATER PUMP COVER	B10	20	6
				GAUGE, FEELER, 0.7	H1	126	3
				GAUGE, OIL LEVEL	B6	13	4
				GEAR ASSY., FINAL	F4	84	2
				GEAR COMP., STARTER CLUTCH	B8	16	3
				GEAR COMP., STARTING CLUTCH	B8	16	3
				GEAR SET, FINAL	F4	84	5
				GEAR, COUNTERSHAFT FIFTH	C6	36	14
				GEAR, COUNTERSHAFT FOURTH	C6	36	11
				GEAR, COUNTERSHAFT LOW	C6	36	3
				GEAR, COUNTERSHAFT SECOND	C6	36	6
				GEAR, COUNTERSHAFT SIXTH	C6	37	17
				GEAR, COUNTERSHAFT THIRD	C6	36	8
				GEAR, MAINSHAFT FIFTH	C6	36	12
				GEAR, MAINSHAFT FOURTH	C6	36	10
				GEAR, MAINSHAFT SECOND & THIRD	C6	36	5
				GEAR, MAINSHAFT SIXTH	C6	37	15
				GEAR, PRIMARY DRIVE	B7	14	11
				GEAR, SPEEDOMETER	F1	79	10
				GEAR, STARTER REDUCTION	B8	16	2
				GRILLE, RADIATOR	G10	120	6
				GRIP	H1	126	15
				GRIP, L. HANDLEBAR	E3	59	10
				GRIP, L. SIDE	G6	112	12
				GRIP, R. HANDLEBAR	E3	59	9
				GRIP, R. SIDE	G6	112	11
				GROMMET A, RR. COVER	B10	20	3
				GROMMET A, SIDE COVER	F8	93	17
				GROMMET B, RR. COVER	C9	42	2
				GROMMET, AIR CLEANER CASE	F8	92	15
					G9	119	21
				GROMMET, BREATHER TUBE	G11	123	4
				GROMMET, SIDE COVER	F6	89	14
				GUIDE A, CAM CHAIN	B5	11	8
				GUIDE B, CAM CHAIN	B5	11	14
				GUIDE COMP. A, CAM CHAIN	B5	11	6
				GUIDE, CLUTCH OUTER	B7	14	3

(E)

ELEMENT, AIR CLEANER	F10	97	2
EMBLEM, L. FUEL TANK	F6	89	16
EMBLEM, R. FUEL TANK	F6	89	15
EMBLEM, RR. COWL	F7	91	12
EMBLEM, SIDE COVER	F8	93	20

(F)

FAN, COOLING	G10	120	4
FENDER A, RR.	G6	112	5
FENDER B, RR.	G6	112	7
FENDER COMP., FR.	E9	70	1
FILTER, OIL	B11	23	10
FLANGE, FINAL DRIVEN	F3	82	1
FLANGE, STARTER CLUTCH	B8	16	4
FLOAT SET	C12	48	3
FORK, CENTER GEARSHIFT	C7	38	2
FORK, L. GEARSHIFT	C7	38	3
FORK, R. GEARSHIFT	C7	38	1
FRAME COMP.	G11	123	3
FUNNEL, AIR	C10	45	21
FUSE B	F8	93	30
	G9	119	27
FUSE F	F10	96	21
FUSE, BLADE	F9	94	31
	F9	94	32

(G)

GASKET	E10	72	16
GASKET A, EX. PIPE	D1	50	4
	F12	100	2
GASKET SET	C12	48	1
GASKET, AIR CLEANER COVER	F10	97	5
	F10	97	9
GASKET, ALTERNATOR COVER	B9	18	2
	D1	51	3
GASKET, CONNECTING CAP	C8	41	22
	D1	51	8
GASKET, CYLINDER HEAD	B2	4	7
	B3	6	6
	D1	50	2

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
GUIDE, DRAIN PIPE	F 12	101	17	(I)			
GUIDE, EX. VALVE	B1	3	1				
	B3	6	1	INDICATOR, RR BRAKE	F2	80	8
GUIDE, OIL SEAL	G4	108	8	INSULATOR, CARBURETOR	B2	4	8
					B3	6	7
(H)				INSULATOR, CLUTCH SLAVE CYLINDER	B10	20	8
					D1	51	6
HANDLE, EYE WRENCH, 120MM	H1	127	16	(J)			
HANDLEBAR	E7	67	6				
HANDLEBAR, COMP. R.	E5	62	14	JET, MAIN, $\approx$ 130	C12	49	22
HARNES, WIRE	G8	117	9	JET, MAIN, $\approx$ 122	C12	49	21
HEAD COMP. FR. CYLINDER	B1	3	2	JET, MAIN, $\approx$ 95	C12	49	21
HEAD COMP. RR. CYLINDER	B3	6	4	JET, MAIN, $\approx$ 98	C12	49	22
HEADLIGHT ASSY.	E1	54	1	JET, NEEDLE	C12	49	16
HEADLIGHT UNIT	E1	54	3	JET, SECONDARY MAIN	C12	49	22
HOLDER	G7	114	7	JET, SECONDARY MAIN, $\approx$ 130	C12	49	22
HOLDER A. CAMSHAFT	B1	3	3	JET, SLOW, $\approx$ 40	C12	49	23
	B3	6	2	JOINT B. BRAKE ARM	G1	103	21
HOLDER ASSY. A. CAM CHAIN TENSIONER	B5	11	11	JOINT COMP., YOKE	G4	108	1
HOLDER ASSY. B. CAM CHAIN TENSIONER	B5	11	13	JOINT SET A. FUEL	C10	44	6
HOLDER B. CAMSHAFT	B1	3	4	JOINT SET B. FUEL	C10	45	13
	B3	6	3	JOINT SET C. FUEL	C10	44	4
HOLDER SET, BRUSH	B11	22	5	JOINT SET D. FUEL	C10	44	12
HOLDER 1C, FR. FORK AXLE	E11	75	67	JOINT SET E. FUEL	C10	44	7
HOLDER BOOT	E10	73	32	JOINT, BOOST	B3	6	8
HOLDER, COUNTERSHAFT BEARING	C9	42	6	JOINT, BREATHER	F11	98	22
HOLDER, CROSS SHAFT BEARING	C9	42	8	JOINT, EX. PIPE	F12	100	1
HOLDER GREASE	E8	68	8	JOINT, FUEL TUBE	H4	132	2
HOLDER, HELMET	F7	90	1	JOINT, PINION	F4	84	11
HOLDER, IGNITOR	G6	112	8	JOINT, TUBE	G10	121	13
HOLDER, JET NEEDLE	C12	49	17	JOINT, TWO WAY	E4	61	5
	C12	49	18	(K)			
HOLDER, L. PILLION STEP	G2	104	15				
HOLDER, L. UPPER	E7	67	11	KEY SET	E7	67	1
HOLDER, MASTER CYLINDER	E4	61	9	KEY, BLANK	E7	67	5
	E6	64	9	KEY, WOODRUFF	C5	35	11
HOLDER, O-RING	F4	84	12	KNOB, TRIP METER	E2	57	12
HOLDER, R. PILLION STEP	G2	104	14	(L)			
HOLDER, R. UPPER	E7	67	9				
HOLDER, RR. SWINGARM GREASE	G4	109	15	LABEL, BATTERY CAUTION	G12	125	19
HOLDER, UPPER	E7	67	10	LABEL, DRIVE CAUTION	F6	89	18
HORN ASSY.	E8	68	2	LABEL, FAN MOTOR FUSE	G9	118	20
	E8	68	3	LABEL, FR. FORK CAUTION	F6	89	17
HOSE A. RADIATOR	G10	121	23	LABEL, FUSE	F8	92	8
HOSE B. FR. BRAKE	E4	61	4	LABEL, HELMET HOLDER	F7	91	13
HOSE B. WATER	C8	41	18	LABEL, JACK UPPER WARNING	H4	132	12
HOSE, CONNECTING	C8	40	4	LABEL, RESERVE TANK	G10	121	29
HOSE, L. FR. BRAKE	E4	61	2	LABEL, RR. CUSHION CAUTION	F8	93	23
HOSE, LOWER WATER	G12	124	12				
HOSE, R. FR. BRAKE	E4	61	3				
HOSE, RADIATOR	G10	121	17				
HOSE, WATER	C8	41	15				

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
LABEL, TIRE CAUTION	G4	109	17	NUT, FLANGE, 6MM	E8	69	20
LENS, TURN SIGNAL	G7	114	3		F7	91	20
LEVER COMP., L. HANDLE	E6	64	13		F10	96	18
LEVER SET A. LINK	C10	44	1		F12	101	25
LEVER, CHOKE	E3	59	4		G3	106	13
LID, RR. COWL CASE	F7	91	10		G9	119	22
LIFTER, DAMPER	G4	108	3		G11	122	37
LINK SET A. STARTER	C10	44	2	NUT, FLANGE, 8MM	F12	101	26
LINK SET B. STARTER	C10	44	5		G12	125	26
LINK SET C. STARTER	C10	44	9	NUT, GOVERNOR ARM FIXING	G1	103	16
LOCK, BEARING ADJUSTING	F4	84	9	NUT, HEX, 10MM	G3	106	12
	F4	84	10		G4	109	21
(M)				NUT, HEX, 16MM	F4	85	25
				NUT, HEX, 3MM	E3	58	31
MAINSHAFT	C6	36	1		E3	58	33
MARK, ACCESSORIES & LOADING CAUTION	F7	91	14	NUT, HEX, 6MM	C7	39	28
MARK, FR. FORK	E10	73	39		E3	58	32
MARK, RADIATOR CAUTION	F8	93	22		G1	103	17
METAL BUSH	G5	110	6		G1	103	18
METER, TEMPERATURE & GEAR POSITION	E2	57	16	NUT, HEX, 8MM	E11	75	64
MIRROR, L.	E4	60	12	NUT, INSTRUMENT SETTING	E2	57	24
MIRROR, R.	E4	60	11	NUT, LOCK, 22MM	B7	14	12
MOTOR ASSY., STARTER	B11	22	1	NUT, LOCK, 30MM	C9	43	16
MOTOR, FAN	G10	120	5	NUT, LOCK, 64MM	C9	43	17
MUFFLER COMP., L.	F12	101	16	NUT, RR. AXLE U. 16MM	F4	85	24
MUFFLER COMP., R.	F12	100	5	NUT, RR. SWINGARM PIVOT	G4	109	24
(N)				NUT, SPECIAL, 6X7	F11	99	24
				NUT, SPEED, 3MM	F8	93	24
NEEDLE, FR. JET	C12	49	15	NUT, STEERING STEM	E7	67	15
	C12	49	16	NUT, TAPPET ADJUSTING	B4	9	17
NEEDLE, RR. JET	C12	49	15	(O)			
	C12	49	16				
NET COMP., AIR CLEANER BASE	F11	98	14	O-RING	B11	22	8
NUT B. BRAKE ROD ADJUSTING	G1	103	22		B11	22	9
NUT, CAP, 8MM	E3	58	34	O-RING B, 6.8X1.9	E2	57	25
NUT-WASHER, 6MM	B11	22	7		E11	74	57
NUT, AXLE, 10MM	G5	111	26	O-RING D, 13.8X2.4	E11	74	55
	G5	111	31	O-RING E, 33.5X2	E11	74	56
NUT, CAP, 6MM	E5	63	23	O-RING, 12.5X1.4	G10	121	30
	E6	65	21	O-RING, 13.5X1.4	G10	121	30
	F12	101	22	O-RING, 13.8X2.4	E11	74	55
NUT, CONNECTING ROD	G9	119	22	O-RING, 13X2.5	C8	41	26
NUT, FLANGE, 10MM	C3	31	5		D2	52	20
	G12	125	31	O-RING, 14.6X3.7	B12	24	16
	G12	125	32		D1	51	14
NUT, FLANGE, 12MM	G7	115	24	O-RING, 14.7X2.2	B12	24	18
NUT, FLANGE, 5MM	F10	96	17		D2	52	16
NUT, FLANGE, 6MM	E5	63	23	O-RING, 14.8X2.2	B12	24	18
	E6	65	21		D2	52	16
				O-RING, 16.8X1.9	E12	77	27
				O-RING, 18.3X2.3	C8	41	23
					D1	51	9

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
O-RING, 18.5X2.4	B12	24	17	PAN. OIL	B11	23	1
	D1	51	15	PANEL COMP. RR	F2	80	3
O-RING, 18X2.8	C1	27	16	PEDAL ASSY., GEARSHIFT	G1	102	1
	D2	52	17	PEDAL COMP., GEARSHIFT	G1	102	4
O-RING, 19X1.9	G4	109	28	PEDAL COMP., RR BRAKE	G1	102	11
O-RING, 21.5X2	B4	9	19	PIECE B. OIL LOCK	E10	73	44
	D1	50	6	PIECE, CLUTCH JOINT	B7	14	8
O-RING, 22X1.9	F5	86	34	PIECE, OIL LOCKING	E10	72	20
O-RING, 22X3.0	B6	13	6	PIN A. ARM	B5	11	12
	D1	51	10	PIN A. DOWEL, 12X20	B2	5	24
O-RING, 29X2.4	E11	74	58		B3	7	20
O-RING, 3X70	C9	43	25	PIN A. DOWEL, 8X14	B2	5	23
	D2	52	18		B3	7	19
O-RING, 30.8MM	F5	86	33		B6	13	8
O-RING, 32.95X2.62	B10	21	19		B10	21	20
	D1	51	11		B12	24	23
O-RING, 35.2X2.4	F5	86	35		C1	27	17
O-RING, 46X5X3.5	F3	83	9	PIN B. JOINT	G1	102	10
O-RING, 49.4X3.1	E11	74	59	PIN C. PILLION STEP	G2	105	28
O-RING, 5.6X1.9	E11	74	54	PIN, COTTER, 20X32	B12	24	22
	G5	111	30	PIN, COTTER, 2.5MM	F2	80	11
O-RING, 5.7X2.2	C9	43	24		G3	106	14
	D1	51	13	PIN, DOWEL, 8X14	B12	25	23
O-RING, 5.8X1.9	E10	73	54	PIN, DOWEL, 8X8	B8	17	14
	G5	111	30	PIN, HANGER RETAINER GROOVE, 4.0MM DIA.	E12	77	21
O-RING, 56.5X3.5	F3	83	8	PIN, KNOCK	C10	45	22
O-RING, 58.5X3.5	F5	86	36	PIN, KNOCK, 8X14	B12	24	15
O-RING, 58X2	C8	41	24	PIN, LOCK, 6MM	B5	11	22
	D1	51	12	PIN, LOCK, 8MM	B6	12	23
O-RING, 6.8X1.9	E2	57	25	PIN, PARALLEL	E10	73	34
	E11	74	57	PIN, PISTON	B8	16	1
O-RING, 7.7X2.3	B12	24	19		C3	31	3
O-RING, 7.8X2.2	B12	24	19	PIN, PISTON, 10X33	B8	16	1
O-RING, 70X3	C9	43	25	PIN, RING GEAR STOPPER	F4	84	13
	D2	52	18	PIN, SHIFT RETURN SPRING	C7	39	19
O-RING, 8.4X2.4	B6	13	7	PIN, SPECIAL LOCK, 6MM	B5	11	21
OIL SEAL, 12.5X25X8	C1	27	14	PIN, SPLIT, 1.6X10	G2	105	26
OIL SEAL, 25X66X8.5	C9	43	23	PIN, SPLIT, 1.6X12	G1	103	19
OIL SEAL, 34X50X7	F5	86	31	PIN, SPLIT, 1.6X15	G2	105	27
OIL SEAL, 47X56X7	G4	109	27	PIN, SPLIT, 1.6X25	G2	105	27
OIL SEAL, 60X80X8	F5	86	32	PIN, SPLIT, 20X25	B12	24	22
OIL SEAL, 65X80X10.5	G5	111	28	PIN, SPLIT, 20X35	B12	24	22
OIL SEAL, 8X18X5	B10	21	18	PIN, SPLIT, 2.5MM	F2	80	11
OIL SEAL, 8X25X8	C9	43	22	PIN, SPRING, 2X14	F8	93	27
ORIFICE, OIL CONTROL	C9	43	12	PIN, STEP BAR JOINT	G2	104	2
ORIFICE, PIN, 10X16	C9	43	18	PIN, 8X43.2	B5	11	10
ORIFICE, PLATE	C6	37	24	PIPE A. OIL PATH	B1	3	5
OUTER COMP., CLUTCH	B7	14	2		B3	6	5
OUTER COMP., STARTER CLUTCH	B8	16	5	PIPE A. WATER	C8	40	13
				PIPE ASSY., CLUTCH	E6	64	5
(P)				PIPE B. OIL PATH	B2	4	6
				PIPE B. WATER	C8	41	16
PAD COMP., FR.	E12	76	5	PIPE COMP., L. FR. SHOCK	E10	73	41
				PIPE COMP., R. FR. SHOCK	E9	71	10

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
PIPE, CONNECTING	C8	40	6	(R)			
PIPE, L. RR. EX.	F12	100	13				
PIPE, L. SEAT	E10	73	45	RADIATOR COMP.	G10	120	2
PIPE, MAIN STAND PIVOT	G3	106	3	RAIL, RR. GRAB	F7	91	11
PIPE, OIL	B11	23	11	RECTIFIER ASSY., REGULATE	F8	92	2
PIPE, OIL STRAINER	B11	23	6	RECTIFIER ASSY., SILICON	G8	117	8
PIPE, R. RR. EX.	F12	100	6	REFLECTOR, L. FR. REFLEX	G10	121	27
PIPE, SEAT	E10	72	28	REFLECTOR, R. FR. REFLEX	G10	121	26
PIPE, THROTTLE GRIP	E3	59	8	REFLECTOR, TURN SIGNAL	G7	114	4
PIPE, WATER OUTLET CONNECTING	C8	40	5	RELAY COMP., TURN SIGNAL	G6	112	3
PISTON	C3	31	2	RETAINER, BEARING	F4	84	8
	E10	72	24	RETAINER, BRACKET	E12	77	11
	E12	76	6	RETAINER, GEAR BOX	F1	78	7
PISTON COMP., VACUUM	C12	49	14	RETAINER, VALVE SPRING	B4	9	12
PISTON SET, CLUTCH MASTER CYLINDER	E6	64	4	RING B. STOPPER	G5	110	10
PISTON, SLAVE CYLINDER	B10	20	9	RING SET, PISTON	C3	31	1
PLATE	E12	77	22	RING, BACK UP	E9	71	12
PLATE A. DRUM	C7	38	8		G5	111	18
PLATE A. ELEMENT SETTING	F10	97	3	RING, DAMPER COVER	G4	108	10
PLATE B. CLUTCH	B7	14	6	RING, HEADLIGHT	E1	54	2
PLATE B. DRUM SETTING	C7	38	9	RING, PISTON	E10	72	25
PLATE B. ELEMENT SETTING	F10	97	4	RING, SEAL	B11	22	6
PLATE SET, STAY	C10	44	11	RING, SNAP	E10	73	52
PLATE SET, VALVE	C12	48	7	RING, SPRING STOPPER	G4	108	9
PLATE, BATTERY SETTING	F9	95	2	RING, STOPPER	E9	71	8
PLATE, BEARING SETTING	C6	36	2		E9	71	9
PLATE, CLUTCH	B7	14	6		G4	108	11
PLATE, CLUTCH PRESSURE	B7	14	7	ROD ASSY. A. FR. CONNECTING	C3	31	4
PLATE, COUPLER HOLDER	F8	92	4	ROD ASSY. A. RR. CONNECTING	C3	31	6
PLATE, DIAPHRAGM	E4	61	10	ROD ASSY. B. FR. CONNECTING	C3	31	4
	E6	64	10	ROD ASSY. B. RR. CONNECTING	C3	31	6
PLATE, DRUM CAM	C7	38	7	ROD ASSY. C. FR. CONNECTING	C3	31	4
PLATE, DUST GUARD	F4	84	7	ROD ASSY. C. RR. CONNECTING	C3	31	6
PLATE, FUEL TANK HEAT GUARD	G11	123	6	ROD ASSY. D. FR. CONNECTING	C3	31	4
PLATE, HEAT GUARD	G11	123	1	ROD ASSY. D. RR. CONNECTING	C3	31	6
PLATE, L. ENGINE UPPER HANGER	G12	124	13	ROD ASSY. E. FR. CONNECTING	C3	31	4
PLATE, L. SEAT LOCK	F7	90	4	ROD ASSY. E. RR. CONNECTING	C3	31	6
PLATE, L. SIDE	F8	92	10	ROD ASSY., SHOCK CONNECTING	G5	110	8
PLATE, OIL SEPARATE	C1	26	3	ROD ASSY., TENSION	G5	111	19
PLATE, R. SEAT LOCK	F7	90	3	ROD SET A. STARTER LINK	C10	44	3
PLATE, RR. FENDER	G6	112	9	ROD SET B. STARTER LINK	C10	44	10
PLATE, SETTING	C10	45	15	ROD, ADJUSTING	E10	72	21
PLIERS, 135	H1	126	12	ROD, CLUTCH LIFTER	B7	14	10
PLUG, BREATHER TUBE	F11	98	19	ROD, PUSH	E6	64	2
PLUG, SPARK	B2	5	26	ROD, RR. BRAKE	G1	102	9
	B3	7	21	ROLLER, 15X13	B8	17	16
PROTECTOR	E4	61	7	ROLLER, 4X13.8	C7	39	26
	E6	64	7	ROLLER, 6X15	B8	17	21
PROTECTOR, RR. EX. PIPE	F12	100	4	ROTOR COMP.	B9	18	6
PROTECTOR, TUBE	G9	118	16	RUBBER A. MOUNTING	G11	123	7
PULLER, FUSE	F8	92	9	RUBBER A. STAND STOPPER	F12	101	29
PUMP ASSY., OIL	B11	23	3	RUBBER B. BATTERY TRAY MOUNT	F8	93	18
PUMP COMP., WATER	B10	20	4	RUBBER B. MOUNTING	G11	123	8
				RUBBER C. MOUNTING	G11	123	9

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
RUBBER D. MOUNTING	G12	124	10	SCREW, OVAL 4X8	E3	58	28
RUBBER, BATTERY	F9	95	4	SCREW, OVAL 5X20	E3	58	29
RUBBER, CANISTER MOUNTING	H4	132	10	SCREW, PAN	C10	45	14
RUBBER, FUEL TANK FR.	F6	89	10	SCREW, PAN, 2X6	E2	57	23
RUBBER, FUEL TANK RR.	F6	89	12	SCREW, PAN, 3X10	E2	57	26
RUBBER, GEARSHIFT PEDAL	G1	102	6	SCREW, PAN, 3X20	E2	57	27
RUBBER, MAIN FOOTPEG	G2	104	13	SCREW, PAN, 4X10	B8	17	18
RUBBER, METER SETTING	E2	56	3		C12	49	19
RUBBER, MOUNTING	B1	2	7	SCREW, PAN, 4X15	F11	99	27
RUBBER, MUFFLER MOUNTING	F12	101	14	SCREW, PAN, 4X6	F8	93	26
RUBBER, PILLION FOOTPEG	G2	105	19		F10	96	16
RUBBER, PURGE CONTROL VALVE				SCREW, PAN, 5X10	E11	74	63
MOUNTING	C11	46	29	SCREW, PAN, 5X115	B11	22	4
RUBBER, RADIATOR MOUNTING	G10	120	8	SCREW, PAN, 5X28	B2	5	22
	G10	121	21		B3	7	18
RUBBER, SEAT STOPPER	F7	90	8	SCREW, PAN, 5X8	B2	5	21
RUBBER, SHOCK	F10	96	14		B3	7	17
RUBBER, SPEEDOMETER	E2	57	11	SCREW, PAN, 6X12	B9	19	11
RUBBER, STAND	G3	106	7	SCREW, PAN, 6X8	F12	101	24
RUBBER, STOPPER	E10	73	29	SCREW, RIVET, 1.5X5	G12	125	29
RUBBER, TACHOMETER	E2	57	15	SCREW, RR. COVER	H4	132	14
				SCREW, SPECIAL 6X8	G7	115	21
(S)				SCREW, TAPPET ADJUSTING	B4	9	16
				SCREW, TAPPING, 3X10	E3	58	30
SCREEN SET, FUEL STRAINER	F5	87	4	SCREW, TAPPING, 3X8	G11	122	36
SCREW SET	C10	44	8	SCREW, TAPPING, 4X12	G6	113	18
SCREW SET A	C12	48	5		G7	115	22
SCREW SET C	C12	48	6	SCREW, TAPPING, 4X25	G7	115	23
SCREW-WASHER, 4X10	C11	46	30	SCREW, TAPPING, 6X12	F7	91	19
SCREW-WASHER, 4X12	C11	46	31	SCREW, WASHER, 4X8	G10	121	33
	E5	62	22	SCREW, WASHER, 6X16	G9	119	25
	E6	65	20	SCREW, 4MM	G10	121	33
SCREW-WASHER, 4X16	C12	49	20	SCREW, 5X10	E11	75	63
SCREW-WASHER, 4X8	F6	89	22	SEAL SET, FR. FORK	E10	73	38
SCREW-WASHER, 5X10	G10	121	34	SEAL SET, FR. SHOCK	E10	73	38
SCREW-WASHER, 5X12	C11	46	33	SEAL, AIR CLEANER BASE	F10	97	9
	F11	99	28	SEAL, DUST	E10	73	53
	G12	125	30	SEAL, DUST, 22X42X7	F1	79	16
SCREW-WASHER, 5X20	E4	60	13	SEAL, OIL	C1	27	15
SCREW-WASHER, 5X28	E4	60	14	SEAL, OIL, 14X24X6	C1	27	15
SCREW-WASHER, 5X45	E4	60	15	SEAL, PISTON	E12	77	19
SCREW-WASHER, 5X8	C11	46	32	SEAL, SHOCK ARM	G5	110	11
SCREW-WASHER, 6X12	G10	121	35		G5	110	12
SCREW-WASHER, 6X20	F11	99	29	SEAL, VALVE STEM	B4	8	1
SCREW, BLEEDER	B10	20	13		D1	50	1
	C8	41	20	SEAL, WATER PIPE	C8	41	25
	E12	76	1		D2	52	19
SCREW, FLAT, 4X12	E5	62	21	SEAT ASSY.	F7	90	2
	E6	65	19	SEAT, SPRING	E9	71	4
SCREW, FLAT, 6X16	C6	37	27		E9	71	7
	C7	39	27	SEAT, VALVE SPRING INNER	B4	9	14
SCREW, FLAT, 6X18	F11	98	12	SEAT, VALVE SPRING OUTER	B4	9	13
SCREW, OVAL 3X6	F6	89	21	SENDING UNIT, WATER TEMPERATURE	C8	41	19
				SEPARATOR, COUPLER HOLDER	E8	68	10

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
SHAFT COMP. GEARSHIFT FORK	C7	38	4	SPRING, CLICK	E10	72	22
SHAFT SET, CROSS	C9	43	10	SPRING, CLUTCH	B7	14	9
SHAFT, SHIFT DRUM STOPPER PIVOT	C7	38	13	SPRING, DAMPER CAM	G4	108	4
SHAFT, VALVE ROCKER ARM	B4	9	7	SPRING, FR. BRAKE SHOE	F2	80	10
SHIM A, PINION GEAR	F4	85	15	SPRING, FR. SHOCK	E9	71	2
SHIM A, STOPPER PIN	F4	85	14	SPRING, FR. SHOCK REBOUND	E9	71	11
SHIM B, PINION GEAR	F4	85	15	SPRING, FR. VACUUM PISTON	C12	48	9
SHIM B, STOPPER PIN	F4	85	14	SPRING, FUEL TUBE COVER	F5	87	1
SHIM C, PINION GEAR	F4	85	15		G10	120	1
SHIM D, PINION GEAR	F4	85	15	SPRING, GEARSHIFT ARM	C7	39	17
SHIM E, PINION GEAR	F4	85	15	SPRING, GEARSHIFT RETURN	C7	39	18
SHIM F, PINION GEAR	F4	85	15	SPRING, MAIN STAND	G3	106	2
SHIM G, PINION GEAR	F4	85	15	SPRING, NEUTRAL STOPPER	C7	38	15
SHIM, COUNTERSHAFT	C9	42	7	SPRING, OIL LOCK VALVE	E9	71	6
SHIM, CROSS SHAFT	C9	42	9	SPRING, PAD	E12	77	7
SHIM, DAMPING	F1	79	12	SPRING, PISTON	E10	72	17
SHOCK ABSORBER ASSY., L. FR.	E10	73	40	SPRING, PROPELLER SHAFT	G4	108	6
SHOCK ABSORBER ASSY., R. FR.	E9	71	1	SPRING, RR. VACUUM PISTON	C12	48	10
SHOCK ABSORBER ASSY., RR.	G5	110	3	SPRING, SEAT LOCK	F7	90	6
SHOE COMP., RR. BRAKE	F2	80	5	SPRING, SHIFT DRUM STOPPER	C7	38	14
SHROUD COMP.	G10	120	3	SPRING, SIDE STAND	G3	106	5
SLEEVE	E12	77	10	SPRING, SLAVE CYLINDER	B10	20	10
SLEEVE, FR. CALIPER BRACKET	E12	77	13	SPRING, STARTING CLUTCH ROLLER	B8	16	6
SLIDER, STEP	G2	104	8	SPRING, STEP RETURN	G2	104	6
SOCKET COMP.	E2	56	5		G2	104	7
	E2	56	6	SPRING, STOP SWITCH	G1	102	8
SOCKET COMP., ILLUMINATION	E2	57	10	SPRING, TENSIONER	B5	11	4
SOCKET COMP., TURN SIGNAL	G7	114	5	SPRING, VALVE INNER	B4	9	11
	G7	114	9	SPRING, VALVE OUTER	B4	9	10
SPACER A, RING GEAR	F4	85	17	SPROCKET, CAM	B5	10	1
SPACER B, RING GEAR	F4	85	17	SPROCKET, OIL PUMP DRIVE	B7	14	1
SPACER C, RING GEAR	F4	85	17	SPROCKET, OIL PUMP DRIVEN	B11	23	4
SPACER D, RING GEAR	F4	85	17	STABILIZER, FR. SHOCK	E10	73	46
SPACER E, RING GEAR	F4	85	17	STAND COMP., MAIN	G3	106	1
SPACER F, RING GEAR	F4	85	17	STATOR COMP.	B9	18	7
SPACER G, RING GEAR	F4	85	17	STAY A, PULSE ALTERNATOR	B8	17	10
SPACER H, RING GEAR	F4	85	17	STAY ASSY., INSTRUMENT	E2	56	7
SPACER I, RING GEAR	F4	85	17	STAY B, PULSE ALTERNATOR	B8	17	11
SPACER, IGNITION COIL	G8	117	4	STAY, COUPLER HOLDER	E8	68	12
SPACER, RR. FENDER	G6	112	6	STAY, FR. TURN SIGNAL	G7	114	10
SPANNER, 10X12	H1	126	10		G7	114	11
SPANNER, 14X17	H1	126	11	STAY, HORN	E8	68	13
SPANNER, 8MM	H1	126	9	STAY, L. HEADLIGHT	E1	54	11
SPARK UNIT	F8	92	1	STAY, METER	E2	56	7
	G6	112	1	STAY, R. HEADLIGHT	E1	54	10
	G6	112	2	STEM COMP., STEERING	E8	68	4
SPEEDOMETER ASSY.	E2	56	8	STEP ASSY., L. MAIN	G2	104	11
SPINDLE COMP. GEARSHIFT	C7	38	16	STEP ASSY., R. MAIN	G2	104	10
SPINDLE COMP., RR. BRAKE	G1	102	12	STOPPER, FOOTPEG RUBBER	G2	104	9
SPRING	C12	48	11	STOPPER, KEY BODY	F8	92	14
	C12	49	12	STOPPER, SIDE STAND	G3	106	6
SPRING A, BRAKE ROD	G1	103	20	STOPPER, SPRING	G4	108	7
SPRING, BRAKE PEDAL	G1	102	13	STRAINER, OIL	B11	23	7
SPRING, CARBON BRUSH	B11	22	3	STRAP, CABLE, 118MM	G9	119	23

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
STRIPE, L. FUEL TANK	H2	129	2	TUBE, BREATHER	H4	132	9
STRIPE, L. RR. COWL	H3	131	4	TUBE, BREATHER DRAIN	F11	98	16
STRIPE, L. SIDE COVER	H3	131	6	TUBE, CANISTER BREATHER	H4	132	6
STRIPE, R. FUEL TANK	H2	129	1	TUBE, CHARGE	H4	132	7
STRIPE, R. RR. COWL	H2	129	3		H4	132	8
STRIPE, R. SIDE COVER	H3	131	5	TUBE, FUEL, 7.3X170	F6	88	7
SUB FRAME COMP.	G12	124	11	TUBE, LEVEL	G10	121	18
SUB HARNESS, HORN	E8	68	1	TUBE, OVERFLOW	G10	121	16
SUSPENSION, TURN SIGNAL RELAY	G6	112	4	TUBE, RESERVE TANK	G10	121	15
SWINGARM ASSY., DRIVE	G4	108	12	TUBE, TENSIONER SPRING	B5	11	9
SWINGARM ASSY., RR.	G4	108	13	TUBE, VACUUM	F5	87	3
SWITCH ASSY., CHANGE	B9	19	9	TUBE, 3.5X180	C11	47	36
SWITCH ASSY., CLUTCH	E6	64	6	TUBE, 3.5X200	C11	47	37
SWITCH ASSY., COMBINATION & LOCK	E7	67	2	TUBE, 3.5X210	C11	47	38
	E7	67	3	TUBE, 3.5X70	C11	47	34
SWITCH ASSY., FR. STOP	E4	61	1	TUBE, 3.5X80	C11	47	35
SWITCH ASSY., OIL PRESSURE	C1	26	7	TUBE, 8X440	H4	133	20
SWITCH ASSY., RR. STOP	G1	102	7	TURN SIGNAL ASSY.	G7	114	1
SWITCH ASSY., STARTER MAGNETIC	F10	96	12		G7	114	8
SWITCH ASSY., STARTER/ENGINE STOP	E3	59	6	TURN SIGNAL ASSY., L. FR.	G7	114	8
SWITCH ASSY., STARTER/KILL	E3	59	6	TURN SIGNAL ASSY., L. RR.	G7	115	14
SWITCH ASSY., TURN SIGNAL	E3	59	7	TURN SIGNAL ASSY., R. FR.	G7	114	1
SWITCH ASSY., STARTER/KILL	E3	59	6		G7	114	12
					G7	115	14
				TURN SIGNAL ASSY., R. RR.	G7	115	12
(T)							
T-JOINT	C10	45	23	(V)			
TACHOMETER ASSY.	E2	57	13	VALVE ASSY., FUEL	F5	87	2
TAILLIGHT UNIT	G8	116	2	VALVE ASSY., RELIEF	B11	23	9
TANK COMP., FUEL	F6	88	9	VALVE COMP., AIR	E10	73	36
TANK SET, FUEL	F6	88	9		G5	110	2
TANK, RESERVE	G10	120	10	VALVE COMP., PURGE CONTROL	C11	46	28
TANK, STORAGE	F11	98	20	VALVE SET, FLOAT	C12	48	2
TENSIONER, CAM CHAIN	B5	11	5	VALVE SET, STARTER	C12	48	8
TERMINAL SET, BRUSH	B11	22	2	VALVE, EX.	B4	9	9
THERMOSTAT	C8	40	1	VALVE, IN.	B4	9	8
THERMOSWITCH ASSY.	G10	121	28	VALVE, OIL LOCK	E9	71	5
THREAD COMP., STEERING HEAD UPPER	E8	68	7	VALVE, RIM	F1	78	2
THREAD, STEERING HEAD TOP	E8	69	16		F3	82	6
TIRE ASSY., FR.	F1	78	8				
	F3	82	5				
TIRE ASSY., RR.	F3	82	5				
TOOL SET	H1	126	1	(W)			
TOP COMP.	C12	49	13	WASHER	E2	56	4
TUBE	C11	46	25	WASHER B, THRUST, 25MM	C6	37	22
	C11	46	26	WASHER K, DRIVE PINION	C6	37	18
TUBE A, BREATHER	C1	26	2	WASHER, ANCHOR PIN	F2	80	4
TUBE B, BREATHER	F11	98	21	WASHER, DRAIN PLUG, 12MM	B12	24	21
TUBE, AIR CLEANER	F11	98	15		D2	52	21
TUBE, AIR CLEANER BREATHER	F11	98	18	WASHER, ENGINE HANGER	G12	125	28
TUBE, AIR VENT	C11	46	27	WASHER, L. SIDE	E10	73	31
TUBE, AIR VENT, 3.5X130	F5	87	5	WASHER, LOCK	C7	39	21
TUBE, BATTERY	F10	96	15				

Description Index

Description	Grid	Page	Ref. No.	Description	Grid	Page	Ref. No.
WASHER, LOCK	E8	69	17	WASHER, 11MM	B10	21	16
WASHER, LOCK, 25MM	C6	37	23		D1	51	7
WASHER, MOUNTING RUBBER	B1	2	6	WASHER, 6MM	B5	11	19
WASHER, OIL BOLT	B2	5	19		F7	91	17
	D1	50	5		G6	113	15
	E5	62	19		G8	116	5
	E6	65	17	WASHER, 6X19	B7	15	16
WASHER, PILLION FOOTPEG	G2	105	18	WASHER, 6X2.3	B12	24	14
WASHER, PLAIN, 5MM	F11	99	30		C7	39	23
WASHER, PLAIN, 6MM	C8	41	27	WASHER, 7MM	B5	11	20
	E3	58	35	WASHER, 8MM	B5	11	18
	F5	86	38		F4	85	26
	F12	101	27	WEIGHT, BALANCE	F1	78	1
	G2	105	24		F3	82	4
	G11	122	38	WHEEL COMP., FR.	F1	78	6
	H4	132	15	WHEEL COMP., RR.	F3	82	3
WASHER, PLAIN, 8MM	E11	75	65	WIRE A, GUARD	C8	40	9
	G2	105	25	WIRE B, GUARD	C8	40	10
WASHER, RR. BRAKE ANCHOR PIN	F2	80	4	WIRE COMP., L. TURN SIGNAL	G7	114	9
WASHER, RR. BRAKE ARM	C1	27	13		G7	115	15
WASHER, RR. COVER GROMMET	B10	21	17	WIRE COMP., R. TURN SIGNAL	G7	114	5
WASHER, SEALING, 6.5X12	B2	5	18		G7	115	13
	C1	27	12	WIRE COMP., TAILLIGHT	G8	116	3
WASHER, SEALING, 6MM	G12	125	27	WRENCH, EYE, 10X12	H1	126	8
WASHER, SHIFT DRUM STOPPER	C7	39	22	WRENCH, EYE, 22MM	H1	127	17
WASHER, SPECIAL	F7	91	16	WRENCH, HEX, 5MM	H1	126	5
WASHER, SPECIAL, 35X40	F4	85	16		H1	126	6
WASHER, SPECIAL, 5MM	E10	72	23	WRENCH, HEX, 8MM	H1	126	7
WASHER, SPECIAL, 6MM	C7	39	24	WRENCH, PLUG	H1	126	4
WASHER, SPECIAL, 8MM	E10	73	51				
	F12	101	23				
WASHER, SPEEDOMETER GEAR	F1	79	11				
WASHER, SPRING, 22MM	B7	15	14				
WASHER, SPRING, 3MM	E3	58	36				
WASHER, SPRING, 4MM	B8	17	19				
	F10	96	19				
WASHER, SPRING, 5MM	B11	22	10				
WASHER, SPRING, 6MM	E3	58	37				
	F10	96	20				
	F12	101	28				
WASHER, SPRING, 8MM	E11	75	66				
WASHER, STEERING STEM	E7	67	16				
WASHER, THRUST	B8	17	13				
WASHER, THRUST, 20X0.85	C6	37	20				
WASHER, THRUST, 20X0.90	C6	37	20				
WASHER, THRUST, 20X0.95	C6	37	20				
WASHER, THRUST, 20X1.00	C6	37	20				
	C6	37	21				
WASHER, THRUST, 20X1.05	C6	37	20				
WASHER, THRUST, 25MM	B7	15	15				
WASHER, THRUST, 25X34	C6	37	19				
WASHER, THRUST, 5MM	B2	5	17				
	B3	7	15				
WASHER, WAVE, 12MM	B4	9	18				