## NUCL 402 Engineering of Nuclear Power Systems

Lecture 16: Global Nuclear Energy Partnership and the Nuclear Fuel Cycle

S. T. Revankar
School of Nuclear Engineering
Purdue University

#### **GNEP – Overview**

- ✓ The Global Nuclear Energy Partnership is a DOE Program that is part of the Advanced Energy Initiative
  - Overriding goal of AEI & GNEP is to produce carbon-free nuclear power
  - This is planned to be accomplished by having nations with secure capabilities to sell fuel services to other nations

These other nations must promise to use fuel only for energy purposes

#### **GNEP - Overview**


#### ✓ Principles of the GNEP

- Expand nuclear power; provide for safe operation of plants and safe management of waste
- Continue to develop nuclear safeguards to ensure nuclear materials are used for peaceful purposes
- Establish safe, reliable global fuel services network while reducing the risk of proliferation
- Develop fast reactors to consume spent fuel to reduce waste
- Develop proliferation resistant reactors to bring nuclear power to developing countries
- Develop technology that would stop separation of plutonium from spent fuel, with the goal of eliminating the world's supply of plutonium

#### **GNEP - Overview**

- **✓ Three primary components:** 
  - Nuclear Fuel Recycling Center (NFRC)
     For separating usable elements from spent fuel
     Also to create actinide rods from these elements for use in the ARR
  - Advanced Recycling Reactor (ARR)
     For burning actinide fuel rods created at NFRC
     This reduces the amount of waste that needs to be stored
  - Advanced Fuel Cycle Research Facility (AFCRF)
     For research on transmutation fuels and continuous improvement of fuel cycles

#### **GNEP - Overview**



Simplified Block Diagram Representing NFRC & ARR


#### **GNEP - Who?**

- ✓ As of Feb. 1, 2008, a total of 20 countries are signatories to the principles of the GNEP:
  - Leaders: United States, China, Russia, Japan, and France
  - Uranium Suppliers: Australia, Kazakhstan, Canada
  - Fuel Service Receivers: Bulgaria, Hungary, Lithuania, Romania, Slovenia, Ukraine, Poland, Ghana, Jordan, South Korea, Italy, Senegal

## **GNEP – Economic Impact**

- ✓ Overriding economic consideration is to keep nuclear energy cost-competitive with other forms of energy
- ✓ Division of labor in US to come from three primary sources:
  - Operation of factilies: Industry
  - Research: Government Funded Laboratories and Universities

## **GNEP – Economic Impact**



## **GNEP – Economic Impact**

- ✓ Total cost estimates for GNEP Research (through 2012):
  - Systems Integration: \$126.3 M
  - Spent Fuel Separation Technology: \$1010.4 M
  - Transmutation Technologies: \$1044.8 M
  - Transmutation Fuels: \$1142.8 M
  - Reactors for Deployment: \$75.5 M
  - Modeling and Simulation: \$462 M
  - University Programs: \$28.5 M
  - Other: \$20.77+ M
- **✓ TOTAL: \$3.91 Billion**

## **GNEP – Environmental Impact**

- ✓ One of the overriding keys of GNEP is to meet the growing world demand for energy without emitting air pollution or greenhouse gases.
- ✓ Waste Reduction
  - Development of Actinide Burning Reactors
  - Utilization of closed-fuel cycles
- ✓ Currently 13 sites are under consideration for all 3 primary structures considered crucial to GNEP to be located in the same place

## **GNEP – Environmental Impact**



Sites Being Considered for Primary Structures

© DOE

## **GNEP – Safety & Security**

- ✓ One of the overriding goals of the GNEP is to increase overall safety of nuclear power
  - Development of proliferation-resistant fuel cycles and reactors
  - Fuel recycling that does not separate pure Plutonium
    - Long term goal of eliminating separation of Plutonium completely and eliminating civilian stockpiles
  - Proliferation risk reduced by limiting the number of countries with access to enrichment and reprocessing plants.

#### Front End and Back End....

The nuclear fuel cycle is the series of industrial processes which involve the production of electricity from uranium in nuclear power reactors

The nuclear fuel cycle, also called nuclear fuel chain, is the progression of nuclear fuel through a series of differing stages.

- ✓ FRONT END: the preparation of the fuel, steps in the service period in which the fuel is used during reactor operation, and
- ✓ BACK END: safely manage, contain, and either reprocess or dispose of spent nuclear fuel.
- If spent fuel is not reprocessed, the fuel cycle is referred to as a open fuel cycle (or a once-through fuel cycle). If the spent fuel is reprocessed, it is referred to as a closed fuel cycle.

#### **Fuel Cycle**

<sup>235</sup>U –naturally available

$${}^{232}_{90}Th + n \rightarrow {}^{233}_{90}Th^* \xrightarrow{\beta} {}^{233}_{91}Pa \xrightarrow{\beta} {}^{233}_{92}U$$


$${}^{238}_{92}U + n \rightarrow {}^{239}_{92}U^* \xrightarrow{\beta} {}^{239}_{93}Np \xrightarrow{\beta} {}^{239}_{94}Pu$$


#### **Sources of Uranium**


4 ppm on earths crust contain U
Relatively high grade ore (1-4%) in
Zaire and Canada –primary minerals
picthblend and uraninite

$$xUO_2 \cdot yUO_3$$
;  $0 < y / x < 2$ 

Medium grade (0.1 to 0.5%) in US, Canada, Australia, Gabon, South Africa Sea water →3 ppb U









# Fuel Cycles Once Through Fuel Cycle

Amount of fuel wasted- 90 to 95% of nuclear

waste could be re-processed and used as fuel. (EIR Science & Technology)

#### Constituents of Spent Nuclear Fuel





US-Colorado Plateau (Arizona, Colorado, New Mexico and Utah) and Wyoming (0.1 to 0.5%) Minerals

Carnotite: (K<sub>2</sub>O<sub>2</sub> UO<sub>3</sub> V<sub>2</sub>O<sub>5</sub> xH<sub>2</sub>O) and Autunite: (CaO 2UO<sub>3</sub> P<sub>2</sub>O<sub>5</sub> xH<sub>2</sub>O)

#### **Uranium Milling and Processing to UO<sub>2</sub>**

Average ore in US contain 0.2 to 0.25% of U<sub>3</sub>O<sub>8</sub>

Ore is leached with sulfuric acid to dissolve out uranium

Solvent extraction or ion-exchange procedure to obtain uranium

oxide –yellow cake (75 to 80% U<sub>3</sub>O<sub>8)</sub>

Yellow cake is treated with ammonia to give ammonium diurinate (NH<sub>4</sub>)<sub>2</sub>U<sub>2</sub>O<sub>7</sub>

This is then fed to fluidized bed to crack ammonia at 540-640C producing UO<sub>2</sub> brown oxide.

Hydroflorination fluidized bed reaction



 $UF_4+F_2\rightarrow UF_6$  (hexafluoride) sent to enrichment facility

UO<sub>2</sub> is then obtained from UF<sub>6</sub> by hydrolyzing with water and then treating with ammonia to get ammonia diurinate and crack ammonia

S. T. Revankar-16-19

#### **Enrichment**

Natural uranium consists, primarily, of a mixture of two isotopes (atomic forms) of uranium. Only 0.7% of natural uranium is "fissile", or capable of undergoing fission, the process by which energy is produced in a nuclear reactor. The fissile isotope of uranium is uranium 235 (U-235). The remainder is uranium 238 (U-238).

In the most common types of nuclear reactors, a higher than natural concentration of U-235 is required. The enrichment process produces this higher concentration, typically between 3.5% and 5% U-235. This is done by separating gaseous uranium hexafluoride into two streams, one being enriched to the required level and known as low-enriched uranium. The other stream is progressively depleted in U-235 and is called 'tails'.

Two enrichment processes exist in large scale commercial use, each uses UF<sub>6</sub> as feed: gaseous diffusion and gas centrifuge. They both use the physical properties of molecules, specifically the 1% mass difference, to separate the isotopes. The product of this stage of the nuclear fuel cycle is enriched uranium hexafluoride, which is reconverted to produce enriched uranium oxide.

S. T. Revankar-16-20

#### **Gaseous Diffusion**

Different rates at which gases of different molecular weight diffuse through a porous barriers.

Pore size < mean free path of the molecules

Average pore dia 0.05 µm; 106 pores /mm<sup>2</sup>


UF<sub>6</sub> is solid at room temp and sublimates to vapor at 56.4C

KE= 1/2Mv<sup>2</sup>; if M is different then v will be different if KE is same.

For mixture vof gases at uniform temperature KE is same

$$\frac{M_H v_H^2}{2} = \frac{M_L v_L^2}{2}; \alpha^* = \frac{v_L}{v_H} = \sqrt{\frac{M_L}{M_H}}$$
 Theoretical Separation factor 
$$\alpha = \frac{a/(1-a)}{b/(1-b)}$$
 Stage separation factor

a and b are weight fraction or assay of U235 in enriched and depleted stream respectively α≈1.003 <α\* (1.0043)



LOW PRESSURE


Number of cascade

stages in cascade 
$$= (\frac{2}{\alpha - 1}) \ln \frac{x_p / (1 - x_p)}{x_w / (1 - x_w)}$$

Where  $x_p$  and  $x_w$  are final assay of U235 in enriched and depleted stream respectively.

Example:  $x_p=3\%$  and  $x_w=0.3\%$ 

Number of cascade =1100.



S. T. Revankar-16-22

#### **Gas Centrifuge**


**Principle:** Heavier gas molecules move towards the periphery and the lighter ones tend to remain in the center.

In a force field at equilibrium the gas distribution is  $n = n_0 \exp(-E/RT)$ 

 $n_0$  is concentration of molecule at filed =0, E= -1/2Mv<sup>2</sup>—the potential energy at distance d from axis where concentration is n.

The separation factor

$$\alpha = \frac{n_{L(0)} / n_{H(0)}}{n_L / n_H} = \exp[(M_H - M_L)v^2 / 2RT]$$




Gas Centrifuge



S. T. Revankar-16-24

#### **Material Balance in Separative Work**



For U235 fraction  $x_F M_F = x_P M_P + x_T M_T$ 

So U feed per unit product

$$\frac{M_F}{M_P} = \frac{x_P - x_T}{x_F - x_T}$$

For natural uranium  $x_F = 0.00711$  and for US enrichment facility  $x_T = 0.002$ , Thus  $M_F$  is directly proportional to  $x_P$ . At enrichment  $x_P$  the mass U235 is  $M_{235} = x_P M_P$ , then

$$M_F = (\frac{x_P - x_T}{x_F - x_T}) \frac{M_{235}}{x_P} \approx \frac{M_{235}}{x_F - x_T} = 196M_{235}$$

#### **Cost in Separation**

The cost of enrichment is described in terms of a special unit called *the separative work unit*. Separative work can be expressed in terms of a function V(x) a value function for assay x 1-x

 $V(x) = (1 - 2x) \ln(\frac{1 - x}{x})$ 

The effort expended: Separative work unit (SWU)

$$SWU = M_P V(x_P) + M_T V(x_T) - M_F V(x_F)$$
  

$$SWU(kg) = M_P [V(x_P) - V(x_T)] - M_F [V(x_F) - V(x_T)]$$

If C<sub>s</sub> is cost of a separative work unit in \$/kg

$$M_{P}C_{P} = SWUC_{S} + M_{F}C_{F} - M_{T}C_{T}$$

$$C_{P} = \frac{SWU}{M_{P}}C_{s} + \frac{M_{F}}{M_{P}}C_{F} - \frac{M_{T}}{M_{P}}C_{T}$$




Fig. 4.33 Feed and separative work, in kg, as a function of product enrichment.




Fig. 4.35 Feed and separative work, in kg, as a function of tails enrichment.

# Fuel Cycles (Nuclear Resource utilization)

**Definition-** The extent to which the world's nuclear resources are used compared to the extent to which they could be effectively used.

Reactor	%fissile in	% fissile out	% Fissile Material Used			
Light Water Reactor	3.5%	1.5%	57% (Rouben)			
CANDU Reactor	.71%*	.5%*	30% (Rouben)*			
Gas Cooled Reactor	8%	4-4.72%	41-50% (Argon)			
Breeder Reactor	Ratio of creation to burn up "use" (.95-1.05) (Hitachi)					

<sup>\*</sup>These percentages are based on CANDU core loaded with natural uranium


### **Fuel Cycles**

(Resource Limitation)

Resource limitation factor: As the price of uranium increases, the amount that can be mined profitably increases.

U.S. Forward-Cost Uranium Reserves by State, December 31, 2003									
	\$30 per pound			\$50 per pound					
State(s)	Ore (million tons)	Grade <sup>a</sup> (percent U <sub>3</sub> O <sub>8</sub> )	U <sub>3</sub> O <sub>8</sub> (million pounds)	Ore (million tons)	Grade <sup>a</sup> (percent U <sub>3</sub> O <sub>8</sub> )	U <sub>3</sub> O <sub>8</sub> (million pounds)			
Wyoming	41	0.129	106	238	0.076	363			
New Mexico	15	0.280	84	102	0.167	341			
Arizona, Colorado, Utah	8	0.281	45	45	0.138	123			
Texas	4	0.077	6	18	0.063	23			
Other <sup>b</sup>	6	0.199	24	21	0.094	40			
Total	74	0.178	265	424	0.105	890			

 $<sup>^{\</sup>rm 3}\! \text{Weighted}$  average percent  $\text{U}_3\text{O}_8$  per ton of ore.



blincludes California, Idaho, Nebraska, Nevada, North Dakota, Oregon, South Dakota, and Washington.