
## Part A

### CHAPTER 3

# Architecture and Organization



Alan Clements

1

These slides are provided with permission from the copyright for CS2208 use only. The slides must not be reproduced or provided to anyone outside the class.

All downloaded copies of the slides are for personal use only. Students must destroy these copies within 30 days after receiving the course's final assessment.



#### **Example 1: Calculating the Absolute Value**

- □ To calculate  $x \leftarrow |x|$ , where x is a signed integer, we can implement if x < 0 then x = -x
- ☐ In ARM

```
TEQ r0, #0 ; compare r0 with zero

RSBMI r0, r0, #0 ; if negative (MInus) r0 \leftarrow 0 - r0
```

- ☐ What is the difference between TEQ and CMP? •
- ☐ What is the difference between RSBMI and RSBLT? • •
- ☐ Can we use RSBMI ro, #0 instead of RSBMI ro, ro, #0 ?
- ☐ Can we use NEGMI ro, ro instead of RSBMI ro, ro, #0 ?


To know the answer, read slide #59

To know the difference, read slide #72

To know the difference, read slide #83

To know the answer, read slide #59

□ Suppose we have r0, r1, and r2 as follow:



and we want to rearrange r2 as follow:

r2

Note that: we can not do:
BIC r2, r2, #0xffff0000
To know the reason, read
Slides 105-110

```
AND r0, r0, #0xFF

AND r1, r1, #0xFF

BIC r2, r2, #0xFF0000


BIC r2, r2, #0xFF000000

ADD r2, r2, r1, LSL#16


ADD r2, r2, r0, LSL#24
```

```
; clear all high order 3 bytes
; clear all high order 3 bytes
; clear the 3rd byte
; clear the 4th byte
; LSL r1 by 2 bytes & add it to r2
; LSL r0 by 3 bytes & add it to r2
```

Can we use ORR instead of ADD in this situation?




□ Suppose we have r0, r1, and r2 as follow:



#### □ Another solution in 5 instructions


```
AND r0, r0, #0xFF ; clear r0 all high order 3 bytes AND r1, r1, #0xFF ; clear r1 all high order 3 bytes ADD r2, r1, r2, LSL#16 ; LSL r2 by 2 bytes & add r1 to it ADD r2, r2, r0, LSL#8 ; LSL r0 by 1 byte & add it to r2 MOV r2, r2, ROR#16 ; Swap the two r2 16 bits together
```


Can we use ORR instead of ADD in this situation?



#### Example 3: Byte Reversal (Big-endian 🖨 Little-endian)

- ☐ Suppose that **Oxab** CD EF GH is stored in r0
- We want to reverse the content of r0,i.e., store 0xGH EF CD AB in r0
- ☐ Let us review the XOR truth table
  - x ⊕ x = 0
  - X ⊕ 0 = X
  - $\blacksquare$   $x \oplus y \oplus y = x$





☐ We will use r1 as a working register

```
EOR \mathbf{r1}, r0, r0, ROR#16 ; A\oplusE, B\oplusF, C\oplusG, D\oplusH, E\oplusA, F\oplusB, G\oplusC, H\oplusD BIC \mathbf{r1}, r1, #0x00FF0000 ; A\oplusE, B\oplusF, 0, 0, E\oplusA, F\oplusB, G\oplusC, H\oplusD MOV \mathbf{r0}, r0, ROR#8 ; G, H, A, B, C, D, E, F EOR \mathbf{r0}, r0, r1, LSR#8 ; r1 after LSR#8 is
```

Α	В	$C = A \oplus B$
0	0	0
0	1	1
1	0	1
1	1	0

```
; G , H , A , B , C , D , E , F

;rl after LSR#8 is

; O , O ,A⊕E,B⊕F, O , O ,E⊕A,F⊕B

;The final result will be

;G⊕O,H⊕O,A⊕A⊕E,B⊕B⊕F,C⊕O,D⊕O,E⊕E⊕A,F⊕F⊕B

; G , H ,E ,F ,C ,D ,A ,B
```

#### **Example 4: Variable Swapping**

- ☐ Assume that we have two variables stored in **r0** and **r1**
- ☐ We wants to swap these two variables

```
[r2] \leftarrow [r0]
[r0] \leftarrow [r1]
[r1] \leftarrow [r2]
```

 $\square$  Now, we want to do the same thing without using  $r^2$ 

The red values are the originals. \_\_\_

150

 $C = A \oplus B$ 

#### **Example 4: Variable Swapping**

- ☐ Assume that we have two variables stored in **r0** and **r1**
- ☐ We wants to swap these two variables

```
[r2] \leftarrow [r0]
[r0] \leftarrow [r1]
[r1] \leftarrow [r2]
```

- $\square$  Now, we want to do the same thing without using r2
- □ Another solution

Let us review the XOR truth table

```
■ x ⊕ x = 0
```

$$\blacksquare$$
  $\times$   $\oplus$   $0 = \times$ 

$$\mathbf{x} \oplus \mathbf{y} \oplus \mathbf{y} = \mathbf{x}$$

The red values are the originals.

```
EOR r0, r0, r1 ; [r0] \leftarrow [r0] \oplus [r1].

EOR r1, r0, r1 ; [r1] \leftarrow [r0] \oplus [r1] ; [r1] \leftarrow ([r0] \oplus [r1]) \oplus [r1] ; [r1] \leftarrow [r0] \oplus [r1] ; [r0] \leftarrow [r0] \oplus [r1] ; [r0] \leftarrow ([r0] \oplus [r1]) \oplus [r0] ; [r0] \leftarrow [r1] ; [r0] \leftarrow [r1]
```

 $X \leftarrow X \oplus Y$ 

$$Y \leftarrow X \oplus Y$$

XThis stide iX m bied Yersion of the original author's slide (A. Clements) and is used with permission. All new contents added are copyrighted by © Mahmoud R. El-Sakka

#### Example 5: Multiplication by $2^n$ - 1, $2^n$ , or $2^n$ + 1

- ☐ Multiplying by 2<sup>n</sup> can be implemented using MOV instruction and LSL#n
- ☐ Example:

Write one ARM instruction to store  $r1 \times 16$  into r2

MOV **r2**, r1, LSL#4 ; [r2]  $\leftarrow$  [r1]  $\times$  2^4

- ☐ Multiplying by 2<sup>n</sup> + 1 can be implemented using ADD instruction and LSL#n
- ☐ Example

Write one ARM instruction to store  $r1 \times 17$  into r2

ADD **r2**, r1, r1, LSL#4 ; [r2]  $\leftarrow$  [r1] + [r1] × 2^4

- ☐ Multiplying by 2<sup>n</sup> 1 can be implemented using RSB instruction and LSL#n
- ☐ Example

Write one ARM instruction to store  $r1 \times 15$  into r2

RSB **r2**, r1, r1, LSL#4; [r2] $\leftarrow$ [r1] × 2^4 - [r1]

#### Example 5: Multiplication by $2^n - 1$ , $2^n$ , or $2^n + 1$

☐ Let us translate the following C code

```
if(x > y)
  p = 17 * q;
else
{ if(x == y)
    p = 16 * q;
  else /* i.e., x < y */
    p = 15 * q;
}</pre>
```

☐ Assume that x and y are stored in r2 and r3, and also that p and q are r4 and r1

```
CMP r2, r3 ;Compare x and y  ADDGT r4, r1, r1, LSL#4 ; IF >, then p \leftarrow q + q << 4 \\ MOVEQ r4, r1, LSL#4 ; IF =, then p \leftarrow q << 4 \\ RSBLT r4, r1, LSL#4 ; IF <, then p \leftarrow q << 4 - q
```

r4 not r1

Not correct in the book page 200

#### Example 6: Dividing by D

- ☐ Dividing by **D** can be implemented using MUL and ASR instructions
- ☐ Example:

Write ARM instructions to divide r0 by D and store the result in r1 i.e.,  $[r1] \leftarrow [r0] / D$ 

☐ The result can be written as:

```
[r0] / D = [r0] \times (1 / D)
= [r0] \times (2^N/D) / 2^N
```

- ✓ Select N to be a large integer at the same time not to cause an overflow when evaluating [r0] × (2^N/D)
- ✓ Evaluate [r0] × (2^N/D)
- ✓ Arithmetic shift right the result N time

```
\square If D = 5 and r0 = 32004, we can pick N = 16
```

$$\square$$
 2^N / D = 2^16 / 5 = 1024 × 64 / 5 = 13107.2

round(13107.2) = 13107

Note that 13107 / 2<sup>16</sup> = 0.199997 ≈ 0.2

LDR **r2**,=13107; (2^N/D)

MUL r1, r2, r0;  $[r0] \times (2^N/D)$ 

ASR r1, #16 ;  $[r0] \times (2^N/D) / 2^N = [r0] / D$ 

This slide is a modified version of the original author's slide (A. Clements) and is used with permission. All new contents added are copyrighted by © Mahmoud R. El-Sakka

#### Example 7: Converting Capital Letter Small Letter

- ☐ Let us convert any capital letter to small letter
- ☐ Capital letters begins by 'A' and end by 'Z'
- $\square$  Assume that the character to be converted in r0; and r1 is a working register

```
CMP r0, #'A' ; Is it in the range of the capital?

RSBGES r1, r0, #'Z' ; If >= 'A',


; then check with 'Z'

; and update the flags

ORRGE r0, r0, #2_100000 ; If between 'A' and 'Z' inclusive,

; then set bit 5 to force lower case
```

# Another solution CMP r0, #'A' BLT DONE CMP r0, #'Z' BGT DONE ORR r0, r0, #2\_100000 Make the conversion Can be ADD r0, r0, #32



This slide is a modified version of the original author's slide (A. Clements) and is used with permission. All new contents added are copyrighted by © Mahmoud R. El-Sakka


#### Example 8: If Statement in One Instruction!!

☐ Let us translate the following C code

$$if(x < 0)$$
  
  $x = 0;$ 

- □ Assume that x is stored in r0

  BIC **r0**, r0, r0, ASR#31; only one instruction!!
- ☐ ASR#31 will fill all bits of r0 with the sign bit
  - o If positive, the result will be 0x00000000



#### **Example 9: Simple Bit-level Logical Operations**

- □ Assume #2\_0000 0000 0000 0000 0000 0000 0000 **pqrs** is stored in r0
- ☐ We wish to implement the following statement

```
if ((p == 1) && (r == 1))

s = 1;
```

```
TST r0,#0x8 ; check the value of bit p TSTNE r0,#0x2 ; if p == 1, ; check the value of bit r ORRNE r0,r0,#1 ; if r == 1, ; set s \leftarrow 1
```

In this situation, you can not replace the ORRNE by ADDNE as soriginally might be 1.

#### **Example 10: Hexadecimal Character Conversion**

```
☐ We would like to convert 4 binary bits to hexadecimal digits
                                                                     0000 - '0'
Assume that these 4 bits are stored at the LSBs of r0 and
  the rest of the bits are zeros
                                                                     0010 - 12'
□ Note that the ASCII code of
    o '0' is 48, i.e., 0 \times 30 (difference from 0000_2 is = 0 \times 30)
       '1' is 49, i.e., 0 \times 31 (difference from 0001_2 is = 0 \times 30)
                                                                               15/
                                                                               16'
       '9' is 57, i.e., 0 \times 39 (difference from 1001_2 is = 0 \times 30)
☐ Note also that the ASCII code of
                                                                               187
    o 'A' is 65, i.e., 0 \times 41 (difference from 1010_2 is = 0 \times 37)
                                                                               191
       'B' is 66, i.e., 0 \times 42 (difference from 1011_2 is = 0 \times 37)
                                                                     1010 →
                                                                               \A'
    0
      . . .
                                                                     1011 →
                                                                               'B'
       'F' is 70, i.e., 0 \times 46 (difference from 1111_2 is = 0 \times 37)
                                                                               'C'
                                                                     1100 <del>></del>
☐ The conversion algorithm is:
                                                                               'D'
  character = the4BitBinaryValue + 0x30
                                                                                'E'
                                                                     1110
     if(character > 0x39)_
                                    ADDGT not ADDGE
                                                                                √F.√
                                                                     1111 -
        character += 7 Not correct in the book page 202
       r0, r0, #0x30; add 0x30 to convert 0 through 9 to ASCII
ADD
                                                                                157
     r0, #0x39; check for A to F hex values
CMP
ADDGT r0, r0, #7 ; If A to F, then add 7 to get the ASCII
```

This slide is a modified version of the original author's slide (A. Clements) and is used with permission. All new contents added are copyrighted by © Mahmoud R. El-Sakka.

#### **Example 10: Hexadecimal Character Conversion**

```
☐ We would like to convert 4 binary bits to hexadecimal digits
                                                                      0000 - '0'
Assume that these 4 bits are stored at the LSBs of r0 and
  the rest of the bits are zeros
□ Note that the ASCII code of
    o '0' is 48, i.e., 0 \times 30 (difference from 0000_2 is = 0 \times 30)
       '1' is 49, i.e., 0 \times 31 (difference from 0001_2 is = 0 \times 30)
                                                                                151
                                                                                16'
       '9' is 57, i.e., 0 \times 39 (difference from 1001_2 is = 0 \times 30)
☐ Note also that the ASCII code of
                                                                                \8/
    o 'A' is 65, i.e., 0 \times 41 (difference from 1010_2 is = 0 \times 37)
                                                                                191
       'B' is 66, i.e., 0 \times 42 (difference from 1011_2 is = 0 \times 37)
                                                                                \A'
    0 ...
                                                                                'B'
       'F' is 70, i.e., 0 \times 46 (difference from 1111_2 is = 0 \times 37)
                                                                                'C'
                                                                      1100 <del>></del>
☐ Another algorithm
                                                                                'D'
  using conditional operator (i.e., ?:)
                                            variable = Expression1 ? Expression2 : Expression3
                                                                      1110
                                                                                 \E/
  → म• /
                                                                      1111 -
        +(the4BitBinaryValue \leq 0x9)? 0x30 : 0x37;
CMP r0, #0x9
                   ; is it 0-9 or A-F hex values?
                                                                                 158
ADDLE r0, r0, \#0x30; if it is 0-9, add 0x30 to convert to ASCII
ADDGT r0, r0, #0x37; if it is A-F, add 0x37 to convert to ASCII
```

This slide is a modified version of the original author's slide (A. Clements) and is used with permission. All new contents added are copyrighted by © Mahmoud R. El-Sakka

#### **Example 11: Multiple Selection**


```
☐ Let us translate the following C code
     switch (i)
     { case 0: do action; break;
       case 1: do action; break;
       case N: do action; break;
       default: do something;
Assume that r0 contains the selector i
          TEQ r0, \#0; is the switch variable == 0?
          BEQ case0 ; If i == 0, jump to the case0 code
          TEQ r0, \#1; is the switch variable == 1?
          BEQ case1 ; If i == 1, jump to the case1 code
          TEQ r0, \#N; is the switch variable == N?
          BEQ caseN ; If i == N, jump to the caseN code
          B default
          do action of case 0
case0
          B AfterCase
case1
          do action of case 1
          B AfterCase
          do action of case N
caseN
          B AfterCase
default do action of default
AfterCase
```

#### Example 12: Finding the Longest Sequence of Repeated Digits

☐ In Chapter one, we attempted to find the longest sequence of repeated digits.

FIGURE 1.7

A string of digits



- ☐ Let us revisit this problem and implement the solution using ARM assembly language.
- ☐ If you recall, we proposed 13 steps to solve this problem:
  - 1. Read the first digit in the string and call it New\_Digit
  - 2. Set the Current\_Run\_Value to New\_Digit
  - 3. Set the Current\_Run\_Length to 1
  - 4. Set the Max Run to 1
  - 5. REPEAT
  - 6. Read the next digit in the sequence (i.e., read a New\_Digit)
  - 7. IF its value is the same as Current\_Run\_Value
  - 8. THEN Current\_Run\_Length = Current\_Run\_Length + 1
  - 9. ELSE {Current\_Run\_Length = 1
  - 10. Current\_Run\_Value = New\_Digit}
  - 11. IF Current\_Run\_Length > Max\_Run
  - 12. THEN Max\_Run = Current\_Run\_Length
  - This slide is 13. UNTIL The last digit is read

#### Example 12: Finding the Longest Sequence of Repeated Digits

```
AREA
                RunLength, CODE, READONLY
                                                       FIGURE 1.7
                                                                A string of digits
        ENTRY
                                                                          String of 17 digits
                                                              23277366664792211
        ADR
               r9, String; r9 points to the sting
        LDRB
              r0, EoS ; r0 is the EoS symbol
                                                                  Run of four consecutive
              r1, [r9], #1 ; Step-01: r1 is New Digit
        LDRB
                                                                  digits with the same value
                                                                                  digits with the same value @
              r2, r1 ;Step-02: r2 is the Current_Run_Value
        MOV
              r3,#1 ;Step-03: r3 is the Current_Run_Length (set to 1)
        MOV
        MOV \mathbf{r4}, #1 ;Step-04: r4 is the Max Run Length (set to 1)
Repeat LDRB r1, [r9], #1; Step-05 & 06: REPEAT: Read next digit (i.e., New Digit)
              r1,r2
                      ;Step-07: Compare New Digit and Current Run Value
        CMP
        ADDEO r3, r3, #1 ;Step-08: IF same THEN Current Length=Current Length+1
        MOVNE r3, #1
                          ;Step-09:
                                                 ELSE Current Run Length = 1
        MOVNE r2, r1
                                                       Current Run Value = New Digit
                          ;Step-10:
              r3,r4
                           ;Step-11: IF Current Run Length > Max Run
        CMP
                           ;Step-12: THEN Max Run = Current Run Length
        MOVGT r4, r3
                           ;Step-13: Testing the end of string
        TEO
              r0,r1
        BNE Repeat
                           ;Step-13: UNTIL all digits tested
                           ;parking loop
       B Park
Park
String DCB 2,3,2,7,7
                                Read the first digit in the string and call it New Digit
        DCB 3, 6, 6, 6, 6, 4
                                Set the Current_Run_Value to New_Digit
        DCB 7,9,2,2,1
                                Set the Current_Run_Length to 1
                                Set the Max_Run to 1
        DCB 0xFF
EoS
                           5.
                                REPEAT
        END
                           6.
                                     Read the next digit in the sequence (i.e., read a New_Digit)
                           7.
                                     IF its value is the same as Current_Run_Value
                           8.
                                         THEN Current_Run_Length = Current_Run_Length + 1
                                                                                       161
                           9.
                                         ELSE {Current_Run_Length = 1
                                              Current Run Value = New Digit
                           10.
                                     IF Current_Run_Length > Max_Run
                           11.
                           12.
                                         THEN Max Run = Current Run Length
                                UNTIL The last digit is read
 This slide is a modified version of the original aut 13.
                                                                                     R. El-Sakka
```