2η Σειρά Ασκήσεων Συστήματα Μικροϋπολογιστών

Βερέμης Αλέξανδρος 03115063 Σπυρίδων Κρητικός 03116133

1^η Άσκηση:

PART_A:

; DISABLE MEMORY PROTECTION TN 10H LXI H,0900H ;START OF MEMORY STORAGE MVI B,00H ;SET INITIAL VALUES TO B

MVI A,00H ;AND A

NUMS_IN_MEM:

; B HAS THE APPROPRIATE NUMBER TO BE MOV M,B

;STORED

;IF A == 0, THEN 256 HAVE BEEN INR A ;ASSIGNED TO MEMORY AND PART_A IS ;FINISHED, PART_B STARTS CPI 00H

JZ PART_B

INX H ;ELSE "POINT" TO THE NEXT MEMORY

;STORAGE POSITION

;B += 1, NEXT APPROPRIATE NUMBER INR B

JMP NUMS_IN_MEM

PART_B:

LXI H,0900H MVI B,00H MVI C,00H

;D TELLS HOW MANY BITS HAVE BEEN MVI D,08H

; CHECKED UNTIL NOW

COUNT_ONES:

MOV A,M ; READ NUMBER FROM MEMORY

CHECK_BIT:

MOV E,A ; E IS USED AS A TEMPORARY VARIABLE MOV A,D ; IF ALL BITS OF CURRENT NUMBER

CPI 00H ; HAVE BEEN CHECKED THEN JZ CHECK_NEXT CHECK NEXT NUMBER

MOV A,E ;ELSE

RAL ; CHECK NEXT BIT THROUGH CARRY

DCR D ONE LESS BIT TO CHECK

JNC CHECK_BIT ; IF CURRENT BIT != 1 CHECK NEXT INX B ;ELSE, BC += 1, INCREASE NUMBER OF

;ONES

JMP CHECK_BIT

CHECK_NEXT:

INX H ; "POINT" TO THE NEXT MEM POSITION ; CHECK IF ALL NUMBERS HAVE BEEN MOV A,H

CPI OAH ;READ

JZ PART_C ; IF THEY HAVE, PART_C STARTS ;ELSE CHECK NEXT NUMBER MVI D,08H

JMP COUNT_ONES

PART_C:

LXI H,0900H MVI D,00H

IN_RANGE:

; READ NUMBER FROM MEMORY MOV A,M

CPI 10H ; IS LESS THAN 10H? JC LOOK_NEXT ;YES, CHECK NEXT NUMBER
CPI 60H ;IS GREATER THAN 60H?
JNC LOOK_NEXT ;YES, CHECK NEXT NUMBER

INR D ; NO, D += 1, INCREASE NUMBER OF

; DESIRED NUMBERS

LOOK_NEXT:

INX H ; "POINT" TO THE NEXT NUMBER TO LOOK MOV A, H ; CHECK IF ALL NUMBERS HAVE BEEN

CPI OAH ;READ

JZ END_PROGRAM ; IF THEY HAVE, THE PROGRAM ENDS

END_PROGRAM:

END

2^η Άσκηση:

MOV D,FFH MOV A,D

STA 3000H ;Initially, lights are off MVI E,96H ;E = 150 (counter for 30sec)

LXI B,00C8H ;BC = 200ms

INIT:

CALL GET_MSB

CPI 00H ; Wait for first OFF

JZ OFF1

CALL DELB ; If it's not yet OFF, wait until it comes

JMP INIT

OFF1:

CALL GET_MSB

CPI 80H ;Wait for first ON after OFF

JZ ON1 CALL DELB JMP OFF1

ON1:

CALL GET_MSB

CPI 00H ; Wait for second OFF

JZ OFF2 CALL DELB JMP ON1

OFF2:

CALL GET_MSB

CPI 01H

JZ ON2 ;Wait for second ON

CALL TOGGLE ; If not second ON, toggle lights

CALL DELB

DCR E ;Decrease timer by 200ms

MOV A,E

CPI 00H ; If 30 secs have not passed

JNZ OFF2 ;Repeat

CALL TURN_OFF ;Else turn off the lights
JMP OFF1 ;And go to OFF1 routine

ON2:

CALL GET_MSB

CPI 00H ;Wait for third OFF

JZ OFF3 ;On third OFF, go to OFF3

CALL TOGGLE ;Else toggle lights

CALL DELB ;delay routine

DCR E ;Same as OFF2

MOV A,E CPI FFH JNZ ON2

CALL TURN_OFF

JMP OFF1

OFF3:

MVI E,96H Reset counter to 30sec

JMP OFF2 ;Go to OFF2 Again

TOGGLE:

;Toggle lights MOV A,D

CMA ;Αντιστροφή των ψηφίων για να αναψουν όλα τα φώτα

MOV D,A STA 3000H

RET

TURN_OFF:

;Turn off lights MVI A, FFH

STA 3000H

RET

GET_MSB:

LDA 2000H Get MSB from dip switches;

ANI 80H RET

3^η Άσκηση:

EXERCISE_I:

START:

LDA 2000H ; READ INPUT

;CHECK BIT7 RAL

JC TURN_1 ;IF BIT7 = 1 THEN TURN ON 1 LED

RAL ;CHECK BIT6

RAL JC TURN_2 ; IF BIT6 = 1 THEN TURN ON 2 LEDS

RAL ;CHECK BIT5

JC TURN_3 ; IF BIT5 = 1 THEN TURN ON 3 LEDS

RAL ;CHECK BIT4

; CHECK BIT3 RAL

JC TURN_5 ; IF BIT3 = 1 THEN TURN ON 5 LEDS

RAL ;CHECK BIT2

JC TURN_6 ; IF BIT2 = 1 THEN TURN ON 6 LEDS

; CHECK BIT1 RAL

JC TURN_7 ; IF BIT1 = 1 THEN TURN ON 7 LEDS

;CHECK BIT0 RAL

; IF BITO = 1 THEN TURN ON 8 LEDS JC TURN_8

MVI A, FFH STA 3000H JMP START

TURN_8:

MVI A,00H ; ALL DIGITS HAVE TO BE ZERO IN ORDER TO TURN ON ALL THE LEDS

STA 3000H JMP START

TURN_7:

MVI A,01H

```
STA 3000H
             JMP START
TURN_6:
             MVI A,03H ; THE DIGITS THAT ARE NOT ZERO DO NOT TURN ON THE EQUIVALENT
LEDS
             STA 3000H
             JMP START
TURN_5:
             MVI A,07H
             STA 3000H
             JMP START
TURN_4:
             MVI A, OFH
             STA 3000H
             JMP START
TURN_3:
             MVI A,1FH
             STA 3000H
             JMP START
TURN_2:
             MVI A,3FH
             STA 3000H
             JMP START
TURN_1:
             MVI A,7FH
             STA 3000H
             JMP START
             END
EXERCISE_II:
START:
      CALL KIND
                         ;READ KEYBOARD
      CPI 01H
      JZ TURN_1
                          ;TURN ON LED 1
      CPI 02H
      JZ TURN_2
                          ;TURN ON LED 2
      CPI 03H
      JZ TURN_3
                          ;TURN ON LED 3
      CPI 04H
      JZ TURN_4
                          ;TURN ON LED 4
      CPI 05H
      JZ TURN_5
                          ;TURN ON LED 5
      CPI 06H
      JZ TURN_6
                          ;TURN ON LED 6
      CPI 07H
      JZ TURN_7
                          ;TURN ON LED 7
      CPI 08H
      JZ TURN_8
                          ;TURN ON LED 8
      MVI A, FFH
      STA 3000H
      JMP START
TURN_1:
      MVI A, FEH
      STA 3000H
      JMP START
TURN_2:
      MVI A,FDH
      STA 3000H
```

```
JMP START
TURN_3:
      MVI A, FBH
      STA 3000H
      JMP START
TURN_4:
      MVI A,F7H
      STA 3000H
      JMP START
TURN_5:
      MVI A, EFH
      STA 3000H
      JMP START
TURN_6:
      MVI A,DFH
      STA 3000H
      JMP START
TURN_7:
      MVI A, BFH
      STA 3000H
      JMP START
TURN_8:
      MVI A,7FH
      STA 3000H
      JMP START
      END
EXECISE_III:
      IN 10H
                           ; DISABLE MEMORY PROTECTION
      LXI H, OAO2H
                          ; "POINT" TO MEMORY 0A02H
      MVI M,10H
                          ;STORE NOTHING TO "PRINT"
                          ; POINT TO THE NEXT MEMORY CELL 0A03H
      INX H
                          ;STORE NOTHING TO "PRINT"
      MVI M,10H
                          ;POINT TO THE NEXT MEMORY CELL 0A04H;STORE NOTHING TO "PRINT"
      INX H
      MVI M,10H
                          ; POINT TO THE NEXT MEMORY CELL 0A05H
      INX H
      MVI M,10H
                          ;STORE NOTHING TO "PRINT"
START:
LINE_0:
                          ;LINE INSTR STEP, FETCH PC, HRDWR STEP
      MVI A, FEH
      STA 2800H
                          ; READ LINE
      LDA 1800H
                          ; READ COLUMNS
      ANI 07H
                          ;SET THE 5 MSB'S = 0
      MVI C,86H
      CPI 06H
                          ; INSTR STEP
      JZ DISPLAY
      MVI C,85H
      CPI 05H
                           FETCH PC
      JZ DISPLAY
      MVI C,F7H
      CPI 03H
                           ;HRDWR STEP
      JZ DISPLAY
LINE_1:
                          ;LINE RUN, FETCH REG, FETCH ADRS
      MVI A,FDH
      STA 2800H
                          ; READ LINE
      LDA 1800H
                           ; READ COLUMNS
```

```
ANI 07H
                         ;SET THE 5 MSB'S = 0
      MVI C,84H
      CPI 06H
                          ;RUN
      JZ DISPLAY
      MVI C,80H
      CPI 05H
                          ;FETCH REG
      JZ DISPLAY
      MVI C,82H
      CPI 03H
                         ;FETCH ADRS
      JZ DISPLAY
LINE_2:
                          ;LINE 0, STORE/INCR, DECR
      MVI A, FBH
      STA 2800H
                         ; READ LINE
      LDA 1800H
                         ; READ COLUMNS
      ANI 07H
                         ;SET THE 5 MSB'S = 0
      MVI C,00H
                         ;0
      CPI 06H
      JZ DISPLAY
      MVI C,83H
                         ;STORE/INCR
      CPI 05H
      JZ DISPLAY
      MVI C,81H
      CPI 03H
                          ; DECR
      JZ DISPLAY
LINE_3:
                         ;LINE 1, 2, 3
      MVI A,F7H
      STA 2800H
                         ; READ LINE
      LDA 1800H
                         ; READ COLUMNS
      ANI 07H
                         ;SET THE 5 MSB'S = 0
      MVI C,01H
      CPI 06H
                         ;1
      JZ DISPLAY
      MVI C,02H
      CPI 05H
                          ; 2
      JZ DISPLAY
      MVI C,03H
      CPI 03H
                          ; 3
      JZ DISPLAY
LINE_4:
                         ;LINE 4, 5, 6
      MVI A, EFH
      STA 2800H
                         ; READ LINE
      LDA 1800H
                         ; READ COLUMNS
      ANI 07H
                         ;SET THE 5 MSB'S = 0
      MVI C,04H
      CPI 06H
                         ; 4
      JZ DISPLAY
      MVI C,05H
      CPI 05H
                         ; 5
      JZ DISPLAY
      MVI C,06H
      CPI 03H
                          ;6
      JZ DISPLAY
                         ;LINE 7, 8, 9
LINE_5:
      MVI A,DFH
      STA 2800H
                         ; READ LINE
      LDA 1800H
                         ; READ COLUMNS
      ANI 07H
                         ;SET THE 5 MSB'S = 0
      MVI C,07H
      CPI 06H
                          ;7
```

```
JZ DISPLAY
      MVI C,08H
      CPI 05H
                         ;8
      JZ DISPLAY
      MVI C,09H
      CPI 03H
                          ; 9
      JZ DISPLAY
LINE_6:
                          ;LINE A, B, C
      MVI A,BFH
      STA 2800H
                          ; READ LINE
      LDA 1800H
                          ; READ COLUMNS
      ANI 07H
                         ;SET THE 5 MSB'S = 0
      MVI C, OAH
      CPI 06H
                         įΑ
      JZ DISPLAY
      MVI C,0BH
      CPI 05H
                         iΒ
      JZ DISPLAY
      MVI C, OCH
      CPI 03H
                          ; C
      JZ DISPLAY
LINE_7:
                          ;LINE D, E, F
      MVI A,7FH
      STA 2800H
                         ; READ LINE
      LDA 1800H
                         ; READ COLUMNS
      ANI 07H
                         ;SET THE 5 MSB'S = 0
      MVI C,0DH
      CPI 06H
      JZ DISPLAY
      MVI C,0EH
      CPI 05H
                         įΕ
      JZ DISPLAY
      MVI C, OFH
      CPI 03H
                          ;F
      JZ DISPLAY
      JMP START
                         ; IF NO BUTTON IS PRESSED, CHECK AGAIN
DISPLAY:
      LXI H, OAOOH
      MOV A,C
                         ;( C) := BUTTON'S CODE
      ANI OFH
                         ; ISOLATE THE 4 LSB'S
      MOV M,A
                         ;STORE THEM TO MEMORY
                         ; POINT TO THE NEXT MEMORY CELL 0A01H
      INX H
      MOV A,C
                         ;( C) := BUTTON'S CODE
      ANI FOH
                         ; ISOLATE THE 4 MSB'S
      RRC
                         ;SHIFT THEM TO THE 4 LSB'S
      RRC
      RRC
      RRC
      MOV M,A
                          ;STORE THEM TO MEMORY
      LXI D, OAOOH
                         ; MEMORY ADDRESS WHERE THE MESSAGE IS
      CALL STDM
      CALL DCD
      JMP START
```

END


4^η Άσκηση:

```
MVI C,00H
             ; THE FIRST MS LEDS ALWAYS OFF THAT'S WHY
             ; WE LOAD 00H and not F0H
;Calculate X0_a
      ;Load B0
      LDA 2000H
      ANI 01H
                          ;Mask for 1st LSB digit
      CALL GET_DIGIT
      MOV B,A
      ;Load A0
      LDA 2000H
      ANI 02H
      CALL GET_DIGIT
      ;X0 = A0 | B0
      ORA B
      ;Store X0_a for next operation
      MOV D,A
;Calculate X1
      ;Load B1
      LDA 2000H
      ANI 04H
      CALL GET_DIGIT
      MOV B,A
      ;Load A1
      LDA 2000H
      ANI 08H
      CALL GET_DIGIT
      ;X1 = A1 | B1
      ORA B
;Calculate X0
      XRA D
      ;Store this bit in C
      ORA C
      MOV C,A
      ;X1 = A1 | B1
      ORA B
      ;Shift and store
      RLC
      ORA C
      MOV C,A
;Calculate X2
      ;Load B2
      LDA 2000H
      ANI 10H
```

CALL GET_DIGIT

```
MOV B,A
      ;Load A2
      LDA 2000H
      ANI 20H
      CALL GET_DIGIT
      ;X2 = A2 \& B2
      ANA B
      ;Shift and store
      RLC
      RLC
      ORA C
      MOV C,A
;Calculate X3
      ;Load B3
      LDA 2000H
      ANI 40H
      CALL GET_DIGIT
      MOV B,A
      ;Load A3
      LDA 2000H
      ANI 80H
      CALL GET_DIGIT
      X3 = A3 \& B3
      ANA B
      ;Shift and store
      RLC
      RLC
      RLC
      ORA C
      MOV C,A
; Move C to LEDs in order to display the right turned on LEDs
      MOV A,C
;Complement A because LEDs are on when bit is 0
      CMA
      STA 3000H
      HLT
GET_DIGIT:
      JPE A0
                    ; If result had even parity, this
      JMP A1
                    ;means it was all zeros => digit was 0
A0:
      MVI A,00H
      RET
      MVI A,01H
A1:
      RET
      END
```

5^η Άσκηση:



Έστω ότι θέλουμε να διαβάσουμε τα δεδομένα που βρίσκονται στην τετράδα με διεύθυνση 0010 0110. Από τη διεύθυνση αυτή των 8 bit τα 4 πρώτα μας δίνουν τη γραμμή όπου βρίσκονται, δηλαδή τη γραμμή 0010= 2, η οποία γραμμή επιλέγεται από τον επιλογέα γραμμών. Τα υπόλοιπα 4 bit μας δείχνουν ότι κάθε bit της τετράδας βρίσκεται στη στήλη 0110 = 6 του καθενός από τα 4 κελιά από στήλες του ενός bit. Με βάση αυτά τα bit A3-A0, στην έξοδο των πολυπλεκτών βρίσκονται τα δεδομένα από τη στήλη αυτή, σχηματίζοντας έτσι την τετράδα που θέλουμε. Επειδή έχουμε (CS)' = 0, (WE)' = 1 και (RD)' = 0, η αριστερή συστοιχία απομονωτών οδηγείται σε κατάσταση υψηλής αντίστασης εξόδου λόγω απενεργοποίησης της αριστερής πύλης AND, ενώ η δεξιά πύλη και η δεξιά συστοιχία απομονωτών ενεργοποιούνται και συνδέεται η έξοδος των πολυπλεκτών (δηλαδή η τετράδα που διαβάζουμε) με το δίαυλο δεδομένων.

Ομοίως, αν θέλουμε να κάνουμε εγγραφή σε αυτή τη θέση μνήμης, η επιλογή γραμμής και στήλης γίνεται με τον ίδιο τρόπο, με τους πολυπλέκτες να συνδέουν την έξοδό τους με την κατάλληλη θέση μνήμης. Επειδή τώρα έχουμε (WE)' = 0 και (RD)' = 1, η αριστερή συστοιχία πολυπλεκτών είναι αυτή που ενεργοποιείται, οπότε ο δίαυλος δεδομένων, ο οποίος περιέχει την τετράδα προς εγγραφή, συνδέεται μέσω του κυκλώματος με τα κελιά μνήμης που αντιστοιχούν στην επιθυμητή τετράδα, οπότε και ολοκληρώνεται η εγγραφή.

6^η Άσκηση:

Η ROM ξεκινά από τη διεύθυνση 0000Η και υλοποιείται χρησιμοποιώντας 2 ολοκληρωμένα μνήμης 4K8 bit (ROM) και 1 ολοκληρωμένο μνήμης 2K8 bit (ROM) -συνολικά 3 ICs. Η μνήμη RAM καταλαμβάνει 6 KB και ακολουθεί χωρίς κενά διευθύνσεων την ROM, ενώ αποτελείται απο μια μνήμη 2K8 και μια 4K8 SRAMs (2 ICs).

Σύμφωνα με τις προδιαγραφές που μας δίνονται, οι μνήμες μαζί με τις διευθύνσεις που καταλαμβάνουν:

Μνήμη	Διευθύνσεις
ROM 1 (4K)	0000H - 0FFFH
ROM 2 (4K)	1000H - 1FFFH
ROM 3 (2K)	2000H - 27FFH
SRAM 1 (2K)	2800H - 2FFFH
SRAM 2 (4K)	3000H - 3FFFH

Τα I.C. των 2Kbyte δέχονται ως είσοδο τα bit διεύθυνσης A10-A0 (11 bits), ενώ τα άλλα I.C. (4KB) δέχονται τα A11-A0 (12 bits). Για τον χάρτη μνήμης του συγκεκριμένου συστήματος εργαζόμαστε όπως παρακάτω:

Για τη $1_η$ ROM ξεκινάμε από τη διεύθυνση 0000 0000 0000 και καταλήγουμε στη διεύθυνση 0000 1111 1111 1111 (μεταβάλλονται τα bits A0-A11)

A15	A14	A13	A12	A11	A10	A9	A8	A7	A6	A5	A4	A3	A2	A1	A0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
0	0	0	0	1	1	1	1	1	1	1	1	1	1	1	1

 Γ ια τη 2^{η} ROM ξεκινάμε από τη διεύθυνση 0001 0000 0000 0000 και καταλήγουμε στη διεύθυνση 0001 1111 1111 1111 (μεταβάλλονται τα bits A0-A11)

A15	A14	A13	A12	A11	A10	A9	A8	A7	A6	A5	A4	A3	A2	A1	A0
0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0
0	0	0	1	1	1	1	1	1	1	1	1	1	1	1	1

Για τη 3^{η} ROM ξεκινάμε από τη διεύθυνση 0010 0000 0000 0000 και καταλήγουμε στη διεύθυνση 0010 1111 1111 1111 (μεταβάλλονται τα bits A0-A10)

A15	A14	A13	A12	A11	A10	A9	A8	A7	A6	A5	A4	A3	A2	A1	A0
0	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
0	0	1	0	0	1	1	1	1	1	1	1	1	1	1	1

 Γ ια τη 1^{η} RAM ξεκινάμε από τη διεύθυνση 0010 1000 0000 0000 και καταλήγουμε στη διεύθυνση 0010 1111 1111 1111 (μεταβάλλονται τα bits A0-A10)

A15	A14	A13	A12	A11	A10	A9	A8	A7	A6	A5	A4	A3	A2	A1	A0
0	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
0	0	1	0	1	1	1	1	1	1	1	1	1	1	1	1

Για τη 2^{η} RAM ξεκινάμε από τη διεύθυνση 0011 0000 0000 0000 και καταλήγουμε στη διεύθυνση 0011 1111 1111 1111 (μεταβάλλονται τα bits A0-A11)

A15	A14	A13	A12	A11	A10	A9	A8	A7	A6	A5	A4	A3	A2	A1	A0
0	0	1	1	0	0	0	0	0	0	0	0	0	0	0	0
0	0	1	1	1	1	1	1	1	1	1	1	1	1	1	1

Από τα παραπάνω συμπεραίνουμε ότι τα μοναδικά bits που δεν μεταβάλλονται σε καμία περίπτωση είναι τα Α15, Α14. Επομένως για τη δημιουργία του αποκωδικοποιητή θα αναστρέψουμε τις εισόδους των bits αυτών (που θα έχουν πάντα τιμή μηδέν) ώστε να έχουν ρόλο εισόδου επίτρεψης και φυσικά θα έχουμε επιπλέον την καθιερωμένη είσοδο επίτρεψης στο λογικό 1. Άρα, Τα bits Α14,Α15 χρησιμοποιούνται ως επίτρεψη στον αποκωδικοποιητή.


Επίσης προκύπτει ότι υπεύθυνα για την ενεργοποίηση της κατάλληλης μνήμης είναι τα bits A13, A12 και A11.

ROM 1: A13' A12' ROM 2: A13' A12 ROM 3: A13 A12' A11' SRAM 1: A13 A12' A11 SRAM 2: A13 A12 Οι συνδυασμοί που μπορούμε να έχουμε και οι αντίστοιχες έξοδοι του αποκωδικοποιητή βρίσκονται στον παρακάτω πίνακα:

A13	A12	A11	ΕΞΟΔΟΣ	MNHMH
0	0	0	Y0	ROM1
0	0	1	Y1	ROM1
0	1	0	Y2	ROM2
0	1	1	Y3	ROM2
1	0	0	Y4	ROM3
1	0	1	Y5	SRAM1
1	1	0	Y6	SRAM2
1	1	1	Y7	SRAM2

Από τα συνολικά 64 KB της μνήμης δεν χρησιμοποιούνται τελικά τα 64-16=48 Kbytes από τις RAM και τις ROM.

Το σχέδιο του συστήματος μνήμης:



7^η Άσκηση:

