```
function ode45_ex
close all
clear all
lr=1.5;
lf=1.5;
%C
%Initial Condition:
xo=[0;0;0];
%timespan:
t=0:0.1:10;
Vx=1;
[t,x]=ode45(@sys,t,xo);
plot(t, x(:,3))
ylabel('y(m)');
xlabel('x(m)');
title(['Vx=',num2str(Vx), 'm/s'])
function dx = sys(t, x)
%Parameters:
Vx=4; %(m/s)
m=50; %(kg)
Iz=100; %(kg-m^2);
Caf=8000; %(N/rad)
Car=8000; %(N/rad)
%square input
Amp=5; %steering angle in degree
yd=Amp-2*Amp.*heaviside(t-5)+2*Amp.*heaviside(t-10); %input square
wave
steerangle=5*yd;
steerangle=steerangle*pi()/180;
A=-(cos(steerangle)*Caf+Car)/m*Vx;
B=(-(cos(steerangle)*Caf*lf+lr*Car)/(m*Vx))-Vx;
C=(-cos(steerangle)*Caf*lf+lr*Car)/Iz*Vx;
D=-(cos(steerangle)*Caf*lf*lf+lr*lr*Car)/Iz*Vx;
E=Caf*cos(steerangle)/m;
F=lf*Caf*cos(steerangle)/Iz;
u=steerangle;
```


```
dx(1,:)=A*x(1)+C*x(2)+E*u;

dx(2,:)=B*x(1)+C*x(2)+F*u;

dx(3,:)=x(1);
```

end

end



Published with MATLAB® R2019a