

# Akai MPK Mini MK3

## Loop Lab

### GarageBand and Ableton Live

Every knob, pad, key, and beginner loop workflow

**Keys -> Pads -> Knobs -> Loops -> Performance**

kiffness-mpk-mini-manual (0.3.1)

Alexy Khrabrov

*Codex with ChatGPT 5.5*

# Akai MPK Mini MK3 Loop Lab

## Every knob, pad, key, and beginner loop workflow for GarageBand and Ableton Live

Alexy Khrabrov

Codex with ChatGPT 5.5

2026-06-20

### Contents

|        |                                       |    |
|--------|---------------------------------------|----|
| 1      | Start Here .....                      | 2  |
| 2      | The Mental Model .....                | 2  |
| 3      | Identifying Your MPK Mini .....       | 3  |
| 4      | The Keys .....                        | 4  |
| 4.1    | Octave Buttons .....                  | 4  |
| 4.2    | Key Exercise: One-Bar Bass .....      | 5  |
| 5      | The Pads .....                        | 5  |
| 5.1    | Pad Banks .....                       | 5  |
| 5.2    | Full Level .....                      | 5  |
| 5.3    | Note Repeat .....                     | 6  |
| 6      | The Knobs .....                       | 6  |
| 6.1    | GarageBand Knob Reality .....         | 7  |
| 6.2    | Ableton Knob Reality .....            | 7  |
| 7      | Arpeggiator .....                     | 7  |
| 8      | Joystick, Pitch, and Modulation ..... | 8  |
| 9      | Programs and Presets .....            | 8  |
| 10     | GarageBand Loop Lab .....             | 9  |
| 10.1   | Setup .....                           | 9  |
| 10.2   | Four-Track Starter Loop .....         | 9  |
| 10.2.1 | Track 1: Drums .....                  | 9  |
| 10.2.2 | Track 2: Bass .....                   | 9  |
| 10.2.3 | Track 3: Chords .....                 | 9  |
| 10.2.4 | Track 4: Hook .....                   | 10 |
| 10.3   | GarageBand Loops and Cycle .....      | 10 |
| 11     | Ableton Live Loop Lab .....           | 10 |
| 11.1   | Setup .....                           | 10 |
| 11.2   | Four-Clip Starter Set .....           | 11 |
| 11.3   | Drum Rack Mapping .....               | 11 |
| 11.4   | Knob Mapping .....                    | 11 |
| 11.5   | Clip Launch With Pads .....           | 11 |
| 11.6   | Sync Note Repeat to Live .....        | 12 |

|      |                                  |    |
|------|----------------------------------|----|
| 12   | Performance Studies .....        | 12 |
| 12.1 | Clint Eastwood-Style Hook .....  | 12 |
| 12.2 | In Da Club-Style Cover .....     | 12 |
| 12.3 | Beginner MK3 Control Study ..... | 12 |
| 13   | Troubleshooting .....            | 13 |
| 14   | Thirty-Day Practice Plan .....   | 14 |
| 15   | Final Project .....              | 14 |

## 1 Start Here

This book is for learning the Akai MPK mini as a small performance instrument, not as a mysterious USB accessory. The goal is practical: plug it into a Mac, understand every control on the surface, and use it to make short loops in GarageBand and Ableton Live.

The guide is grounded in these study references:

- Smith’s Covers, “Gorillaz - Clint Eastwood (Akai MPK Mini MK3 Cover)”: [https://www.youtube.com/shorts/d\\_VK75O173w](https://www.youtube.com/shorts/d_VK75O173w)
- inMusic Brands Support, “Akai Pro MPK Mini Play MK3 | Onboard Features & Standalone Use”: <https://www.youtube.com/watch?v=QTLGsW9tlw4>
- IxStage, “50 Cent - In Da Club / AKAI MPK MINI MK3 COVER”: <https://youtu.be/awnLq-c5N8M>
- Dezavi Productions, “AKAI MPK mini MK3 Tutorial Beginners”: <https://youtu.be/sM6RY5s4e8o>
- Autumn Gard, “AKAI MPK MINI PLAY MK3 TUTORIAL WITH ABLETON LIVE”: <https://youtu.be/ckAbhrpB89w>
- Matthew Stratton, “AKAI MPK MINI MK3 Complete Setup”: <https://youtu.be/FqU2F31dJiw>
- Matthew Stratton, “AKAI MPK MINI MK3 - Ableton Live Setup Tutorial”: <https://youtu.be/mQBsbT1CHY>

Those videos teach three different things. The cover videos show what the MPK looks like when someone has already mapped it and can perform confidently. The beginner videos explain the controls: pads, banks, note repeat, arpeggiator, octaves, knobs, and software setup. The Ableton tutorial shows the same hardware inside a clip-based DAW, where pads and knobs become a live-looping surface.

This book does not copy the source music, video frames, or transcripts. It turns the observed techniques into original practice routines you can do with your own sounds.

## 2 The Mental Model

The MPK mini sends MIDI. MIDI is not audio. When you press a key, tap a pad, move a joystick, or turn a knob, the MPK sends a message such as “note C2 on,” “controller 74 moved,” or “pitch bend up.” GarageBand or Ableton receives that message and decides what sound or command it should control.

Think of the controller as four instruments in one:

| Surface          | What it feels like    | What it sends                      | Typical job                         |
|------------------|-----------------------|------------------------------------|-------------------------------------|
| Keys             | tiny keyboard         | MIDI notes with velocity           | bass, chords, lead, melody          |
| Pads             | finger drums          | MIDI notes, CC, or program changes | drums, samples, clip launch         |
| Knobs            | eight rotary controls | MIDI CC values                     | filter, volume, pan, sends, effects |
| Buttons/joystick | performance controls  | transport, octave, arp, bend, mod  | range, timing, expression           |

The important beginner lesson is that the same physical pad can do different things in different modes. In Drum or Notes mode it sends a note. In CC mode it sends a control-change message. In Program Change mode it changes presets or patches. In Ableton or GarageBand scripts on newer models, pads can also select tracks, arm tracks, mute, solo, launch clips, or stop clips.

### 3 Identifying Your MPK Mini

Your photo shows the familiar MPK mini layout: 25 mini keys, eight MPC-style pads, eight knobs, octave buttons, arpeggiator, note repeat, full level, and a small display/joystick area depending on generation. You believe it is an MK3, so the examples below use MK3 language. If a label on your physical unit differs from a tutorial video, use this translation:

| If the video says | On your controller look for         | Meaning                                     |
|-------------------|-------------------------------------|---------------------------------------------|
| Bank A/B          | Bank A/B, Pads A/B, or Pad Bank     | Switch pads from notes 1-8 to 9-16          |
| Full Level        | Full Level                          | Pads always send velocity 127               |
| Note Repeat       | Note Repeat                         | Held pads repeat in time                    |
| Arp               | Arpeggiator or ARP On/Off           | Held keys become rhythmic patterns          |
| Tap Tempo         | Tap Tempo                           | Sets internal arp/note-repeat tempo         |
| Prog Select       | Program Select or Program           | Recall saved controller mappings            |
| CC                | CC or Control Change                | Pads send control messages instead of notes |
| Prog Change       | Program Change                      | Pads send patch-change messages             |
| Joystick/X-Y      | X-Y controller, joystick, pitch/mod | Pitch bend and modulation/expression        |

MK3 and MPK Mini Play MK3 tutorials overlap, but the Play model has internal sounds and a speaker. A plain MK3 relies on the Mac for sound. When a tutorial says “internal sound,” translate that to “software instrument in GarageBand or Ableton” unless your unit is the Play version.

## 4 The Keys

The 25 keys are velocity-sensitive. Press softly and the DAW receives a softer note. Press harder and the DAW receives a louder/brighter note if the instrument responds to velocity.

The keys are small, so use them deliberately:

| Job      | Good beginner range | Practice pattern             |
|----------|---------------------|------------------------------|
| Bass     | lower octave        | root, fifth, octave          |
| Chords   | middle octave       | two-note shells or triads    |
| Lead     | upper octave        | short repeated hook          |
| Arpeggio | any held chord      | hold three notes with ARP on |

### 4.1 Octave Buttons

The Octave Down and Octave Up buttons shift the keyboard range. If the bass is too high, press Octave Down once. If the lead is buried, press Octave Up once. Press both octave buttons together on many MPK models to return to center.

Beginner rule: record bass one octave down, chords at center, and lead one octave up. Do not chase every octave while recording. Choose the range first, then play.

## 4.2 Key Exercise: One-Bar Bass

Set a GarageBand or Ableton software instrument to a simple synth bass.

1. Set tempo to 92 BPM.
2. Press Octave Down once.
3. Play C, G, C, rest.
4. Record one bar.
5. Quantize to 1/8 notes.
6. Loop it for four bars.

Now change only the sound. Try synth bass, electric bass, organ bass, and sub-bass. The MIDI notes stay the same while the instrument changes.

## 5 The Pads

The eight pads are the fastest way to feel the MPK as an MPC-style performance surface. They are usually velocity-sensitive. A soft tap sends a lower velocity; a hard hit sends a higher velocity.

### 5.1 Pad Banks

Bank A gives eight pads. Bank B gives eight more. Together they act like a sixteen-pad grid.

| Bank       | Beginner mapping                                 |
|------------|--------------------------------------------------|
| A Pad 1    | Kick                                             |
| A Pad 2    | Snare or clap                                    |
| A Pad 3    | Closed hat                                       |
| A Pad 4    | Open hat or percussion                           |
| A Pad 5    | Vocal chop or sample stab                        |
| A Pad 6    | Extra percussion                                 |
| A Pad 7    | Riser or transition                              |
| A Pad 8    | Stop, mute, or crash                             |
| B Pads 1-8 | alternate samples, fills, or second drum kit row |

### 5.2 Full Level

Full Level makes every pad hit send maximum velocity. Use it when you want even drums and are tired of weak snare hits. Turn it off when you want expressive finger drumming.

Practice:

1. Choose a drum kit.
2. Turn Full Level off and play kick-snare-hat.

3. Turn Full Level on and repeat.
4. Decide which version feels better for the loop.

For beginner loops, use Full Level while learning timing, then turn it off when you want musical dynamics.

### 5.3 Note Repeat

Note Repeat retriggers a held pad at the current tempo and division. It is for hi-hats, rolls, tambourines, and trap-style repeated hits. In the beginner MK3 tutorials, this is usually demonstrated with pads, not keys.

Practice:

1. Put closed hat on Pad 3.
2. Turn Note Repeat on.
3. Hold Pad 3 while the project plays.
4. Try 1/8, 1/16, and 1/16 triplet divisions.
5. Record the one that grooves.

If Note Repeat is late or drifting, check whether the MPK is using internal clock or external clock from the DAW. For tight DAW loops, external sync is usually the cleanest path when your model/software supports it.

## 6 The Knobs

The eight knobs are assignable MIDI controls. In tutorials they are often called Q-Link knobs or assignable encoders. They do not make sound by themselves. They move a parameter inside the current instrument, effect, mixer, or DAW script.

Use this default learning map:

| Knob | GarageBand<br>Control | Smart<br>Ableton<br>Mixer job | Device/<br>Mixer job | What you hear       |
|------|-----------------------|-------------------------------|----------------------|---------------------|
| K1   | cutoff or tone        | filter cutoff                 |                      | darker to brighter  |
| K2   | resonance             | filter resonance              |                      | sharper filter peak |
| K3   | attack                | envelope attack               |                      | pluck to swell      |
| K4   | release               | envelope release              |                      | short to long tail  |
| K5   | track volume          | mixer volume                  |                      | quiet to loud       |
| K6   | pan                   | mixer pan                     |                      | left to right       |
| K7   | echo/delay send       | delay send                    |                      | dry to echo         |
| K8   | reverb send           | reverb send                   |                      | close to spacious   |

## 6.1 GarageBand Knob Reality

GarageBand does not give the older MK3 the same deep control-script behavior that newer MPK mini IV guides describe. With a plain MK3, you usually use MIDI Learn or Smart Controls when available. The practical workflow is:

1. Select a software instrument track.
2. Open Smart Controls.
3. Choose the control you want to move.
4. Use MIDI Learn if GarageBand exposes it for that control.
5. Turn the MPK knob.
6. Test that the on-screen knob moves.

If the knob does not map, do not panic. Record the MIDI notes first, then use GarageBand's on-screen automation for the sound change. The musical idea matters more than proving every knob works on day one.

## 6.2 Ableton Knob Reality

Ableton is friendlier for manual mapping:

1. Open Preferences > Link/Tempo/MIDI.
2. Enable Track and Remote for the MPK input.
3. Click MIDI Map Mode.
4. Click the Ableton parameter.
5. Turn the MPK knob.
6. Exit MIDI Map Mode.

Start with K1 mapped to Auto Filter frequency and K8 mapped to Reverb dry/wet. That gives you the two most obvious performance moves: open the sound and push it into space.

## 7 Arpeggiator

The arpeggiator belongs to the keys. Hold a chord and the MPK turns it into a pattern. It can run up, down, in order, randomly, or across multiple octaves depending on settings.

Beginner settings:

| Parameter   | Starting value              | Why                    |
|-------------|-----------------------------|------------------------|
| Tempo/clock | DAW sync or 92 BPM internal | keeps loops in time    |
| Division    | 1/8                         | clear enough to hear   |
| Mode        | Up                          | predictable            |
| Octave      | 1                           | avoids chaos           |
| Latch       | Off at first                | stops when you release |
| Swing       | 50%                         | straight grid          |

Exercise:



1. Choose a pluck or bell sound.
2. Turn ARP on.
3. Hold C minor: C, Eb, G.
4. Record two bars.
5. Change only the division to 1/16.
6. Record a second pass and compare.

Use ARP for texture. Do not let it become a substitute for learning the hook.

## 8 Joystick, Pitch, and Modulation

The MK3 joystick is usually pitch bend on one axis and modulation on another. Pitch bend changes note pitch temporarily. Modulation often adds vibrato, filter movement, or another instrument-specific effect.

Practice:

1. Load a lead synth.
2. Hold one note.
3. Move the joystick left/right slowly for pitch bend.
4. Move it up/down for modulation.
5. Record a short lead phrase with one bend at the end.

Use the joystick like punctuation. One bend can sound expressive. Constant bend movement often sounds accidental.

## 9 Programs and Presets

A program is a saved controller mapping: which MIDI notes pads send, what CC numbers knobs send, what channel the keys use, and how the performance controls behave. The Matthew Stratton setup video is useful because it emphasizes the registration/software-manager path: install the supporting software, download bundled instruments, and understand where the MPK editor or software manager fits.

For this book, use three beginner programs:

| Program                  | Purpose                                                        |
|--------------------------|----------------------------------------------------------------|
| Program 1: Loop Lab      | keys, pads, knobs all on one normal MIDI channel               |
| Program 2: Drum Practice | pads mapped for a 16-pad drum rack                             |
| Program 3: Performance   | pads for samples, keys for lead/bass, knobs for filter/effects |

If you are unsure, stay on Program 1. Most beginner frustration comes from accidentally changing programs or modes and then wondering why the DAW no longer responds the same way.

## 10 GarageBand Loop Lab

GarageBand is the simplest place to start because it opens quickly and has friendly built-in sounds.

### 10.1 Setup

1. Connect the MPK by USB.
2. Open GarageBand.
3. Create an Empty Project.
4. Add a Software Instrument track.
5. Play the keys. You should hear the default instrument.
6. Open Musical Typing only if you need a comparison; the MPK should be the real input.

If GarageBand does not hear the MPK, open GarageBand > Settings > Audio/MIDI and reset MIDI drivers. On macOS you can also remove and reconnect the device in Audio MIDI Setup.

### 10.2 Four-Track Starter Loop

Set tempo to 92 BPM and make a four-bar cycle.

| Track | GarageBand patch         | MPK control           | Part             |
|-------|--------------------------|-----------------------|------------------|
| 1     | Drum Kit or Beat Machine | Pads 1-4              | kick, snare, hat |
| 2     | Synth Bass               | lower keys            | root/fifth bass  |
| 3     | Classic Electric Piano   | middle keys           | two-note chords  |
| 4     | Lead Synth or Organ      | upper keys + joystick | short hook       |

#### 10.2.1 Track 1: Drums

1. Select the drum track.
2. Turn Full Level on.
3. Record Pad 1 on beats 1 and 3.
4. Record Pad 2 on beats 2 and 4.
5. Add Pad 3 as eighth-note hats.
6. Quantize to 1/16 if needed.

#### 10.2.2 Track 2: Bass

1. Select a bass patch.
2. Press Octave Down once.
3. Record C, G, C, rest.
4. Keep the bass shorter than the drum loop.

#### 10.2.3 Track 3: Chords

1. Select an electric piano or pad.
2. Return octave to center.
3. Record C minor for two beats, Ab major for two beats.
4. Use only two or three notes per chord.

#### 10.2.4 Track 4: Hook

1. Select a lead or organ sound.
2. Press Octave Up once.
3. Record a five-note hook.
4. Use the joystick on the last note only.

### 10.3 GarageBand Loops and Cycle

GarageBand's cycle region lets you loop a section while recording. Turn cycle on, drag the yellow cycle bar over four bars, and record multiple passes until the take feels right.

Beginner loop rules:

1. Record only one job per track.
2. Fix timing with quantize after the take.
3. Duplicate good regions instead of replaying everything.
4. Use automation after the musical parts are stable.

## 11 Ableton Live Loop Lab

Ableton Live is built for clips, scenes, and looping. The MPK feels more like a performance controller here because Ableton can map pads and knobs directly.

### 11.1 Setup

1. Connect the MPK by USB.
2. Open Ableton Live or Live Lite.
3. Open Preferences > Link/Tempo/MIDI.
4. In MIDI Ports, enable Track for the MPK mini input. This lets pads and keys play instruments.
5. Enable Remote for the MPK mini input if you want knobs or pads to control Ableton parameters through MIDI mapping.
6. If Live offers MPK mini MK3 in Control Surface, select it, then choose the MPK mini input and output. If Live fills those in automatically, leave them.
7. On the controller, use Program Select to choose the Ableton Live program if your MPK already has one loaded.
8. Enable Sync on the MPK output if you want Ableton to send clock for arpeggiator or note repeat.

If you are using a newer MPK mini IV, Akai's Ableton guide describes selecting the MPK mini IV control surface and DAW port. For MK3, the reliable beginner path is simpler: Track on for notes, Remote on for mapping, Sync on only when you need tempo sync.

Matthew Stratton's MK3 Ableton setup video is the most directly relevant Ableton reference for this book because it shows the exact MK3 checklist: confirm pads and keys first, map an encoder to a device parameter, open Link/MIDI preferences when something does not respond, turn on Track for notes, turn on Remote for encoder mapping, select the MPK mini MK3 control surface when available, and use Sync only when you want tempo-locked Note Repeat.

## 11.2 Four-Clip Starter Set

Create four MIDI tracks:

| Track  | Ableton device                   | MPK control     | Clip length |
|--------|----------------------------------|-----------------|-------------|
| Drums  | Drum Rack                        | Pads            | 1 or 2 bars |
| Bass   | Analog, Drift, or Wavetable bass | keys            | 2 bars      |
| Chords | Electric, Piano, or Pad          | keys            | 4 bars      |
| Lead   | synth lead                       | keys + joystick | 4 bars      |

## 11.3 Drum Rack Mapping

1. Load Drum Rack.
2. Drop Kick, Snare, Closed Hat, and Open Hat into the first four cells.
3. Tap Pad 1. If it does not hit the kick, move the sample to the pad's incoming note or remap the pad with the MPK editor.
4. Record a one-bar clip.
5. Turn on overdub and add hats.

## 11.4 Knob Mapping

1. Put Auto Filter after the lead instrument.
2. Enter MIDI Map Mode.
3. Click Auto Filter Frequency.
4. Turn K1.
5. Click Auto Filter Resonance.
6. Turn K2.
7. Exit MIDI Map Mode.
8. Record automation while the clip plays.

If the encoders do not move anything, re-open Preferences > Link/Tempo/MIDI and check Remote on the MPK input. Track lets notes play instruments; Remote lets controls map to Ableton parameters.

## 11.5 Clip Launch With Pads

Older MK3 units do not automatically become an Ableton clip grid unless you use a script or manual mapping. You can still make a useful setup:

1. Enter MIDI Map Mode.
2. Click the first drum clip launch button.
3. Tap Pad 5.
4. Click the bass clip launch button.
5. Tap Pad 6.
6. Click the chord clip launch button.
7. Tap Pad 7.
8. Click Stop All Clips or a track stop button.

9. Tap Pad 8.

Now Pads 1-4 can stay drums, while Pads 5-8 launch or stop clips.

## **11.6 Sync Note Repeat to Live**

To make Note Repeat follow Ableton's tempo:

1. In Ableton Preferences > Link/Tempo/MIDI, turn Sync on for the MPK output.
2. On the MPK, open the Note Repeat or clock setting.
3. Set the clock source to external if your program exposes that option.
4. Start Live playback.
5. Hold a hat pad with Note Repeat on.

If repeat only works when Live is playing, that is expected with external sync. The MPK is waiting for Live's clock.

## **12 Performance Studies**

### **12.1 Clint Eastwood-Style Hook**

The Smith's Covers Short shows the MPK as a miniature performance station: simple lead phrase, low anchor notes, and a middle pad section.

Practice version:

1. Use an organ, melodica, or nasal synth lead.
2. Map drums to Pads 1-4.
3. Map a vocal/sample stab or effect to Pad 5.
4. Play the hook in one octave.
5. Move to the pads for a short fill.
6. Return to the hook.

Do not start with the full song. Start with one hook, one pad fill, and one ending.

### **12.2 In Da Club-Style Cover**

The IxStage performance reference is useful because it treats the MPK as a cover instrument: keys carry the riff and pads can handle drums or samples.

Practice version:

1. Find the lowest note of the riff.
2. Put that note under your left hand.
3. Put the answer notes under your right hand.
4. Use Pad 1 for kick and Pad 2 for clap.
5. Record the riff first, then drums.

### **12.3 Beginner MK3 Control Study**

The Dezavi Productions tutorial is the core beginner-control study: pads, pressure, bank switching, full level, note repeat, octave shifting, arpeggiator, and knobs.

Practice checklist:

1. Play all eight pads softly and loudly.
2. Turn Full Level on and repeat.
3. Switch Bank A/B and repeat.
4. Turn Note Repeat on and hold a hat pad.
5. Turn ARP on and hold a triad on the keys.
6. Move every knob while watching the DAW.
7. Move the joystick while holding a lead note.

## 13 Troubleshooting

| Symptom                                 | Likely cause                          | Fix                                                    |
|-----------------------------------------|---------------------------------------|--------------------------------------------------------|
| Keys play but pads do nothing           | drum kit expects different MIDI notes | move samples, change pad notes, or use Drum Rack learn |
| Pads play but velocity is uneven        | Full Level off                        | turn Full Level on while practicing                    |
| Note Repeat is not in time              | internal clock differs from DAW tempo | use external sync or tap tempo carefully               |
| Knobs do not move anything              | not mapped                            | use MIDI Learn or Ableton MIDI Map Mode                |
| GarageBand hears no MIDI                | MIDI driver/session stale             | reset MIDI drivers or reconnect in Audio MIDI Setup    |
| Ableton records notes but mapping fails | Remote disabled                       | enable Remote for the MPK input                        |
| Arpeggiator keeps playing               | latch on                              | turn latch off or stop the arpeggiator                 |
| Wrong octave                            | octave shifted                        | press both octave buttons or return to center          |

## 14 Thirty-Day Practice Plan

| Days  | Focus                      | Result                           |
|-------|----------------------------|----------------------------------|
| 1-3   | Keys and octaves           | one bass loop                    |
| 4-6   | Pads and Full Level        | one drum loop                    |
| 7-9   | Note Repeat                | hats and rolls in time           |
| 10-12 | Knobs                      | filter and reverb automation     |
| 13-15 | Arpeggiator                | one pluck pattern                |
| 16-18 | GarageBand four-track loop | drums, bass, chords, hook        |
| 19-21 | Ableton four-clip set      | clips and Drum Rack              |
| 22-24 | Pad launching              | Pads 5-8 launch clips/samples    |
| 25-27 | Performance study          | 60-second cover sketch           |
| 28-30 | Film and revise            | one shareable top-down MPK video |

## 15 Final Project

Make a 60-second loop video:

1. Start with the controller visible.
2. Record drums with pads.
3. Add bass with lower keys.
4. Add chords with middle keys.
5. Add a hook with upper keys.
6. Turn K1 for a filter opening.
7. Use K8 for reverb on the final phrase.
8. End with Pad 8 as a crash, mute, or stop.

The finished video should prove that you know what every surface does. It does not need to be complicated. A clean four-track loop is better than a crowded arrangement where the controller work is hidden.