




Residential Use Only

THIS PRODUCT IS INTENDED FOR USE BY  
CHILDREN FROM AGES 3 TO 14

SAVE THESE  
INSTRUCTIONS



# Banana Beach



**Warning!** Choking Hazard - Small parts! Only for domestic use. For outdoor use only.  
Product must be assembled by an adult. Customer must keep this information



**Ages  
3-14**



Page intended to be empty

# PRODUCT REGISTRATION

## 3 EASY WAYS TO REGISTER

### OPTION 1

Scan the QR Code:



### OPTION 2

Make a photo of the completed registration card and send it by e-mail to:  
[info@wickey.com](mailto:info@wickey.com)

### OPTION 3

Mail the completed form to:

**Wickey Corporation**  
4001 Calhoun Ave, Chattanooga  
TN 37407

## Where did you buy this product?

Date of Purchase

Store

Store City

Store State

## Your registration information:

Name: \_\_\_\_\_ Email: \_\_\_\_\_

Address: \_\_\_\_\_ Street \_\_\_\_\_ City \_\_\_\_\_ State \_\_\_\_\_ Zip \_\_\_\_\_

Please select     18-30     41-50  
your age     31-40     51+  
How old are     2-3     6-7  
your children?     4-5     8+

How would     ★ ★ ★ ★ ★    Excellent  
you rate the     ★ ★ ★ ★    Above Average  
quality of this     ★ ★ ★    Average  
product?     ★ ★    Below Average  
                 ★    Poor

Number of  
children   

Would you recommend this product to friends & family?     Yes     No

May we add you to our mailing list?     Yes     No

May we use your comments on websites or other marketing materials?     Yes     No

Comments: \_\_\_\_\_

\_\_\_\_\_



## General safety information

Congratulations on the purchase of your Wickey climbing frame. The purchased product is expandable at any time, so years of fun are guaranteed. Our systems meet the latest safety requirements: the used materials comply with the European standards, according to ASTM F1148 - Standard Consumer Safety Performance Specification for Home Playground Equipment. All woods are pressure impregnated and thus protected from the elements. Our playground equipment is examined with the utmost care to ensure the necessary safety.

- ▶ Please use only original Wickey components and add-on parts.
- ▶ For domestic use only!
- ▶ Suitable for children between 3 and 14 years old.
- ▶ Maximum load capacity: 220 lbs.
- ▶ For outdoor use only!

## Safety instructions for assembly

- ▶ The product may only be assembled by adults.
- ▶ Make sure that no children are present during the installation of the play equipment.
- ▶ Children must not use the equipment until properly installed.
- ▶ The climbing frame may only be used after the complete inspection of all attachments.
- ▶ Read the installation instructions carefully and keep these instructions for future adjustments or extensions
- ▶ Wear suitable protective clothing, such as safety glasses, and gloves, during the assembly.
- ▶ Do not step onto the platform until the playground equipment is completely assembled.
- ▶ In order to ensure the stability of the climbing frame, you should use ground anchors and fix them in concrete.
- ▶ Make sure that the ground anchors disappear into the ground

completely, to prevent tripping hazards.

- ▶ Tighten the nuts on bolts securely, and flush to the the component.
- ▶ Caps which go over the exposed bolts shall be put on snug to the nut.

## Swing Clearance Distances

- ▶ The distance between the swing seat and the ground should be at least 14".
- ▶ The distance between the individual swing seats and other swinging products should be at least 18".
- ▶ The clearance distance between swings and frame should be at least 12".

## Surroundings and underground

- ▶ Do not install home playground equipment over concrete, asphalt, packed earth, grass, carpet, or any other hard surface. A fall onto a hard surface can result in serious injury or death to the equipment user.
- ▶ Place the equipment on level ground, not less than 6 ft from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.

## Inappropriate use

Improper use or the attachment of inappropriate or foreign materials such as heavy chains, poles or ropes release the manufacturer from his responsibility. The same applies to incorrect assembly. Do not deviate from the assembly instructions and do not change the design and implementation.

## Supervision

Keep in mind that adult supervision is mandatory and essential while children play on these devices. Children under 3 years of age are not allowed to use the playground equipment.

## Maintenance

At the beginning of each play session and every two weeks during the season, check the strength of the screws and hooks. Note, however, that overtightened screws can cause cracks in the wood.

Also check the fastening material, fittings and swing hooks for any signs of wear or rust. Also check the anchors and replace them in case of defects. In addition, all moving metal parts must be lubricated on a regular basis. Also check all the screw covers and sharp edges and replace them or grind them off if necessary. Check the wooden parts for splinters and cracks, which can naturally occur during the drying process. Remove any splinters that may have developed during this process. Swing seats, chains, ropes and other accessories must be checked for signs of wear. Defective parts must be replaced in accordance with the manufacturer's instructions. Lack of inspection can cause the climbing frame to overturn or can have other dangerous effects.

## Wood treatment

Since all wooden parts are pretreated (pressure impregnated) there is no need for further treatment against weathering or decay. Under no circumstances should you paint the wood or use a paint that could result in a slippery/smooth surface.

## Maintenance of plastics

For cleaning the plastic parts, we recommend tap water with detergent. In wintertime, you should store the plastic parts in the house or garage to slow down the natural aging process of the materials.

Wickey's play equipment is intended for private use only, as additional safety requirements are required for public play equipment. Spare parts can be ordered via our webshop: [www.wickey.com](http://www.wickey.com)

## **SAFETY CHECKS AND MAINTAINENCE INSTRUCTIONS**

**OBSERVING THE FOLLOWING STATEMENTS AND WARNINGS  
REDUCES THE LIKELIHOOD OF SERIOUS OR FATAL INJURY**

### **WARNING**

ADULT SUPERVISION REQUIRE. On-site supervision is required anytime a play set is being used.

### **WARNING**

ADULT ASSEMBLY REQUIRED. KEEP AWAY FROM CHILDREN UNTIL ASSEMBLED AND ANCHORED. Product prior to assembly contains sharp points, sharp edges and small parts.

### **WARNING**

FOLLOW ASSEMBLY INSTRUCTIONS. Product must be assembled and anchored on a suitable level surface as instructed (see section X for Assembly Instructions).

### **WARNING**

ENSURE SAFE DISTANCES. Choose a location that allows for minimum safe distances from objects like trees, large rocks, fences, as instructed (see section X for Assembly Instructions for safe distances).

### **WARNING**

WEIGHT CAPACITY. Adhere to all recommendations for number of users and equipment weight limits.

Max 9 occupants (500 lbs) on the elevated fort platform.

Max 2 occupants (130 lbs) on the swings.

Total capacity: 11 occupants (630 lbs)

### **WARNING**

DO NOT MODIFY EQUIPMENT. Never add extra length to chain or rope. The chains or ropes provided are the maximum length designed for the swinging element(s).

### **WARNING**

Ensure suspended climbing ropes, chains, and cables are securely fastened at both ends and cannot be looped back onto themselves.

## **SAFETY CHECKS AND MAINTAINENCE INSTRUCTIONS**

### **WARNING**

Playground equipment and/or surfacing in direct sunlight may reach temperatures high enough to cause serious burn injuries within seconds. Check for hot play surfaces and surfacing before letting children play.

### **WARNING**

Children must be taught safe use practices, including:

- Do not use equipment in a manner other than intended.
- Do not get off equipment while it is in motion.
- Do not walk close to, in front of, behind, or between moving items.
- Do not attach items to the playground equipment that are not specifically designed for use with the equipment, such as, but not limited to jump ropes, clothesline, pet leashes, cables and chain as they may cause a strangulation hazard.

### **SWING SAFETY WARNING**

Failure to follow the below safe practices can result in serious injury.

#### **Children must be taught to:**

- Seat themselves safely, children must sit with full weight in the swing seat center.
- Not to stand on swings.
- Not to jump from moving swings.
- Not push empty swings - they can cause injury to themselves or others.
- Not to twist or loop chains/ropes over beams - this weakens them.
- Never wrap arms or legs around swing chains.
- Never slide down a swing chain.

### **SLIDE SAFETY WARNING**

Failure to follow the below safe practices can result in serious injury.

#### **Children must be taught to:**

- Always go down slide feet first, never headfirst.
- Look before sliding to ensure no one is at the bottom.
- Never run up a slide—this increases fall risk.

## **SAFETY CHECKS AND MAINTAINENCE INSTRUCTIONS**

### **FORT AND CLIMBING WARNING**

Failure to follow the below safe practices can result in serious injury.

#### **Children must be taught to:**

- Not climb when the equipment is wet.
- Never jump from a fort deck—always use the ladder, ramp, or slide.
- Never crawl or walk across the top of equipment.
- Never crawl on top of a fort roof.
- Never look at the sun through accessories like telescopes, periscopes, or binoculars.

### **PROPER DRESS WARNING**

Failure to follow the below safe practices can result in serious injury.

- Children must wear well-fitting shoes that completely enclose feet; no clogs, flip-flops, or sandals.
- DO NOT allow children to wear inappropriate items, such as but not limited to, loose fitting clothing, hood and neck drawstrings, scarves, cord-connected items, capes and ponchos. These items can cause death by strangulation.
- Teach children to remove bike or sports helmets before playing on the playground. These items can cause death by strangulation.

## **SAFETY CHECKS AND MAINTAINENCE INSTRUCTIONS**

### **Before each play session**

- Tighten all hardware but avoid over-tightening to prevent wood from cracking.
- Lubricate all metallic moving parts as needed (See “2.2 Lubrication of Moving Components”).
- Inspect protective coverings on bolts, pipes, edges, and corners. Replace any that are loose, cracked, or missing.
- Check all moving parts—swing seats, ropes, cables, and chains—for wear, rust, or damage. Replace as needed. Replace any swing seat with cracks.
- Inspect metal parts for rust. If found, sand and repaint with a non-lead-based paint.
- Examine wood components for deterioration and splinters. Sand down splinters and replace deteriorated wood. Apply a protective sealant once or twice a year, as required by the warranty (See “2.3 Applying Protective Sealant”).
- Reinstall plastic parts, such as swing seats, that were removed for winter storage.
- Rake and check the depth of loose-fill protective surfacing to prevent compaction and maintain proper cushioning. Replenish as needed.
- Ensure the playset remains level. As children play, the set may shift into the soil-adjust as necessary to keep it stable.
- Ensure legibility of safety warnings.
- Ensure suspended climbing ropes, chains, and cables are securely fastened at both ends and cannot be looped back onto themselves.
- Ensure equipment has not been modified in anyway.
- On sunny and or hot days, skin contacting plastic surfaces (e.g., slides and swing seats) very hot plastic surfaces can cause burns. If needed cool with water prior to use.

### **After each play session:**

- Check for any damaged components, splinters, or cracks.
- Ensure all protective coverings are still in place.
- Ensure all moving components function as intended.

## **SAFETY CHECKS AND MAINTAINENCE INSTRUCTIONS**

### **Twice a month during play session:**

- Tighten all hardware but avoid over-tightening to prevent wood from cracking.
- Check all moving parts—swing seats, ropes, cables, and chains - for wear, rust, or damage.
- Replace as needed. Replace any swing seat with cracks.
- Rake and check the depth of loose-fill protective surfacing to prevent compaction and maintain proper cushioning. Replenish as needed.

### **Once a month during play session:**

- Lubricate all metallic moving parts as needed  
(See “1.2 Lubrication of Moving Components”).
- Check all moving parts—swing seats, ropes, cables, and chains - for wear, rust, or damage. Replace as needed. Replace any swing seat with cracks.

### **When temperature drops below 32 degrees Fahrenheit:**

- Remove plastic swing seats and other specified items per the manufacturer’s instruction. Store indoors or discontinue use.

### **At the end of each play season:**

- Remove plastic swing seats and other specified items per the manufacturer’s instructions. Store indoors or discontinue use.
- Rake and check the depth of loose-fill protective surfacing to prevent compaction and maintain proper cushioning. Replenish as needed.
- Ensure warning labels remain legible and replace them if they become worn or unreadable.

### **Lubrication of Moving Components**

- Use a metal-safe lubricant like WD-40 on all metallic moving parts.
- Avoid using WD-40 on non-metal components, as it may cause damage.
- For non-metal parts (e.g., plastic), use a plastic-compatible lubricant such as silicone lubricant.
- Follow the lubricant manufacturer’s application instructions.
- Apply lubricant sparingly to prevent buildup.
- Wipe off excess lubricant to avoid attracting dirt and debris.

## **SAFETY CHECKS AND MAINTAINENCE INSTRUCTIONS**

### **Applying Protective Sealant**

- Pressure-treated wood must be fully dry before applying a sealer. Depending on the climate, this drying process can take anywhere from a few weeks to several months.
- A simple way to check if the wood is ready for sealing is the “bead test.” Pour a small amount of water onto a horizontal surface. If the water beads up, the wood still contains moisture. If the wood absorbs the water, it is dry enough to be sealed.
- Before sealing, ensure all surfaces are clean, dry, dust-free, and free from any contaminants that could interfere with adhesion.
- Use a sealant specifically recommended for pressure-treated wood and suited to your climate conditions.

### **Safe Deconstruction and Disposal Instructions**

- Keep Children Away: Do not let children play on the playground while dissembling
- Disassemble Safely: Wear proper personal protective equipment (PPE) and start from the top and work downward, removing non-structural components first (e.g., swings, climbing rope, ladder). Identify and support load-bearing components before removing them to prevent collapse, especially on multi-level structures.
- Check for Sharp Points or Edges: Ensure de-construction hasn't resulted in accessible sharp points and edges, check for and safely dispose of any hardware.
- Do Not Burn Treated Wood: Burning releases harmful chemicals into the air and environment.
- Check Local Disposal Rules: Contact local waste management to determine proper disposal options for treated wood.
- Avoid Composting or Chipping: Do not compost or chip treated wood, as it can release chemicals into the soil.

## SAFETY CHECKS AND MAINTAINENCE INSTRUCTIONS

**WARNING**  
**CONTINUOUS ADULT SUPERVISION REQUIRED!**  
**STRANGULATION HAZARD**

**Never allow children** to wear bike or sport helmets when using this playset.

**Never allow children** to play with ropes, clotheslines, pet leashes, cable, chains, or cord-like items when using the playset or to attach these items to the playset.

**Never allow children** to wear loose-fitting clothing, ponchos, hoods, scarves, capes, necklaces, flip-flops, sandals, or items with drawstrings, cords, or ties when using this playset.

Failure to prohibit these items increases the risk of serious injury and death to children from entanglement and strangulation.

### SERIOUS HEAD INJURY HAZARD

- Installation over hard surfaces creates a risk of serious injury or death from falls to the ground. Maintain shock-absorbing material under and around the playset as recommended in the Installation and Operating instructions.

### SERIOUS BURN HAZARD

- Playground equipment and/or surfacing in direct sunlight may reach temperatures high enough to cause serious burn injuries within seconds. Check for hot play surfaces and surfacing before letting children play.
- Refer to the instructions for the maximum number of users, installation, and operating instructions.

## **SAFETY CHECKS AND MAINTAINENCE INSTRUCTIONS**

### **PLAYGROUND SITE SELECTION AND PROTECTIVE SURFACING**

**WARNING: PROPER SITE SELECTION AND INSTALL PROTECTIVE SURFACING DOES NOT ELIMINATE THE NEED FOR ADULT SUPERVISION AND TEACHING CHILDREN SAFE PLAY PRACTICES.**

- Site Selection: Place the equipment on level ground, not less than 6 ft (1.8 m) from any structure or obstruction such as a fence, garage, house, over-hanging branches, laundry lines, or electrical wires (see “Playground Site Diagram”).
- Remove any objects from areas where users might run into, trip, or land when falling or exiting the equipment.
- If site is not level, professional grading may be needed.
- Placement of Protective Surfacing:
- NOTE: MAXIMUM FALL HEIGHT = 76.529"

### **WARNING: INSTALL PROTECTIVE SURFACING**

It is critical that all areas where a child may fall onto or exit equipment is covered with adequate protective surfacing to minimize injury (see “Playground Site Diagram”)

- For Stationary Climbing Equipment and Slides: At a minimum install protective surfacing at least 6 feet in every direction from the equipment's perimeter.
- For Swings: Extend protective surfacing in front and behind the swing to at least twice the height of the swing (measured from the ground to the top of the support structure).
- Depth of Protective Surfacing Material:
  - For equipment up to 60 in./1524 mm tall: Use at least 9 in. (229 mm) of sand or pea gravel.
  - For taller equipment (up to 96 in./2438 mm): Use at least 9 in. (229 mm) of loose-fill material such as wood mulch/chips, engineered wood fiber (EWF), or shredded/recycled rubber mulch.

## **SAFETY CHECKS AND MAINTAINENCE INSTRUCTIONS**

- For equipment less than 48 in. (1219 mm) tall: Use a minimum of 6 in. (152 mm) of protective surfacing. (Less than 6 in. will be too easily displaced or compacted.)
- Initial Fill and Maintenance:
  - Although you might start with a 12 in. (305 mm) layer, it will compress to about 9 in. (229 mm) over time.
  - Because the material will naturally compact, settle, and shift, check it periodically and refill as needed to maintain the minimum depth.
  - Periodically rake, check and maintain the depth of the loose-fill surfacing material. Marking the correct depth on the play equipment support posts will help you to see when the material has settled and needs to be raked and or replenished. Be sure to rake and evenly redistribute the surfacing in heavily used areas.
- Installation Surface Requirements







### **WARNING: Do Not Install Over Hard Surfaces**

DO NOT place equipment on concrete, asphalt, or similar hard surfaces—these can increase injury risks if a fall occurs.

Use Proper Surfacing Material: Grass and dirt are not acceptable as protective surfacing since environmental wear reduces their shock-absorbing effectiveness. Carpeting and thin mats generally do not provide adequate protection.


- Exception for Ground-Level Equipment: Items such as sandboxes, activity walls, or playhouses that have no elevated play surface do not require protective surfacing.
- Containment and Drainage: Use containment, such as digging out around the perimeter and/or lining the perimeter with landscape edging. Don't forget to account for water drainage.
- Poured-In-Place Surfaces or Pre-Manufactured Rubber Tiles:
  - These alternatives generally require professional installation—this is typically not a do-it-yourself project.

## Marking predrilling








Sand end cut to Radius 1/8"

# Tools




1. Handsaw	10. Ratchet
2. Shovel	11. Hex Key
3. Rubber Mallet	12. Bubble Level
4. Hammer	13. Square
5. Ladder	14. Tape Measure
6. Drilling Set	15. Pencil
7. Phillips Screw	16. Sand-paper, grit size: 1/8"
8. Wrench	17. Lighter
9. Scissors	

# Anchoring




all anchoring devices must be placed below the level of the playing surface to prevent tripping or injury resulting from a fall

# Woodlist



<input type="checkbox"/>	 	   	<b>F95B</b>
94.5"	x 3.5" x 3.5"		
<input type="checkbox"/>	 		<b>T95</b>
94.5"	x 1.5" x 3.5"		
<input type="checkbox"/>	 		<b>T87A</b>
86.5"	x 1.5" x 3.5"		
<input type="checkbox"/>	 		<b>T87</b>
86.5"	x 1.5" x 3.5"		
<input type="checkbox"/>	 	<b>T42A</b>	
41.5"	x 1.5" x 3.5"		
<input type="checkbox"/>	 	<b>T32A</b>	
31.5"	x 1.5" x 3.5"		
<input type="checkbox"/>	 	<b>T10</b>	
10"	x 1.5" x 3.5"		
<input type="checkbox"/>	 	<b>O42A</b>	
41.5"	x 0.75" x 3.5"		
<input type="checkbox"/>	 	<b>O42</b>	
41.5"	x 0.75" x 3.5"		
<input type="checkbox"/>	 	<b>O32A</b>	
31.5"	x 0.75" x 3.5"		
<input type="checkbox"/>	 	<b>O29A</b>	
28.5"	x 0.75" x 3.5"		

# Mounting Materials



Screw, 6x70mm, T30, (length: 2-3/4")



Washer, M10



Screw, 8x2", T20, (length: 2")





Washer





Screw, 5x20mm, PZ2, (length: 3/4")



Lock Nut, M10





Carriage Bolt, M10x40mm, (length: 1-5/8")




Hexagon Head Wood Screw, 10x80mm, (length: 3-1/4")


Mounting Bracket, 55x45mm




Carriage Bolt, M10X190mm, (length: 7-1/2")



Cap





Special Cap






O32A 0.75 x 3.5 x 31.5" A long, thin, rectangular metal strip.	O35A 0.75 x 3.5 x 34.5" A long, thin, rectangular metal strip.	O42A 0.75 x 3.5 x 41.5" A long, thin, rectangular metal strip.	T10 1.5 x 3.5 x 9.5" A short, thick, rectangular metal strip.	T32A 1.5 x 3.5 x 31.5" A long, thin, rectangular metal strip.	T42A 1.5 x 3.5 x 41.5" A long, thin, rectangular metal strip.	F65A 3.5 x 3.5 x 65" A very long, thin, rectangular metal strip.
<b>31x</b>	<b>57x</b>	<b>15x</b>	<b>6x</b>	<b>1x</b>	<b>35x</b>	<b>1x</b>
F87 3.5 x 3.5 x 86.5" A long, thin, rectangular metal strip.	F95 3.5 x 3.5 x 94.5" A long, thin, rectangular metal strip.	F95A 3.5 x 3.5 x 94.5" A long, thin, rectangular metal strip.	5x20 PZ 2 A Phillips head screw.	#8x2" T20 A Phillips head screw.	6x70 T30 A Phillips head screw.	Washer A flat, circular metal washer.
<b>2x</b>	<b>4x</b>	<b>3x</b>	<b>97x</b>	<b>416x</b>	<b>148x</b>	<b>97x</b>
Washer M10 A flat, circular metal washer.	Cap A cylindrical plastic or metal cap.	Nut M10 A hexagonal nut.	Special Cap A cylindrical cap with a ribbed base.	Tarp Hammock A diamond-shaped tarp.	Tarp Roof A rectangular tarp.	Tarp Shop A rectangular tarp with a scalloped edge.
<b>3x</b>	<b>3x</b>	<b>8x</b>	<b>4x</b>	<b>1x</b>	<b>1x</b>	<b>1x</b>
Tarp shop A diamond-shaped tarp.	Tarp wall A rectangular tarp with a curved end.	Climbingstone A climbing stone with a hole.	Rope A coiled rope.	Rope Ladder A ladder made of ropes.	Grips A curved metal grip.	Slide Rocli A curved slide rail.
<b>1x</b>	<b>1x</b>	<b>10x</b>	<b>1x</b>	<b>1x</b>	<b>8x</b>	<b>1x</b>
Telescope A telescope with a lens cap.	Wheel A simple wheel.	Ships Wheel A ship's wheel.	Sticker A rectangular sticker.			
<b>2x</b>	<b>2x</b>	<b>1x</b>	<b>1x</b>			


# 1 Tarp cutting plan




## 2 Tarp cutting plan





### 3 Tarp cutting plan



## 4 Tarp cutting plan






## 5 Tarp cutting plan



<b>T95</b> 1.5 x 3.5 x 94.5"	<b>F95A</b> 3.5 x 3.5 x 94.5"	<b>F87</b> 3.5 x 3.5 x 86.5"	<b>T42A</b> 1.5 x 3.5 x 41.5"	<b>6x70</b> T30
<b>1x</b>	<b>1x</b>	<b>1x</b>	<b>5x</b>	<b>20x</b>

## 1 Frame 1



**T95**  
1.5 x 3.5 x 94.5"

**2x**

**T42A**  
1.5 x 3.5 x 41.5"

**1x**

**O42A**  
0.75 x 3.5 x 41.5"

**2x**




**6x70**  
T30


**4x**

**#8x2"**  
T20



**8x**

## 2 Frame 2






### 3 Frame 2 (rear)



**4**



**T42A**  
1.5 x 3.5 x 41.5"







**2x**


**6x70**  
T30







**8x**

**5**







**6**



<b>F95A</b> 3.5 x 3.5 x 94.5"	<b>T87</b> 1.5 x 3.5 x 86.5"	<b>T42A</b> 1.5 x 3.5 x 41.5"	<b>O42A</b> 0.75 x 3.5 x 41.5"	<b>6x70</b> T30	<b>#8x2"</b> T20
<b>2x</b>	<b>1x</b>	<b>4x</b>	<b>2x</b>	<b>16x</b>	<b>8x</b>






## 7 Frame 3




**O42A**  
0.75 x 3.5 x 41.5"  
**2x**

**#8x2"**  
T20  
**8x**

## 8 Frame 3




**9**



Frame 3

**T42A**  
1.5 x 3.5 x 41.5"







**3x**

**6x70**  
T30




**12x**

**10**



**T42A**  
1.5 x 3.5 x 41.5"





**3x**

**6x70**  
T30






**12x**

**11**



**T42A**



**O42A**  
0.75 x 3.5 x 41.5"






**4x**

**#8x2"**  
T20




**16x**

**12**



**O35A**  
0.75 x 3.5 x 34.5"





**#8x2"**  
T20



**11x**

**44x**

**13**



**T42A**  
1.5 x 3.5 x 41.5"





**1x**

**6x70**  
T30



**4x**


**14**



**T42A**

**T**

**6x70**



**49"**

**T42A**  
1.5 x 3.5 x 41.5"






**2x**

**6x70**  
T30



**8x**




**15**




**O35A**  
0.75 x 3.5 x 34.5"  
**12x**





**#8x2"**  
T20  
**48x**

**1**




**2**





**1**



**O32A**  
0.75 x 3.5 x 31.5"



**2x**


**#8x2"**  
T20





**8x**

**1**

**180°**




**90°**



**#8x2"**



**O**

**042**





**2**



**O42A**  
0.75 x 3.5 x 41.5"




**4x**

**#8x2"**  
T20




**16x**



# 1 Climbing 90



**90°**




**2 1/4 "**



**O42A**

**#8x2"**









Climbingstone



5x

## 2 Climbing 90




**T42A**  
1.5 x 3.5 x 41.5"



**1x**

Tarp wall



**1x**

**5x20**  
PZ 2






**6x**



Washer







**6x**

## 1 Wall Tarp







## 2 Wall Tarp








### 3 Wall Tarp







## 2 Roof Tarp





# 1 Roof Tarp



**T32A**  
1.5 x 3.5 x 31.5"




**1x**

**6x70**  
T30






**2x**

## 1 Palm





**T32A**





**2x**  
**2** Palm








#8x2"

T20






### 3 Palm






## 4 Palm



**T42A**  
1.5 x 3.5 x 41.5"



**2x**

**O35A**  
0.75 x 3.5 x 34.5"




**7x**

**#8x2"**  
T20





**28x**


# 1 Ladder 90




**3"**






**O**







## 2 Ladder 90




Rope	#8x2" T20	Special Cap
1x	2x	2x

### 3 Ladder 90

**5x**




Special Cap



Option 1

Option 2




#8x2"

T20



2x


Special Cap



2x




4

Ladder 90



Special Cap

8x2"



**T10**  
1.5 x 3.5 x 9.5"




**2x**

**6x70**  
T30







**4x**

# 1 Shop







## 2 Shop



Tarp	<b>5x20</b> PZ 2	Washer
	 <b>6x</b>	 <b>6x</b>

## 3 Shop



**5x20**  
PZ 2








**8x**

**Washer**




**8x**

## 4 Shop






## 1 Shop Wall





**Tarp**








## 2 Shop Wall






### 3 Shop Wall



**O35A**

**#8x2"**



**T42A**  
1.5 x 3.5 x 41.5"





**2x**


**6x70**  
T30








**8x**

## 1 Hammock





## 2 Hammock




**T10**  
1.5 x 3.5 x 9.5"



**4x**


**Grips**



**4x**

# 1 Monkeygrips


**4x**



**Grip**



**T10**

=  
=



**19 3/4"**

**6 1/4"**






#8x2"

T20




16x

## 2 Monkeygrips





## 2 Ropeladder




**M10x190**

**Cap**

**Washer**

**M10**



**Cap**




**M10**

**Washer**

**M10x190**




**1**



**6x70**  
T30

**2x**

## **2** Slide



Tarp Flag



1x

5x20

PZ 2





3x

Washer




3x

# 1 Flag



Tarp





Residential Use Only

THIS PRODUCT IS INTENDED FOR USE BY  
CHILDREN FROM AGES 3 TO 14

SAVE THESE  
INSTRUCTIONS

# Wickey





**Warning!** Choking Hazard - Small parts! Only for domestic use. For outdoor use only.  
Product must be assembled by an adult. Customer must keep this information





Ages  
3-14




max.  
100 kg








## 1 Anchoring







<b>F95B</b> 3.5 x 3.5 x 94.5"	<b>T87</b> 1.5 x 3.5 x 86.5"	<b>Swing frame connector</b> 	<b>6x70</b> T30	<b>M10X40</b> Carriage Bolt 	<b>Nut M10</b> 	<b>Washer M10</b> 
<b>1x</b>	<b>2x</b>	<b>1x</b>	<b>6x</b>	<b>1x</b>	<b>6x</b>	<b>6x</b>
<b>M10X190</b> Carriage Bolt 	<b>Cap</b> 	<b>55x45</b> Mounting Bracket 	<b>Swing Hook</b> 	<b>Ground Anchor</b> 	<b>Washer</b> incl. with anchor 	<b>Screw</b> incl. with anchor 
<b>1x</b>	<b>6x</b>	<b>1x</b>	<b>4x</b>	<b>2x</b>	<b>2x</b>	<b>2x</b>

Swing frame connector	M10X40 Carriage Bolt	Nut M10	Washer M10	Cap	55x45 Mounting Bracket
<b>1x</b>	<b>1x</b>	<b>1x</b>	<b>1x</b>	<b>1x</b>	<b>1x</b>





## 1 Swing



**F95**  
3.5 x 3.5 x 94.5"

**2x**

## 2 Swing






**6x70**  
T30






**6x**


### 3 Swing











# 1 Swingbeam











## 2 Swingbeam




<b>M10X190</b> Carriage Bolt  <b>1x</b>	<b>Nut M10</b>  <b>1x</b>	<b>Washer M10</b>  <b>1x</b>	<b>Cap</b>  <b>1x</b>
--	--	---	--

### 3 Swingbeam





## Anchoring






F95 3.5 x 3.5 x 94.5"	F95A 3.5 x 3.5 x 94.5"	F95B 3.5 x 3.5 x 94.5"	F87 3.5 x 3.5 x 86.5"	T87 1.5 x 3.5 x 86.5"	F65A 3.5 x 3.5 x 65"	T42A 1.5 x 3.5 x 41.5"
8x	3x	1x	2x	37x	1x	35x
O35A 0.75 x 3.5 x 34.5"	T32A 1.5 x 3.5 x 31.5"	O32A 0.75 x 3.5 x 31.5"	T10 1.5 x 3.5 x 9.5"	5x20 PZ 2	#8x2" T20	6x70 T30
58x	1x	29x	2x	150x	416x	187x
150x	11x	11x	10x	10x80 Hexagone Wood Screw	M10X190 Carriage Bolt	M10X40 Carriage Bolt
10x	4x	5x	1x	4x	2x	1x
1x	1x	1x	2x	1x	1x	1x
2x	5x	2x	2x	1x	2x	1x




# Tarp cutting plan





**T**

## Tarp cutting plan



Swing frame connector  1x	M10X40 Carriage Bolt  1x	Nut M10  1x	Washer M10  1x	Cap  1x
---	--	--	---	--




## 1 Swing Connector



**F95**  
3.5 x 3.5 x 94.5"

**2x**

## 2 Swing Connector






**6x70**

T30


**6x**

### **3** Swing Connector



**4**


## Surfswing



**T32A**  
1.5 x 3.5 x 31.5"  
**6x**

**6x70**  
T30  
**24x**

## 5 Surfswing



**T32A**  
1.5 x 3.5 x 31.5"





**2x**

**6x70**  
T30




**8x**

## 6 Surfswing








**O42**  
0.75 x 3.5 x 41.5"  
  
**3x**

**T10**  
1.5 x 3.5 x 9.5"  
  
**2x**

**#8x2"**  
T20  
  
**12x**



## 7 Surfswing



Tarp Surfboard	5x20 PZ 2	Washer
		

**1x**      **14x**      **14x**



## 8 Surfswing



**9**

## Surfswing





11/64"





## 10 Surfswing

**2x**



**Restrictingband**

cut to 33 1/2"




**2x**

## 11 Surfswing

**2x**





**Restrictingband**



<b>Surfstrap</b> cut to 134"	<b>Restrictingband</b> cut to 33 1/2"	<b>5x20</b> PZ 2 	<b>Washer</b> 
<b>2x</b>	<b>2x</b>	<b>8x</b>	<b>8x</b>

## 12 Surfswing



**5x20**  
PZ.2






**4x**

**Washer**








**4x**

## 13 Surfswing



**Washer**

**5x20**



**5x20**  
PZ 2



**12x**


**Washer**



**12x**

**14**


**Surfswing**



**5x20**


**3.**

**Washer**




**2.**


**1.**




**1.**



**2.**



**3.**



**5x20**  
PZ 2




**6x**

**Washer**





**6x**


## 15 Surfswing



**5x20**






**Washer**





## 16 Surfswing

**Hammock**



Grips



2x

M6X40




4x

17



Surfswing



M6X40







Hand Grip





<b>5x20</b> PZ 2	<b>Washer</b>  <b>8x</b>	<b>Tarp Arch</b>  <b>1x</b>	<b>Tarp Opening</b>  <b>1x</b>
---------------------	---	--	---

## 18 Surfswing





## 19 Surfswing



# Notes

## Inspection and Maintenance report

Date of inspection	Defect	Eliminated



Wickey Corporation  
4001 Calhoun Ave Chattanooga, TN 37407

+17042471104  
[wickey.com](http://wickey.com)

© WICKEY Corporation