AceroALF 1.0 — Installation guide

Automatic rebar modeling for Autodesk® Revit® 2023 – 2027 · ALF_BIM

Before you start

- 64-bit Windows 10 or 11, with Revit 2023, 2024, 2025, 2026 or 2027 installed.
- Administrator rights on the PC, because Windows asks for them during installation.
- **Close Revit** before installing.

1. Install

1 Open the installer

Double-click **AceroALF_1.0.0_Setup.exe** and accept the Windows prompt “Do you want to allow this app to make changes?”.

2 If “Windows protected your PC” appears

This is normal for software from independent developers who do not yet have a commercial code-signing certificate. It does not mean the program is harmful. Click **More info** and then **Run anyway**.

If your antivirus asks, allow the file. Only download AceroALF from ALF_BIM’s official channels.

3 Choose the language

Español or English. AceroALF will open in that language; you can change it later with the **Settings** button.

4 Accept the license agreement

Read it and select “I accept the agreement”.

5 Installation folder

The default is `C:\Program Files\ALF_BIM\AceroALF`. You can change it with **Browse…**, for example to another drive.

6 Revit versions

Keep **“Automatically detect the installed Revit versions”**: the installer selects the versions you have. To choose yourself, use “Choose the Revit versions manually”.

7 Install

Click **Install** and then **Finish**.

2. First start in Revit

1 Revit security prompt

The first time, Revit shows “Security – Unsigned Add-In” for **AceroALF**. Choose **Always Load** so it does not ask again.

2 AceroALF tab

The **AceroALF** tab appears in the Revit ribbon.

3 Request your free 14-day trial

Click the **License** button (or any AceroALF command). Under «Free 14-day trial» enter your name and email and click **Send me the code**. You will receive a 6-digit code by email (also check spam): enter it and click **Start trial**. You get all features for 14 days. Internet is needed only at that moment. One trial per person and per PC.

3. Activate your license

1 Copy your PC ID

In Revit, go to the AceroALF tab, **License** button, and copy the **Machine ID** (format `XXXX-XXXX-XXXX-XXXX`).

2 Choose your plan and send your ID

Email **andersonirigoin@gmail.com** with your name, the plan and your Machine ID. You will receive a payment link.

3 Paste the key

Once payment is confirmed you will receive a key starting with `ALF1-`. Paste it complete in the **License** window and click **Activate**.

Plan	1st month	Monthly	3 months	6 months
ALL-IN-ONE (1 PC)	$9	$18	$49	$89
BUSINESS (3+ PCs, per license)	$7.50	$15	$42	$78
STUDENT	Free for 3 months with a current proof of enrollment (answer within 24 h). Non-commercial use, with watermark.			

Launch prices in US dollars (USD). All plans include all features. Each license works on one PC; if you change PCs, email us your new ID.

4. Troubleshooting

Problem	Solution
The AceroALF tab does not appear	Run the installer again and select your Revit version. If you chose “Do Not Load” in the security prompt, reinstall and choose “Always Load”.
“The key signature is not valid”	The key was copied incomplete. Copy it again, in full, from `ALF1-` to the end.
“The saved license belongs to another machine”	The key was used on a different PC. Send us this PC’s ID.
“The computer date is earlier…”	Correct the Windows date and time (Settings → Time & language → “Set time automatically”).
The antivirus blocks the installer	Add an exception for the file or restore it from quarantine. If it persists, email us.

5. Uninstall

Go to Windows Settings → **Apps**, find **AceroALF** and click **Uninstall**. Your license is kept: if you reinstall on the same PC, it stays active.

AceroALF 1.0 · © 2026 Ing. Anderson Irigoín C. — ALF_BIM · Autodesk and Revit are registered trademarks of Autodesk, Inc.