




SportShield

User Guide



Everything you need to know about your device



Contents


| | |
|----------------------------------------------|-----------|
| Your SportShield | 3 |
| Your SportShield | 3 |
| Set up and get started | 4 |
| First steps with SportShield | 4 |
| Pair SportShield with your phone | 5 |
| Connect the device | 5 |
| ● Using Bluetooth | 7 |
| ● Using NFC | 8 |
| Unpair the device | 10 |
| Status of the device | 11 |
| Locate the device | 12 |
| Charge your device | 15 |
| Notifications | 15 |
| How to use SportShield | 16 |
| Lock/Unlock the device | 16 |
| Activate/Deactivate alarm | 18 |
| Get help | 20 |
| Update device software | 20 |
| Sell your SportShield | 20 |
| Get information about your SportShield | 21 |
| Other ways to view the User Guide | 22 |
| Safety and handling | 23 |
| Important safety information | 23 |
| Disposal and recycling information | 25 |



Your SportShield

Your Sportshield

This guide helps you get started to use SportShield and to discover the features it offers. Your device should look like this:





Set up and get started

⚠️ WARNING: This project is a prototype and is currently under development. Thus this user guide is prone to receive changes. Nevertheless, we will try to explain features that are yet to be implemented. The application doesn't currently support the English language, explaining why all the screenshots are in French.

First steps with SportShield

Getting started

It takes just a few minutes to get up and running with SportShield.

Installing the SportShield application is mandatory as the device will NOT work without it.



Pair SportShield with your phone


To set up your SportShield, turn on your phone and open the SportShield application. You should arrive on this menu:





Connect the device


Now you can either choose to pair your device to your phone using Bluetooth or NFC. Click on whichever you want to connect your phone with.





Using Bluetooth


The next step is to choose a name for your device. Once done choosing your name, make sure that you have activated Bluetooth and click on the scan button:






Using NFC

For NFC, you will first have to scan the QR code present at the back of your device.






Once connected to the device, you will then have the opportunity to name it as you desire.





Pair more than one device

You can pair more than one device, in the same way you connected your first one. Either using Bluetooth or NFC. You will find all the devices previously connected to your phone in this section:





Status of the device


You will see in the list every device, their individual status (online, sleep mode, and offline), and you will also see their location, the time when the device was set, and their current battery level.





Locate the device

In order to locate the device, click on the purple button at the bottom of your screen, you will have to allow the access to device location, as you can see on the screenshot below:





After giving access to your phone location, you will access the map (based on the Google maps one), and will be able to see where your paired devices are located.




When clicking on a pinpoint, you will be able to see the current status of your device, with a similar interface as seen previously (p.11).






In case there are no devices paired with your phone you will be prompted with this window.





Charging your device



1. In order to charge your device, you will need an USB-C charger.

2. Plug your charger in the designated area.

3. Your device now should be charging!

Notifications

When a shock is detected, a notification will be sent to the user alerting them.

SportShield App

10h39

**⚠ John's device detected a shock in La Plagne !
L'Escapade, Résidence 3000, 73210 La Plagne-Tarentaise**

Every 2 hours, if there is nothing to report, a notification will be sent to the user to tell them everything is okay. The user can choose the time between those notifications if they find them too repetitive.

SportShield App

12h35

**✓ No report for Anna's device.
Tetras Lyre, Rue de la Glisse, 73210 La Plagne-Tarentaise**



How to use the device

Locking the device

In order to lock the device and secure your snow gear, proceed as follows:



1. Make sure your device is activated and paired to your application.



2. Pull the cable around your snowboard.



3. Your anti-theft is now protecting your gear from the thieves!



Unlocking the device

In order to unlock your device, proceed as follows:



1. The device is locked.



2. Use the NFC feature to unlock your device.



3. Your device is unlocked and you can have fun again!



Activating the alarm

The alarm will automatically activate when it detects a shock. (Note that the alarm decibel rate is set at 130 dB)



1. A shock is detected.



2. The alarm starts ringing.



Deactivating the alarm

In order to deactivate the alarm, proceed as follows:



1. The alarm is ringing.



2. Use the NFC feature to stop the alarm from ringing.



3. The alarm stops ringing!



FAQ

Update device software

You can update your SportShield software by checking for updates in the Play Store  if you are on Android, or using the App Store  for iOS users.

Sell your SportShield

Before you sell or give away your SportShield, be sure to unpair it from your phone and application.

Unpair SportShield from your phone

If you paired your device using Bluetooth:

1. Open the settings of your phone.
2. Go to the Bluetooth section.
3. In the “devices already connected to the phone” section, click on SportShield.
4. Click on “Forget the device”.

If you paired your device using NFC:

1. In your application, open the list of paired devices.
2. Click on the device you want to unpair.
3. On the new window, click on unpair the device.
4. Your SportShield is now unpaired.



Get information about your SportShield

See information about SportShield

On your application, open the list of paired devices., then click on the device you want to see the information and on the new window click on device information. The items you can view include:

- Name
- Software version
- Model number
- Serial number
- Network
- MAC and Bluetooth addresses
- Legal Info

You can also view this information on the settings section, tap Legal to view Legal Notices, License, information on where to find the warranty and RF Exposure information.



Other ways to view the SportShield User Guide

You can watch the SportShield User Guide on your phone in the SportShield App or in your browser. You can also download a PDF of the user guide.

View the user guide from SportShield App

1. Open the SportShield app on your phone.
2. Tap on the Settings icon .
3. Tap on the Help section.
4. Tap SportShield User Guide.

SportShield Support

To contact us for personalized support, see [our website](#).



Safety and Handling

⚠️ WARNING: Failure to follow these safety instructions could result in fire, electric shock, injury, or damage to SportShield or other property. Read all the safety information below before using SportShield.

Handling SportShield contains sensitive electronic components and can be damaged if dropped, burned, punctured, or crushed. Don't use a damaged SportShield, such as one with a cracked case, as it may cause injury. Avoid heavy exposure to dust or sand.

Repairing Don't open SportShield and don't attempt to repair it yourself. Disassembling SportShield may damage it, result in loss of water resistance, and may cause injury to you. If SportShield is damaged or malfunctions, contact Coris or an authorized service provider.

Battery Don't attempt to replace the SportShield battery yourself, you may damage the battery, which could cause overheating and injury. The lithium battery in SportShield should be serviced only by Coris or an authorized service provider. Batteries must be recycled or disposed of separately from household waste. Don't incinerate the battery.

Charging Using damaged cables or chargers, or charging when moisture is present, can cause fire, electric shock, injury, or damage to SportShield or other property.

Hearing Loss Listening to sound at high volumes may damage your hearing. Background noise, as well as continued exposure to high volume levels, can make sounds seem quieter than they actually are.

WARNING: To prevent possible hearing damage, do not stay too close to the alarm for too long.



Choking hazard Some SportShield cables may present a choking hazard to small children. Keep these cables away from small children.

Exposure to liquid SportShield is water resistant but not waterproof. You may, for example, use it during a snowy day and the device will still work perfectly fine.

Operating temperature SportShield is designed to work best in extremely cold temperatures between -4° and 77° F (-20° and 25° C) and be stored in temperatures between -4° and 113° F (-20° and 45° C). SportShield can be damaged and battery life shortened if stored or operated outside of these temperature ranges.

Placement and mounting Ensure that SportShield is securely mounted or placed in a location that is not easily accessible to potential thieves. Avoid placing it in areas where it may be subject to impact or tampering.

False alarm prevention SportShield has been designed to detect and differentiate different types of shocks. Meaning that the likeliness of false alarm activation is low. But the alarm may still be falsely triggered due to movement and environmental factors.



Disposal and recycling information for SportShield



Disposal and Recycling Information

The symbol above means that according to local laws and regulations your product and/ or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

Battery service

The lithium battery in SportShield should be serviced by Coris or an authorized service provider. You may receive a replacement SportShield when ordering battery service. Batteries must be recycled or disposed of separately from household waste.

This guide is provided for reference only. The actual product, including color, size and screen layout, may differ. The statements, information and recommendations in this guide do not constitute a warranty, express or implied.



Every effort has been made to ensure that the information in this manual is accurate. Coris is not responsible for printing or clerical errors.

Some apps are not available in all areas. App availability is subject to change

©2015-2024 Coris Innovation. All rights reserved. Coris Innovation and the Coris Innovation logo are trademarks or registered trademarks of Coris Innovation.

