
ENKU Base R144 | NO FAB


F.Cu - top copper



Unmirrored board coordinates. Engineering view; use paired Gerber/drill data for CAM.

ENKU Base R144 | NO FAB

In1.Cu - inner copper




Source 676c157fb58c1d5b689b... | native KiCad 10.0.7 | 2/10

Unmirrored board coordinates. Engineering view; use paired Gerber/drill data for CAM.

ENKU Base R144 | NO FAB


In2.Cu - inner copper



Unmirrored board coordinates. Engineering view; use paired Gerber/drill data for CAM.

ENKU Base R144 | NO FAB


B.Cu - bottom copper, unmirrored



Unmirrored board coordinates. Engineering view; use paired Gerber/drill data for CAM.

ENKU Base R144 | NO FAB


F.Mask - openings



Unmirrored board coordinates. Engineering view; use paired Gerber/drill data for CAM.

ENKU Base R144 | NO FAB


B.Mask - openings



Unmirrored board coordinates. Engineering view; use paired Gerber/drill data for CAM.

ENKU Base R144 | NO FAB


F.Paste - top stencil



Unmirrored board coordinates. Engineering view; use paired Gerber/drill data for CAM.

ENKU Base R144 | NO FAB


B.Paste - intentionally empty



No bottom paste apertures. Actual closed outline shown for orientation.

ENKU Base R144 | NO FAB

F.Fab - assembly and pad numbers




Source 676c157fb58c1d5b689b... | native KiCad 10.0.7 | 9/10

Unmirrored board coordinates. Engineering view; use paired Gerber/drill data for CAM.

ENKU Base R144 | NO FAB

B.Fab - service references



Unmirrored board coordinates. Engineering view; use paired Gerber/drill data for CAM.