



Electrical Safety Around Pools and Resorts

Water and electricity... precautions that allow no negligence

"The presence of electricity near water requires extra precautions to protect lives and prevent electric shock"



Why Do We Care About This Topic?

Electricity is used in lighting, pumps, and filtration devices



Preventing shock

the biggest danger with water



Protecting children

the family, and visitors



Reducing fires

and electrical faults



Protecting facilities

pools and resorts



Raising awareness

when using devices



Regular maintenance

and monitoring equipment

Remember: Water increases the danger of electricity, so it must be handled with great caution



Key Electrical Risks Around Pools

They appear due to unsafe wiring or unsuitable devices



Electrical devices near water



Exposed or damaged wiring



Connections not rated for wet conditions



Touching devices with wet hands



Unmaintained lighting and pumps



Chargers and speakers near the edge



Children near connections

Message: Any electrical connection or device near water needs inspection, certification, and maintenance



The Basic Safety Rule

Keep devices and connections away from water and wet areas



**No devices
near the pool
edge**



**No chargers
near water**



**Don't touch
devices with
wet hands**



**No wiring in
walkways**



**No equipment
not rated for
wet conditions**



**Report any
danger to a
specialist**



**Request
regular
inspection**

Remember: Staying away from the danger is better than trying to handle it



Electronic Devices Around the Pool

Contact with water can cause an electrical hazard

Don't use them with wet hands

5

Avoid devices near the pool edge

1

Don't pick up a connected device from the water

6

Don't charge devices near water

2

Unplug devices before approaching

7

Don't place chargers on wet floors

3

Keep them out of children's reach

8

Keep devices in a dry spot

4

Important Message: Recreation must not come at the expense of safety



Lighting, Pumps, and Operating Equipment

They must be designed and installed to safety requirements



**Installation by
specialists**



**Regular
maintenance**



**Don't run
damaged
equipment**



**Report
repeated
overheating**



**Don't open
electrical
boxes**



**Don't touch
with wet hands**




**Stop when a
fault is
suspected**

Remember: Pool electrical equipment must only be handled by specialists



Temporary Wiring and Connections

They can be dangerous if they are near water



No temporary connections near the pool

1

No wires in walkways

2

No damaged wiring

3

No wires under carpets

4

Certified power sources

5

Unplug what's not in use

6

Request a specialist's inspection

7

Message: A temporary connection in a wet area can become a direct hazard



Safety During Bad Weather

Rain and storms increase the danger of electricity around water

Don't use faulty equipment

5

Follow management's instructions

6

Don't return before confirming safety

7

Follow the official weather alerts

8

Turn off devices during rain

1

Stay away from pools during thunder

2

Don't touch wet boxes

3

Unplug devices safely

4

Remember: Bad weather can increase the combined danger of electricity and water



Protecting Children and Visitors

They may not realize the danger of electricity around pools



**Supervise
children
continuously**



**Keep them
away from
electrical
rooms**



**Don't allow
touching the
connections**



**No devices
near water**



**Direct visitors
to comply**



**Report unsafe
behavior**



**Teach children
the danger of
electricity**

Message to Employees: Supervision and guidance protect the most vulnerable groups



Electrical Warning Signs Around Water

Signs that call for an immediate stop



Exposed or damaged wiring



A burning smell or heat



Unusual flickering



Frequent power outages



Abnormal sounds



Wet boxes

A feeling of electric tingling Visitors rely on the facility's staff to know the correct action during an emergency

**Move away
immediately, move
others away, and
inform the person in**



The Most Vulnerable Groups Around Pools

Some groups need extra care



Children

Playing near connections



The elderly

Limited mobility near water



People of Determination

Difficulty getting out quickly



New visitors

Unfamiliar with the facility



Swimmers

Direct contact with water



Maintenance workers

Handling electrical equipment

Message: Safety covers everyone and requires accounting for each group's needs



What Do You Do When You Suspect an Electrical Hazard?

Don't approach or try to fix it



Move away from the source of danger



Don't touch the device or wiring



Don't enter the water when in doubt



Move children and visitors away



Inform the person in charge or a specialist



Don't put yourself at risk



Call 999 in case of danger



Wait for the specialists to intervene

Remember: Approaching carelessly can injure more than one person



Special Cases in Pool Electricity

Some situations call for extra caution



**Maintaining
underwater
lighting**



**Running the
pumps for the
first time**



**Renovating
pools and
resorts**



**Installing new
devices**



**Cleaning
electrical
boxes**



**Operating
during peak
season**



**When power
cuts out and
returns**

Important Message: Every electrical job around the pool needs planning and precautions



Communication and Reporting an Electrical Hazard

A clear report speeds up the arrival of help



Example of a clear report:

"There is abnormal flickering in the pool lighting, and users have been moved away from the water"



State the
location
precisely



Mention the
type of danger



Report the
injured



Avoid spreading
unconfirmed
information

Remember: An accurate report saves lives and speeds up the arrival of help



Do's and Don'ts Around Pools and Resorts

Correct Practices and Others to Avoid

Don't ×

- Don't use devices near the edge
- Don't charge near water
- Don't touch them with wet hands
- Don't use damaged wiring
- Don't approach wet boxes
- Don't enter the water when in doubt
- Don't ignore the warning signs

1

2

3

4

5

6

7

Do ✓

- Keep devices away from water
- Use equipment rated for wet environments
- Report any fault immediately
- Watch the children and visitors
- Follow management's instructions
- Request maintenance from specialists
- Call 999 when needed

1

2

3

4

5

6

7



Interactive Scenarios

Practical Application of What You've Learned

Scenario 2

You noticed abnormal flickering in the pool lighting

Correct Action: Inform the person in charge immediately, and avoid using the pool until it's inspected

Scenario 1

A device connected to its charger fell near the pool

Correct Action: Don't touch it, move away, cut the power safely, and inform the person in charge

Scenario 4

You felt a slight tingle when touching the pool edge

Correct Action: Get out immediately, inform the person in charge, and don't let others use it

Scenario 3

A child is trying to touch a connection near a wet area

Correct Action: Move the child away immediately, and inform the person in charge to remove the danger



Test Your Knowledge

Quick Questions to Assess Your Understanding

Q1: Is it allowed to charge electronic devices near the pool?

Answer: No, chargers and devices must be kept away from water



Q2: What do you do if you notice exposed wiring near the pool?

Answer: I move away from the site and inform the person in charge or a specialist immediately



Q3: Is it allowed to touch devices with wet hands?

Answer: No, because that increases the risk of electric shock



Q4: Why don't we use the pool when an electrical fault is suspected?

Answer: Because water can carry the danger and injure people



Q5: Who should handle the pool's electrical equipment?

Answer: Specialists only





Thank You

Electrical safety around pools and resorts is everyone's responsibility

Electricity away from water • No chargers near the pool • Report faults • Watch children • 999

"Enjoying water facilities starts with following safety guidelines"