



# PMR4000RMKII Control command list



# Command list PMR4000RMKII

# 1. TABLE OF CONTENT

| 2. | ОВЛ   | ECTIVE  |                        | 3                       |
|----|-------|---------|------------------------|-------------------------|
| 3. | CON   | IFIGURI | E THE COMMUNICATION    | 4                       |
| 4. | SEN   | р сом   | MANDS TO PMR4000RMKII  | 5                       |
| 5. | PMF   | R4000R  | MKII Responses         | 6                       |
|    | 5.1   | REPLY   |                        | 6                       |
| 6. | CON   | /MAND   | ) LIST Error           | ! Bookmark not defined. |
|    | 6.1   | GET D   | EVICE                  | 7                       |
|    | 6.2   | CREAT   | E SESSION              | 7                       |
|    | 6.3   | DELET   | E SESSION              | 11                      |
|    | 6.4   | GET N   | OTIFIES                | 11                      |
| 7. | netF  | Remote  | Error                  | ! Bookmark not defined. |
|    | 7.1   | PLAY.   |                        | 12                      |
|    | 7.1.  | 1 P     | LAY.SHUFFLE            | 12                      |
|    | 7.1.  | 2 P     | LAY.REPEAT             | 14                      |
|    | 7.1.3 | 3 P     | LAY.RATE               | 15                      |
|    | 7.1.4 | 4 P     | LAY.POSITION           | 17                      |
|    | 7.1.  | 5 P     | LAY.CONTROL            | 18                      |
|    | 7.1.0 | 6 P     | LAY.INFO               | 20                      |
|    |       | 7.1.6.1 | L PLAY.INFO.DURATION   | 21                      |
|    |       | 7.1.6.2 | PLAY.INFO.NAME         | 21                      |
|    |       | 7.1.6.3 | B PLAY.INFO.ALBUM      | 22                      |
|    |       | 7.1.6.4 | PLAY.INFO.ARTIST       | 22                      |
|    |       | 7.1.6.5 | 5 PLAY.INFO.TEXT       | 23                      |
|    |       | 7.1.6.6 | 5 PLAY.INFO.GRAPHICURI | 23                      |
|    | 71    | 7 D     | Ι ΔΥ ΣΤΔΤΙΙς           | 2/1                     |



|    | 7.2 ľ | NAV      | 25  |
|----|-------|----------|---|
|    | 7.2.1 | NAV      | NUMITEMS25  |
|    | 7.2.2 | NAV      | 7.LIST  |
|    | 7.2.3 | NAV      | 7.ACTION  |
|    | 7     | 7.2.3.1  | NAV.ACTION.NAVIGATE                               |
|    | 7     | 7.2.3.2  | NAV.ACTION.SELECTITEM                             |
|    | 7.2.4 | NAV      | '.STATE   |
|    | 7.3   | SYSTEM . |   |
|    | 7.3.1 | SYST     | ΓΕΜ.MODE  |
|    | 7.3.2 | SYST     | ΓΕΜ.INFO  |
|    | 7     | 7.3.2.1  | SYSTEM.INFO.FRIENDLYNAME                          |
|    | 7     | 7.3.2.2  | SYSTEM.INFO.VERSION                               |
|    | 7     | 7.3.2.3  | SYSTEM.INFO.RADIOID                               |
|    | 7.3.3 | SYST     | ΓΕΜ.AUDIO   |
|    | 7     | 7.3.3.1  | SYSTEM.AUDIO.MUTE                                 |
|    | 7     | 7.3.3.2  | SYSTEM.AUDIO.VOLUME                               |
|    | 7     | 7.3.3.3  | SYSTEM.AUDIO.EQPRESET                             |
|    | 7     | 7.3.3.4  | SYSTEM.AUDIO.EQLOUDNESS                           |
|    | 7     | 7.3.3.5  | SYSTEM.AUDIO.EQCUSTOM                             |
|    | 7.3.4 | SYST     | TEM.POWER42                                       |
|    | 7.3.5 | SYST     | TEM.CAPS.EQPRESETS                                |
| 3. | SUMN  | MARY     | 45  |
| Э. | EXAM  | 1PLES    | 49  |
|    | 9.1 E | Example  | 1: How to activate Media player and select a song |
|    | 9.2 E | Example  | 2: How to configure the EQ                        |
|    | 9.3 E | Example  | 3: How to select FM radio and change the channel  |
|    | 9.4 E | Example  | 4: How to select Ethernet radio62                 |



# 2. OBJECTIVE

The objective of this manual is to help the installer to create an external control system which includes the Apart PMR4000RMKII via the Ethernet connection.

With this command list and programs such as commandfusion guiDesigner he will be capable to create a new app to control the PMR4000RMKII.

Beware: The manual doesn't explain programs like commandfusion guiDesigner. For more information about the program check their site

http://www.commandfusion.com/software/guidesigner



# 3. CONFIGURE THE COMMUNICATION

- First Step: Connect the PMR4000RMKII with the network
  - 1. Press the MENU button
  - 2. Go to "SYSTEM SETTINGS"
  - 3. Go to "NETWORK"
  - 4. Go to "MANUAL SETTINGS"
  - 5. Select the network type "WIRED" or "WIRELESS"
  - 6. Select between "DHCP enable" or "DHCP Disable"
- Second Step: Find the PMR4000RMKII IP-address
  - 1. Press the MENU button
  - 2. Go to "SYSTEM SETTING"
  - 3. Go to "NETWORK"
  - 4. Go to "VIEW SETTINGS"
  - 5. IP address: X.X.X.X
- > Third Step: Find the PMR4000RMKII NetRemote PIN
  - 1. Press the MENU button
  - 2. Go to "SYSTEM SETTINGS"
  - 3. Go to "NETWORK"
  - 4. Go to "NetRemote PIN Setup"
  - 5. Installer enters a new PIN (4 Digits) and press OK



# 4. SEND COMMANDS TO PMR4000RMKII

The communication is platform independent. Any internet browser can be used for sending commands. (Internet Explorer, Firefox,...)

The basic command structure is as follows:

COMMAND = http://x.x.x.x/Command

1. Use the PMR4000RMKII IP-address → X.X.X.X

**X.X.X.X** is the PMR4000RMKII IP-address, 192.168.0.87 in the above example, this IP address will be used in all following examples, the real IP address of your device should be entered in each case.

**2.** The required command can be selected from the full command list below.



# 5. PMR4000RMKII Responses

When a command is sent to the unit, it will always send a response back.

# **5.1 REPLY**

When the user sends a valid command and uses the current SessionID and PIN. The unit will reply with the requested information or with a valid response.

When one of these parameters isn't valid the reply will begin with an Error.

#### ➤ 404 NOT FOUND

The user has send a wrong SessionId or invalid command

#### > 403 Forbidden

The user has send a invalid PIN

The unit will check the command and values and will send a reply according to the values.

# FS\_OK

When the value is valid and within the range of the command

# ➤ FS\_FAIL

When the value isn't in the range of the command, this means that the command hasn't been executed.

# FS\_PACKET\_BAD

When a command can't be SET, it will reply with "PACKET\_BAD"

# FS\_NODE\_BLOCKED

Certain commands can only be used when the unit is in the correct mode.

Commands to control the Music player can only be used when the unit system mode is set to "Music Player".



# CONFIGURATION COMMANDS

# **6.1 GET DEVICE**

This command is used to find the units name and version number.

This is the only command when you do not have to send the PIN number.

COMMAND = http://192.168.0.87/device

# **6.2 CREATE SESSION**

There are two ways to control the unit:

| SESS                       | SION                                    | NO SESSION     |                                 |
|----------------------------|---|----------------|---------------------------------|
| +                          | -                                       | +              | -                               |
| 1 User                     |   |                |                                 |
| No conflicts between users | Need to create a new session every time | Multiple users | Possible conflict between users |

If only a single controlling device will be present then setting up a session is not required. If multiple controlling devices will be present then to avoid conflicts a session should be setup between each controlling device and the PMR4000RMKII.



a. Session – setup a private session and use a sessionID

# COMMAND = http://192.168.0.87/fsapi/CREATE\_SESSION?pin=1234

If you set up a private session, you need to enter the PIN that was entered in "3. Configure the communication".

Each controlling device can create a private session, the unit would follow the commands until the session has ended or another user has created a new one.

As long you keep sending the current sessionID the unit will respond and execute the commands and other commands with a different sessionID will get a "404 NOT FOUND" error.



Every user is always capable of starting a new session even when another user is already in a session. This means that the unit will listen to the new sessionID and ignore the previous sessionID.




b. No Session - Send the command directly to the unit.

Every command that is sent straight to the unit will be executed. This will not end the current sessionID.


#### **Examples:**

Current SessionID = 180763961

- 1. The First command has used the correct sessionID
  - ⇒ Valid answer
  - ⇒ The command has been executed




- 2. The second command has used an incorrect sessionID
  - ⇒ Invalid answer "404 NOT FOUND"
  - ⇒ The command hasn't been executed





# The third command hasn't used a sessionID

- **⇒** Valid answer
- ⇒ The command has been executed



NOTE: Controllers with a different sessionID will get a "404 NOT FOUND" error. BUT, a controller who doesn't use a sessionID will get a valid response and their commands will be executed.



## **6.3 DELETE SESSION**

When a user wants to end the session, it is done by sending the following command.

COMMAND = http://192.168.0.87/fsapi/**DELETE\_SESSION**?pin=1234&sid180763961

#### **6.4 GET NOTIFIES**

This command can be used to retrieve information. The reply depends on the current system mode configuration.

COMMAND= http://192.168.0.87/fsapi/GET\_NOTIFIES?pin=1234&sid=98415405

```
### Attp://192.168.0.87/fsapi/GET_NOTIFIES?pin=1234&tsid=98415405
                                                                  0-0
                                                                          2 192.168.0.87
<?xml version="1.0"?>
<fsapiResponse>
   <status>FS_OK</status>
  - <notify node="netremote.sys.mode">
     - <value>
           <u32>0</u32>
       </value>
   </notify>
 - <notify node="netremote.play.info.name">
     - <value>
           <c8_array>105 Hip Hop & R'N'B</c8_array>
       </value>
  </notify>
 - <notify node="netremote.play.status">
      - <value>
          <u8>2</u8>
       </value>
   </notify>
</fsapiResponse>
```

NOTE: The unit will only execute this command if the user sends a Session ID.

If the user sends this command straight to the device (without a Session ID) Reply:

```
HTTP/1.0 404 Not found
Content-Type: text/xml
404 Error
```

# CONTROL COMMANDS



In this chapter we will show and explain the commands to control the unit.

# 7.1 **PLAY**


#### 7.1.1 PLAY.SHUFFLE

The user can request the status of the music player shuffle mode or activate / deactivate the shuffle mode himself.

# **GET PLAY.SHUFFLE**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.play.shuffle?pin=1234

\*In these examples I send the commands straight to the device without setting up a session. To clearly show the important parts of the commands.



The response value can be found in the line <value><u8>0</u8></value>

→ The value of the shuffle = 0

Which means it's inactive.

| VALUE | STATUS   |
|-------|----------|
| 1     | Active   |
| 0     | Inactive |



#### **SET PLAY.SHUFFLE**

COMMAND = http://192.168.0.87/fsapi/SET/netRemote.play.shuffle?value=1&pin=1234

There are two differences between the SET and GET commands.

➢ GET →SET

The third parameter change into a SET command.

➤ Value = 1

The new value needs to be added to the command. This part will be placed between the command and the PIN

NOTE: After the value there is a "&" symbol placed, this shows the unit where the command ends and that the PIN begins.



Reply

Status = FS\_OK

Which means the value was accepted and executed

| VALUE | STATUS     |
|-------|------------|
| 1     | Activate   |
| 0     | Deactivate |




## 7.1.2 PLAY.REPEAT

The user can request the status of the music player repeat mode or activate / deactivate the repeat mode himself.

# **GET PLAY.REPEAT**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.play.repeat?pin=1234



# **SET PLAY.REPEAT**

COMMAND = http://192.168.0.87/fsapi/SET/netRemote.play.repeat?value=1&pin=1234

The repeat command has two possible values.

➤ Value = 1

| VALUE | STATUS     |  |
|-------|------------|--|
| 1     | Activate   |  |
| 0     | Deactivate |  |

When you want to activate the repeat mode, you need to send value = 1.

➤ Value = 0

When you want to deactivate the repeat mode, you need to send value = 0.





## 7.1.3 PLAY.RATE

With this command is the user capable of pause, play, fast forward and rewind the music.

The value has a range between -127 to 127. The value can be divided between 4 categories.

| VALUE      | STATUS       |
|------------|--------------|
| -127 to -1 | Rewind       |
| 0          | PAUSE        |
| 1          | PLAY         |
| 2 to 127   | Fast forward |

#### > -127 to -1

When the user sends a negative value, the music player will rewind the track.

The speed depends on the value, - 10 will rewind faster than value -2

#### > 0

When the user send rate =  $0 \rightarrow$  the track will be paused

#### **≻ 1**

The track will be played with normal speed

# > 2 to 127

The track will be fast forwarded, the speed is here also dependable of the value

The speed of the fast forward is also dependable of the value →80 is faster than 10



#### **GET PLAY.RATE**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.play.rate?pin=1234

# **SET PLAY.RATE**

COMMAND = http://192.168.0.87/fsapi/SET/netRemote.play.rate?value=1&pin=1234



NOTE: REWIND or FAST FORWARD is only activated for 1 track, when the track reaches the end. The music player will pause. The user needs to change the rate to value = 1 (it will start the next track after FAST FORWARD or play the same track after REWIND) OR give PREV or NEXT command to play the next /previous track (this track will be automatically played with rate 1 (normal speed)).



## 7.1.4 PLAY.POSITION

The user can jump to a specific moment of the track. This means that the range of the value is different with every track.

After the position is changed, the music player will continue to play the song (with the same rate).

NOTE: The range of the value has no solid value, because the number of samples is different with every track.

To prevent sending an out of bound value. The user can request the number of samples of the track.


How to get the range of a track?

The duration of a track can be requested with the following command.

http://192.168.0.87/fsapi/GET/netRemote.play.info.duration?pin=1234

# **GET PLAY.POSITION**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.play.position?pin=1234





#### **SET PLAY.POSITION**

COMMAND = http://192.168.0.87/fsapi/SET/netRemote.play.position?value=4521&pin=1234



#### 7.1.5 PLAY.CONTROL

The control command has four different settings.

- 1 → The current selected track will start playing
- 2→The current playing track will be paused

| VALUE | STATUS |
|-------|--------|
| 1     | PLAY   |
| 2     | PAUSE  |
| 3     | NEXT   |
| 4     | PREV   |

# 3 **→**

Media Player:

The next track will be selected and start playing. When the last item of the playlist is active, the unit will start the first track off the playlist.

Radio:

The unit will automatically scan on higher frequencies for the next available radio.

# 4 **→**

Media Player:

The previous track will start playing. If the first track is active, the unit will select the last track off the playlist.

Radio:

The unit will automatically scan on lower frequencies for the next available radio.



# **GET PLAY.CONTROL**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.play.control?pin=1234

# **SET PLAY.CONTROL**

COMMAND = http://192.168.0.87/fsapi/SET/netRemote.play.control?value=4&pin=1234





## 7.1.6 PLAY.INFO

The user can retrieve information about the current track playing or selected on the unit.

These commands can only be used to get information from the unit, the third parameter will never be "SET".

When the unit doesn't have the specific information. (For example: the current playing song doesn't have the artist information.) The response from the unit will be empty.

NOTE : When the track doesn't have the information → Unknown artist

<value><c8\_array></c8\_array></value>

The reply from the unit will be empty.



#### 7.1.6.1 PLAY.INFO.DURATION

The specific duration of the current selected or playing track can be retrieved with this command. This is helpful when the user is going to jump to a specific part of the track and doesn't want to send an invalid command.

#### **GET PLAY.INFO.DURATION**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.play.info.duration?pin=1234

#### 7.1.6.2 PLAY.INFO.NAME

The name of the current selected or playing track can be retrieved with this command.

# **GET PLAY.INFO.NAME**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.play.info.name?pin=1234



#### 7.1.6.3 PLAY.INFO.ALBUM

The name of the album of the current selected or playing track can be retrieved with this command.

#### **GET PLAY.INFO.ALBUM**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.play.info.album?pin=1234

#### 7.1.6.4 PLAY.INFO.ARTIST

The name of the artist of the current selected or playing track can be retrieved with this command.

# **GET PLAY.INFO.ARTIST**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.play.info.artist?pin=1234



#### 7.1.6.5 PLAY.INFO.TEXT

The user can retrieve extra information of the track with this command or when the Ethernet radio is active, this command will retrieve the data that is showed on the display.

# **GET PLAY.INFO.TEXT**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.play.info.text?pin=1234

#### 7.1.6.6 PLAY.INFO.GRAPHICURI

When the Ethernet radio is active, the unit will check on the online database of wifiradiofrontier.

The unit will automatically check if the current selected radio has a logo in the database and if possible returns the location.

# **GET PLAY.INFO.GRAPHICURI**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.play.info.graphicUri?pin=1234



#### 7.1.7 PLAY.STATUS

This command can only be used in a GET function. There are 3 different possible answers.

▶ 1

The unit is loading a track or scanning a radio preset

**>** 2

The unit is ready and playing a track or playing a radio post

> 3

The unit is ready and the track is paused.

# **GET PLAY.STATUS**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.play.status?pin=1234





## **7.2 NAV**

The NAV commands are used to navigate through the data and display them on de app.

For example: when you want to browse through the USB(connected to the unit) map and want to list all the available documents.

# 7.2.1 NAV.NUMITEMS

Before you can retrieve the list, you need to know how many items there are.

## **GET NAV.NUMITEMS**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.nav.numitems?pin=1234

#### 7.2.2 NAV.LIST

The user can retrieve the list of available items with this command.

# LIST\_GET\_NEXT NAV.LIST

COMMAND = http://192.168.0.87/fsapi/LIST\_GET\_NEXT/netRemote.nav.list/-1?maxItems=25&pin=1234

This isn't an ordinary GET function, for it will return an array (list) of data.

# **≻** -1

If the third parameter is "-1", the unit will reply with the entire list otherwise the list will start from the desired list number.

| VALUE | STATUS           |
|-------|------------------|
| -1    | All items        |
| Х     | X = Start number |

## > maxItems=25

This parameter represents the maximal numbers of list items the reply will send.



# Examples:

> If the third parameter > # available numbers & maxItems: 25



> Third parameter = 2 & maxItems: 2

```
Attp://192.168.0.87/fsapi/LIST_GET_NEXT/netRemote.nav.list/2?maxltems=2&xpin=1234
                                                                                        0+0
                                                                                                  @ 192.168.0.87
 <?xml version="1.0"?>

    <fsapiResponse>

     <status>FS_OK</status>
   - <item key="3">
- <field name="name">
        <c8_array>BOOTLO~1</c8_array>
</field>
      - <field name="subtype">
            <u8>0</u8>
        </field>
   </item>
- <item key="4">
      - <field name="name">
           <c8_array>DIMICR~1</c8_array>
      </field>
- <field name="type">
           <u8>0</u8>
        </field>
      - <field name="subtype">
       <u8>0</u8>
</field>
     </item>
 </fsapiResponse>
```



➤ Third parameter = -1 & maxItems: 5

The unit will reply with the entire list:

```
Attp://192.168.0.87/fsapi/LIST_GET_NEXT/netRemote.nav.list/-17maxltems=5&pin=1234
                                                                                       <?xml version="1.0"?>
<fsapiResponse>
<status>FS_OK</status>
  - <item key="0">
- <field name="name">
          <c8_array>AS88</c8_array>
     </field>
- <field name="type">
           <u8>0</u8>
       </field>
     - <field name="subtype">
    <u8>0</u8>
       </field>
   </item>
  - <item key="1">
     </field>
     - <field name="type">
          <u8>0</u8>
     </field>
- <field name="subtype">
          <u8>0</u8>
       </field>
   </item>
 - <item key="2">
     - <field name="name">
           <c8_array>AUDIOP~1.004</c8_array>
       </field>
     - <field name="type">
<u8>0</u8>
       </field>
     - <field name="subtype">
          <u8>0</u8>
       </field>
   </item>
 - <item key="3">
- <field name="name">
          <c8_array>BOOTLO~1</c8_array>
       </field>
     - <field name="type">
          <u8>0</u8>
     </field>
- <field name="subtype">
           <u8>0</u8>
       </field>
   </item>
 - <item key="4">
     - <field name="name">
           <c8_array>DIMICR~1</c8_array>
      </field>
     - <field name="type"><u8>0</u8>
       </field>
     - <field name="subtype">
          <u8>0</u8>
       </field>
   </item>
</fsapiResponse>
```



#### 7.2.3 NAV.ACTION

These commands could be used to move in the map structure and open files.

#### 7.2.3.1 NAV.ACTION.NAVIGATE

This command is used to move through the map structure.

# **SET NAV.ACTION.NAVIGATE**

COMMAND = http://192.168.0.87/fsapi/**SET**/netRemote.nav.action.navigate?**value=1**&pin=1234

➤ SET

This command will execute an action.

- Value
- Oxffffffff


The unit will select the map in an upper level.

# Example:

The user has selected SUBMAP 1.1. He can retrieve the items in this map.

→ http://192.168.0.87/fsapi/SET/netRemote.nav.action.navigate?value=0xffffffff&pin=1234

The unit will move to an upper level and show the content of MAP 1.





X

The unit will enter the selected map and the user will be capable of retrieving the content.

# Example:

The user has selected map 1

→ http://192.168.0.87/fsapi/SET/netRemote.nav.action.navigate?value=2&pin=1234

The unit will open the second map (SUBMAP 1.2).

# **NOTE: Different types:**


0 = Map structure

1 = MP3

2 = MP4

This command will only work if the selected item is a type "0"

<item key="0">
<field name="name"><c8\_array>MAP1~1</c8\_array></field>
<field name="type"><u8>0</u8></field>
<field name="subtype"><u8>0</u8></field>





## 7.2.3.2 NAV.ACTION.SELECTITEM

This command is used to open a file in the current selected map level.

#### **SET ACTION.SELECTITEM**

COMMAND = http://192.168.0.87/fsapi/SET/netRemote.nav.action.selectItem?value=17&pin=1234

➤ SET

This command will execute an action.

➤ Value=17

The selected value will open the item with the same item key.

NOTE: This command can't be used to move through map levels.

It will only open the selected item if the item type isn't "0".

If a valid item has been selected, it will automatically start playing.



## 7.2.4 NAV.STATE

Every time the system mode change, the nav commands will be disabled. Therefore they have to be enabled before they can be executed.

# **GET NAV.STATE**

COMMAND = http://192.168.0.87/fsapi/**GET**/netRemote.**nav.state**?pin=1234

This command can be used to retrieve the current state

#### **SET NAV.STATE**

COMMAND = http://192.168.0.87/fsapi/SET/netRemote.nav.state?value=1&pin=1234

This command can be used to change the current state

Value

To enable the nav commands, the nav.state needs to be set to "1" and to disable it needs to be set to "0".

| VALUE | STATUS  |
|-------|---------|
| 0     | Disable |
| 1     | Enable  |





| Example:  |
|---|
| 'Ethernet radio is activated  |
| Send command:   |
| http://192.168.0.87/fsapi/ <b>SET</b> /netRemote.sys.mode? <b>value=0</b> &pin=1234         |
| Response:   |
| <pre><fsapiresponse><status>FS_OK</status></fsapiresponse></pre>                            |
| 'Get the number of available list items   |
| Send command:   |
| http://192.168.0.87/fsapi/ <b>GET</b> /netRemote.nav.numitems?pin=1234                      |
| Response:   |
| <pre><fsapiresponse><status>FS_NODE_BLOCKED</status></fsapiresponse></pre>                  |
| 'Check the nav.state  |
| Send command:   |
| http://192.168.0.87/fsapi/ <b>GET/</b> netRemote. <b>nav.state</b> ?pin=1234                |
| Response:   |
| <pre><fsapiresponse><status>FS_OK</status><value><u8>0</u8></value></fsapiresponse></pre>   |
| 0 → State = disabled  |
| 'Enable the nav commands.   |
| Send command:   |
| http://192.168.0.87/fsapi/ <b>SET</b> /netRemote.nav.state? <b>value=1</b> &pin=1234        |
| Response:   |
| <pre><fsapiresponse><status>FS_OK</status></fsapiresponse></pre>                            |
| 'Get the number of available list items   |
| Send command:   |
| http://192.168.0.87/fsapi/ <b>GET</b> /netRemote. <b>nav.numitems</b> ?pin=1234             |
| Response:   |
| <pre><fsapiresponse><status>FS_OK</status><value><s32>6</s32></value></fsapiresponse></pre> |



## 5.2.3 NAV.STATUS

When the unit is still loading, it's not possible to read the data. To prevent errors or invalid answers it's best to always check the status after changing the system.mode before sending new commands.

This command has two possible answers

**•** 0

| VALUE | STATUS  |
|-------|---------|
| 0     | Loading |
| 1     | Ready   |


The unit is loading.

**1** 

The unit is ready.

# **GET NAV.STATUS**

COMMAND = http://192.168.0.87/fsapi/**GET**/netRemote.**nav.status**?pin=1234





# **7.3 SYSTEM**

The system commands are used to GET/SET the system configuration.

#### 7.3.1 SYSTEM.MODE

#### **GET SYS.MODE**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.sys.mode?pin=1234

The user can retrieve the current system configuration.

# **SET SYS.MODE**

COMMAND = http://192.168.0.87/fsapi/SET/netRemote.sys.mode?value=0&pin=1234

The mode can be set to three different values.

**•** 0

This mode will select the Ethernet radio

**1** 

This mode will select the Media Player

**2** 

This mode will select the FM radio

| VALUE | STATUS         |
|-------|----------------|
| 0     | Ethernet Radio |
| 1     | Music Player   |
| 2     | FM Radio       |





#### 7.3.2 SYSTEM.INFO

The INFO commands are used to GET/SET data which contain information of the unit.

#### 7.3.2.1 SYSTEM.INFO.FRIENDLYNAME

The friendly name can be used to make it easier to identify certain units on the network.

This name will also be visible in the "http://192.168.0.87/device" command.

# **GET SYS.INFO.FRIENDLYNAME**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.sys.info.friendlyname?pin=1234

#### **SET SYS.INFO.FRIENDLYNAME**

COMMAND= http://192.168.0.87/fsapi/SET/netRemote.sys.info.friendlyName?pin=1234&value=Test

Value=

When the value is left empty, the friendly name will be restored to his default name.

# → APART PMR4000RMKII xxxxxxxxxxx (serial number)

Value=New%20Name

The user can use every standard ASCII character in the new name.

Special characters can be added with their decimal value of the ASCII table.

Space → %20

NOTE : Every command ends with the PINnumber (?value=x&pin=1234), but the SET SYS.INFO.FRIENDLYNAME command is an exception → ?pin=1234&value=x



#### 7.3.2.2 SYSTEM.INFO.VERSION

The user can request the unit his firmware version number. This information can only be requested and not be changed.

# **GET SYS.INFO.VERSION**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.sys.info.version?pin=1234

#### 7.3.2.3 SYSTEM.INFO.RADIOID

The user can request the unit his radio identity number. This information can only be requested and not be changed.

# **GET SYSTEM.INFO.RADIOID**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.sys.info.radioId?pin=1234



#### 7.3.3 SYSTEM.AUDIO

#### 7.3.3.1 SYSTEM.AUDIO.MUTE

The user can enable / disable the mute function or request the current status.

#### **SET SYS.AUDIO.MUTE**

COMMAND = http://192.168.0.87/fsapi/SET/netRemote.sys.audio.mute?value=1&pin=1234

The mode can be set to two values


• 0

This mode will unmute the music.

| VALUE | STATUS |  |  |
|-------|--------|--|--|
| 0     | Unmute |  |  |
| 1     | Mute   |  |  |

**>** 1

This mode will mute the music.



# **GET SYS.AUDIO.MUTE**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.sys.audio.mute?pin=1234

The user can retrieve the current state of the mute function.



#### 7.3.3.2 SYSTEM.AUDIO.VOLUME

The user can retrieve or change the volume.

# **GET SYS.AUDIO.VOLUME**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.sys.audio.volume?pin=1234

The user can retrieve the current value of the volume.



# **SET SYS.AUDIO.VOLUME**

COMMAND = http://192.168.0.87/fsapi/SET/netRemote.sys.audio.volume?value=2&pin=1234

**⊳** 0

When the volume is set to the minimum value, it will activate the mute function.

| VALUE  | STATUS |
|--------|--------|
| 0      | Mute   |
| 1 - 32 | Volume |

▶ 1-32

The range of the volume is set from 1 to 32.





#### 7.3.3.3 SYSTEM.AUDIO.EQPRESET

The user can retrieve or set the EQ configuration.

# **GET SYS.AUDIO.EQPRESET**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.sys.audio.eqpreset?pin=1234

The user can retrieve the current selected EQ type.

# **SET SYS.AUDIO.EQPRESET**

COMMAND = http://192.168.0.87/fsapi/SET/netRemote.sys.audio.eqpreset?value=2&pin=1234



There are two different types:

➤ My EQ

The user can create a personal EQ configuration.

The user can adjust the bass and treble levels and activate / deactivate the loudness.

Preconfigured EQ

The user can choose between 8 different preconfigured EQ types:

Normal/Flat/Jazz/Rock/Movie/Classic/Pop and News.

| VALUE | STATUS  |  |  |
|-------|---------|--|--|
| 0     | My EQ   |  |  |
| 1     | Normal  |  |  |
| 2     | Flat    |  |  |
| 3     | Jazz    |  |  |
| 4     | Rock    |  |  |
| 5     | Movie   |  |  |
| 6     | Classic |  |  |
| 7     | Рор     |  |  |
| 8     | News    |  |  |



# 7.3.3.4 SYSTEM.AUDIO.EQLOUDNESS

When the user has selected the "My EQ" configuration, he can manually activate /deactivate the loudness function.

# **GET SYS.AUDIO.EQLOUDNESS**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.sys.audio.eqloudness?pin=1234

The user can retrieve the current state of the loudness function.



# **SET SYS.AUDIO.EQLOUDNESS**

COMMAND = http://192.168.0.87/fsapi/SET/netRemote.sys.audio.eqloudness?value=1&pin=1234

> 0

This will deactivate the loudness function

| VALUE | STATUS     |
|-------|------------|
| 0     | Deactivate |
| 1     | Activate   |

▶ 1

This will activate the loudness function.





#### 7.3.3.5 SYSTEM.AUDIO.EQCUSTOM

The user can manually configure the EQ with this command

Bass = Param0

Treble = Param1


# **GET SYS.AUDIO.EQCUSTOM**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.sys.audio.eqcustom.param0?pin=1234

This command can be used to retrieve the bass level.

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.sys.audio.eqcustom.param1?pin=1234

This command can be used to retrieve the treble level.



# **SET SYS.AUDIO.EQCUSTOM**

#### COMMAND =

http://192.168.0.87/fsapi/SET/netRemote.sys.audio.eqcustom.param0?value=1&pin=1234

This command can be used to set the bass level.

#### COMMAND =

http://192.168.0.87/fsapi/SET/netRemote.sys.audio.eqcustom.param1?value=1&pin=1234

This command can be used to set the treble level.



|       | Param0 (bass) | Param1 (treble) |
|-------|---------------|-----------------|
| VALUE | -14 to 14     | -14 to 14       |

The bass and treble levels have a range from -14 to 14.





#### 7.3.4 SYSTEM.POWER

The user can enable / disable the standby function with this command.

When the standby mode is active, the output will be muted and the display will be disabled.

NOTE: The Ethernet or FM radio will reselect the last configured radio and automatically start playing.


The music player will select the two main maps

- Shared Media
- USB playback
- → The unit wouldn't continue playing the last selected song.

# **GET SYS.POWER**

COMMAND = http://192.168.0.87/fsapi/GET/netRemote.sys.power?pin=1234

The user can retrieve the current state of the standby mode.





# **SET SYS.POWER**

COMMAND = http://192.168.0.87/fsapi/SET/netRemote.sys.power?value=1&pin=1234

The user can enable / disable the standby mode.

**≻** 1

This will disable the standby mode, the unit will return to his previous status.

| VALUE | STANDBY |
|-------|---------|
| 0     | Enable  |
| 1     | Disable |

NOTE: There are two possibilities to exit the standby mode.

http://192.168.0.87/fsapi/**SET**/netRemote.sys.power?**value=1**&pin=1234 **or send another command to the unit.** 

Set volume, change system settings ,...

> 0

This will activate the standby mode.





#### 7.3.5 SYSTEM.CAPS.EQPRESETS

The user can retrieve the list with available EQ types.

# LIST\_GET\_NEXT SYS.CAPS.EQPRESETS

COMMAND = http://192.168.0.87/fsapi/LIST\_GET\_NEXT/netRemote.sys.caps.eqpresets/-1? maxItems=25&pin=1234

```
🛑 😂 🎒 http://192.168.0.87/(sapi/LIST_GET_NEXT/netRemote;sys;caps;eqpresets/-1/max/tems=25/8xpin=1234
                                                                                         <?xml version="1.0"?>
- <fsapiResponse>
     <status>FS_OK</status>
    - <item key="0">
       - <field name="label">
            <c8_array>My EQ</c8_array>
         </field>
     </item>
    - <item key="1">
       - <field name="label">
            <c8_array>Normal</c8_array>
         </field>
     </item>
    - <item key="2">
      - <field name="label">
            <c8_array>Flat</c8_array>
        </field>
     </item>
   - <item key="3">
      - <field name="label">
            <c8_array>Jazz</c8_array>
         </field>
     </item>
    - <item key="4">
       - <field name="label">
            <c8_array>Rock</c8_array>
         </field>
     </item>
    - <item key="5">
       - <field name="label">
            <c8_array>Movie</c8_array>
         </field>
     </item>
    - <item key="6">
       - <field name="label">
            <c8_array>Classic</c8_array>
         </field>
     </item>
   - <item key="7">
       - <field name="label">
            <c8_array>Pop</c8_array>
         </field>
      </item>
    - <item key="8">
       - <field name="label">
            <c8_array>News</c8_array>
         </field>
      </item>
      stend/>
  </fsapiResponse>
```



# SUMMARY

A. Every command ends with pin number and sessionID (optional) Exceptions: Device / CREATE\_SESSION / DELETE\_SESSION How to change between a SET and a GET command.

http://192.168.0.87/fsapi/GET/netRemote.play.shuffle?pin=1234

- → http://192.168.0.87/fsap<mark>//SET/</mark>netRemote.play.shuffle?value=1&pin=1234
- B. Every command ends with the PINnumber (?value=x&pin=1234)

, but the SET SYS.INFO.FRIENDLYNAME command is an exception ?pin=1234&value=x

- C. REWIND or FAST FORWARD is only activated for 1 track, when the track reaches the end. The music player will pause. The user needs to change the rate to value = 1 (it will start the next track after FAST FORWARD or play the same track after REWIND) OR give PREV or NEXT command to play the next /previous track (this track will be automatically played with rate 1 (normal speed))
- D. There are two possibilities to exit the standby mode.

http://192.168.0.87/fsapi/**SET**/netRemote.sys.power?**value=1**&pin=1234 **or send another command to the unit.** 

Set volume, change system settings,...



\*For further information: use the command list or the examples in this manual.

| http://192.168.0.87/device                                  |     |                          | Retrieve the                                | units name   |
|---|-----|--------------------------|---|--------------|
| http://192.168.0.87/device                                  |     |                          | Retrieve the units name and version number. |              |
| http://192.168.0.87/fsapi/CREATE_SESSION?pin=1234           |     |                          | Create a private session.                   |              |
|   |     |                          | -   |              |
| http://192.168.0.87/fsapi/DELETE_SESSION?pin=1234           |     |                          | <u> </u>                                    | ate session. |
|   |     |                          | Retrieve ext                                |              |
| http://192.168.0.87/fsapi/GET_NOTIFIES?pin=1234&sid=        | 984 | 15405                    | information                                 |              |
|   |     |                          | depends on the current                      |              |
| !!! sessionID is required !!!                               |     |                          | system mode                                 |              |
|   |     |                          | configuration)                              |              |
| http://192.168.0.87/fsapi/GET/netRemote.play.shuffle?       |     | GET & SET                | 0   |              |
| pin=1234  |     |                          | Deactivate                                  |              |
|   |     |                          | 1   | Activate     |
| http://192.168.0.87/fsapi/GET/netRemote.play.repeat?        |     | GET & SET                | 0   |              |
| pin=1234  |     |                          | Dea   | ctivate      |
|   |     |                          | 1   | Activate     |
| http://192.168.0.87/fsapi/GET/netRemote.play.rate?          |     | GET & SET                | -127 to -1                                  | Rewind       |
| pin=1234  |     | σε. ασε.                 | 0   | Pause        |
| piii-1254   |     |                          | 1   | Play         |
|   |     |                          | 2 to 127                                    | Fast         |
|   |     |                          | forward                                     | Tast         |
| http://103.160.0.07/fsani/CFT/natBarrata nlav nasition?     | ,   | CET 0 CET                |   |              |
| http://192.168.0.87/fsapi/GET/netRemote.play.position?      | •   | GET & SET                | Jump to specific                            |              |
| pin=1234  |     | 057.0.657                | moment of the track.                        |              |
| http://192.168.0.87/fsapi/GET/netRemote.play.control?       |     | GET & SET                | 1   | Play         |
| pin=1234  |     |                          | 2   | Pause        |
|   |     |                          | 3   | Next         |
|   |     |                          | 4   | Prev         |
| http://192.168.0.87/fsapi/GET/netRemote.play.info.          |     | GET only                 | Retrieve the                                | •            |
| duration?pin=1234   |     |                          | duration of                                 | the current  |
|   |     |                          | selected or                                 | olaying      |
|   |     |                          | track.                                      |              |
| http://192.168.0.87/fsapi/GET/netRemote.play.info.          |     | GET only                 | Retrieve the                                | name of      |
| name?pin=1234   |     |                          | the current                                 | selected or  |
|   |     |                          | playing tracl                               | ζ.           |
| http://192.168.0.87/fsapi/GET/netRemote.play.info.          | GE  | T only                   | Retrieve the                                |              |
| album?pin=1234  |     | ,                        | name of the                                 |              |
|   |     |                          | selected or                                 |              |
|   |     |                          | track.                                      | ,8           |
| http://192.168.0.87/fsapi/GET/netRemote.play.info. GET only |     | T only                   | Retrieve the                                | artist name  |
| artist?pin=1234   | 5   | of the current selecte   |   |              |
| artistrpin=1234   |     | or playing track.        |   |              |
| http://402.400.007/feepi/CET/petBergets-pleusinfe           |     |                          |   |              |
| http://192.168.0.87/fsapi/GET/netRemote.play.info.          |     | GET only Retrieve extra  |   |              |
| text?pin=1234   |     | information of the track |   | or the track |
|   |     |                          | or radio.                                   |              |



| http://192.168.0.87/fsapi/GET/netRemote.play.info.                                     | GET only           | Retrieve t  | the location of                              |  |
|--|--------------------|---|--|--|
| graphicUri?pin=1234  |                    | an available logo.  |  |  |
| http://192.168.0.87/fsapi/GET/netRemote.play.status?<br>pin=1234                       | GET only           | <ol> <li>Loading a track or scanning a radio preset.</li> <li>Unit is ready and playing a track or playing a radio preset.</li> <li>Unit is ready and the track is paused.</li> </ol> |  |  |
| http://192.168.0.87/fsapi/GET/netRemote.nav.<br>numitems?pin=1234                      | GET only           | Retrieve the number of available list items.  |  |  |
| http://192.168.0.87/fsapi/LIST_GET_NEXT/netRemote.<br>nav.list/-1?maxItems=25&pin=1234 | LIST_GET_NEXT only | Retrieve the list data.   |  |  |
| http://192.168.0.87/fsapi/SET/netRemote.nav.action. navigate?value=1&pin=1234          | SET only           | Used to move through the map structure.   |  |  |
| http://192.168.0.87/fsapi/SET/netRemote.nav.action. selectItem?value=17&pin=1234       | SET only           | Open a file in the current selected map level.  |  |  |
| http://192.168.0.87/fsapi/GET/netRemote.nav.state?<br>pin=1234                         | GET & SET          | 0<br>1  | Disable<br>Enable                            |  |
| http://192.168.0.87/fsapi/GET/netRemote.nav.status?<br>pin=1234                        | GET & SET          | 0<br>1  | Loading<br>Ready                             |  |
| http://192.168.0.87/fsapi/SET/netRemote.sys.mode?value=0&pin=1234                      | GET & SET          | 0 ra  | Ethernet<br>adio<br>Music player<br>FM radio |  |
| http://192.168.0.87/fsapi/GET/netRemote.sys.info. friendlyname?pin=1234                | GET & SET          | Retrieve or change the name of the unit.  |  |  |
| http://192.168.0.87/fsapi/GET/netRemote.sys.info. version?pin=1234                     | GET only           | Retrieve the firmware version number  |  |  |
| http://192.168.0.87/fsapi/GET/netRemote.sys.info. radioId?pin=1234                     | GET only           |   | Retrieve the radio identity number           |  |
| http://192.168.0.87/fsapi/GET/netRemote.sys.audio.<br>mute?pin=1234                    | GET & SET          | 0<br>1  | Unmute<br>Mute                               |  |



| http://192.168.0.87/fsapi/GET/netRemote.sys.audio. | GET & SET     | 0  | Mute      |
|--|---------------|--|-----------|
| volume?pin=1234                                    |               | 1 – 32                                   | . Volume  |
| http://192.168.0.87/fsapi/GET/netRemote.sys.audio. | GET & SET     | 0  | My EQ     |
| eqpreset?pin=1234                                  |               | 1  | Normal    |
|  |               | 2  | Flat      |
|  |               | 3  | Jazz      |
|  |               | 4  | Rock      |
|  |               | 5  | Movie     |
|  |               | 6  | Classic   |
|  |               | 7  | Рор       |
|  |               | 8  | News      |
| http://192.168.0.87/fsapi/GET/netRemote.sys.audio. | GET & SET     | 0  |           |
| eqloudness?pin=1234                                |               | D  | eactivate |
|  |               | 1  | Activate  |
| http://192.168.0.87/fsapi/GET/netRemote.sys.audio. | GET & SET     | Retrieve /set the Bass and Treble level. |           |
| eqcustom.param0?pin=1234                           |               |  |           |
|  |               | Bass                                     | Param0    |
|  |               | Treble                                   | Param1    |
| http://192.168.0.87/fsapi/GET/netRemote.sys.power? | GET & SET     | 0 D                                      | eactivate |
| pin=1234   |               | st                                       | andby     |
|  |               | 1 A                                      | ctivate   |
|  |               | standby                                  |           |
| http://192.168.0.87/fsapi/LIST_GET_NEXT/netRemote. | LIST_GET_NEXT | Retrieve the list with                   |           |
| sys.caps.eqpresets/-1?maxItems=25&pin=1234         | only          | available EQ types.                      |           |



# 9. EXAMPLES

# 9.1 Example 1: How to activate Media player and select a song.

# 'Find device

# 'Create Session

# 'Get system mode



# 0 → Ethernet Radio

# 'Set system mode: Media Player






#### 'Get notifies

```
### http://192.168.0.87/fsapi/GET_NOTIFIES?pin=12348/sid=482006649
                                                                                                       D - € @ 192.168.0.87
  <?xml version="1.0"?>

    <fsapiResponse>

     <status>FS_OK</status>
   - <notify node="netremote.play.status">
- <value>
        <u8>0</u8></value>
   /notify -
- <value>
        <c8_array/>
</value>
     </notify>
   - <notify node="netremote.play.info.text">
       - <value>
        <c8_array/>
</value>
   </notify>
- <notify node="netremote.sys.mode">
      - <value>
        <u32>1</u32>
 </fsapiResponse>
```

#### 'Get nav.state



# 0 → Disable

# 'Set nav.state: enable



# 'Get nav.numitems





#### 'Get nav.list

```
### http://192.168.0.87/fsapi/LIST_GET_NEXT/netRemote.nav.list/-17maxltems=25&pin=1234&xsid=482005649
                                                                                                                   Ø - ♂ @ 192.168.0.87
  <?xml version="1.0"?>
- <item key="0">
- <field name="name">
              <c8_array>Shared media</c8_array>
        <c8_array>Share
</field>
- <field name="type">
          <u8>0</u8></field>
        - <field name="subtype">
     <u8>0</u8>
  </field>
      </item>
    - <item key="1">
        - <field name="name":
         <c8_array>USB playback</c8_array>
</field>
        - <field name="type">
          <u8>0</u8></field>
        - <field name="subtype">
          <u8>0</u8>
</field>
  </item>
stend/>
</fsapiResponse>
```

# 'Open map: USB Playback



# 'Get nav.numitems





0-0

192.168.0.87

# 'Get nav.list





#### 'Open map: Music



# 'Get nav.numitems

# 'Get nav.list

```
Ø - ♂ <u>@</u> 192.168.0.87
      ### http://192.168.0.87/fsapi/LIST_GET_NEXT/netRemote.nav.list/-17maxltems=25&pin=1234&xsid=482006649
<?xml version="1.0"?>
<fsapiResponse>
<status>FS_OK</status>
 - <item key="0">
- <field name="name">
       <c8_array>BEYOND~1.MP3</c8_array>
</field>
     - <field name="type">
       <u8>1</u8>
</field>
     - <field name="subtype">
  <u8>3</u8>
       </field>
 </item>
- <item key="1">
     + <field name="type">
- <field name="subtype">
      <u8>3</u8></field>
   </item>
 - <item key="2">
     - <field name="name">
       <c8_array>_LORDO~1.MP3</c8_array>
</field>
     - <field name="subtype">
          <u8>3</u8>
       </field>
   </item>
   stend/>
</fsapiResponse>
```



# 'Select item 1: BLACKVIOLIN.MP3



# 'Get Artist information

#### 'Get Album information

# 'Get Track info



#### 'Get track duration


# 'Get play.control

# 'Get notifies



# 9.2 Example 2: How to configure the EQ

# 'Get EQ list





# 'Get the EQpreset

3 → Jazz

# 'Set EQ type: My EQ



# 'Get the EQpreset



# 'Get Eqloudness

1 → Active



# 'Get bass level

Bass level → 1

# 'Get treble level





#### 9.3 Example 3: How to select FM radio and change the channel

'Set system mode: FM radio

#### 'Get notifies

```
http://192.168.0.87/(sap)/GET_NOTIFIES?pin=1234&sid=482006649
                                                                                                  D - € 6 192.168.0.87
  <?xml version="1.0"?>
- <notify node="netremote.sys.mode">
       - <value>
           <u32>2</u32>
   </ralue>
</notify>
- <notify node="netremote.play.status">
       - <value>
           <u8>2</u8>
       </value>
   </notify>
- <notify node="netremote.play.frequency">
      </notify>
- <notify node="netremote.play.info.name">
        <c8_array>RADIO 1 </c8_array>
</value>
   </notify>
- <notify node="netremote.play.info.text">
      - <value>
        <c8_array>JACKSON BROWNE - Running on empty</c8_array>
</value>
     </notify>
 </fsapiResponse>
```

#### 'Get Volume level

Volume → 18



# 'Get info name

# 'RDS information

# 'Scan for the next available radio



# 'Get notifies



# 'Get notifies

```
### http://192.168.0.87/fsapi/GET_NOTIFIES?pin=1234&sid=1279442417
                                                                                                 D - X
                                                                                                         C Waiting for 192.168.0.87
  <?xml version="1.0"?>
- <notify node="netremote.play.frequency">
- <value>
           <u32>97500</u32>
        </value>
     </notify>
   - <notify node="netremote.play.info.name">
       - <value>
           <c8_array>RADIO 2 </c8_array>
        </value>
    </notify>
   - <notify node="netremote.play.info.text">
      - <value>
            <c8_array>Vraag het aan</c8_array>
        </value>
     </notify>
 </fsapiResponse>
```

#### 'Get notifies

FS TIMEOUT → No new information

# 'Get play.status



2 > Unit has finished scanning

# 'Get info name



# 9.4 Example 4: How to select Ethernet radio

# 'Set system mode: Ethernet radio



# 'Get nav.state



# 0 → Disabled

# 'Set nav.state: enable





# 'Get notifies

```
### http://192.168.0.87/fsapi/GET_NOTIFIES?pin=1234&sid=1279442417
                                                                                          D - € @ 192.168.0.87
  <?xml version="1,0"?>
- <notify node="netremote.sys.mode">
- <value>
    <u32>0</u32>
</value>
</notify>
   <(8_array>Classic 21 Classiques/value>
    </notify>
   - <notify node="netremote.play.status">
      + <value>
       <u8>2</u8>
</value>
   </notify>
- <notify node="netremote.nav.status">
     </randle/
</randle/
- <notify node="netremote.play.info.text">
      - <value>
        <<br/><<B_array>BLACK SABBATH - SYMPTOM OF THE UNIVERSE/value>
     </notify>
  </fsapiResponse>
```


# 'Get nav.numitems



6 → # available items



# 'Get nav.list





# 'Open map: Stations



# 'Get nav.numitems



5 → # available items



# 'Get nav.list

</fsapiResponse>

```
← (⇒) (€) http://192.168.0.87/fsapi/LIST_GET_NEXT/netRemote.nav.list/-1?maxttems=25&pin=1234&ssid=1279442417

О • С (€) 192.168.0.87
</pre
        - <field name="subtype">
     <u8>0</u8>
     </field>
    </item>
- <item key="1">

<field name="type">

<u8>0</u8></field>

<field name="subtype">

<u8>0</u8></field>

    </item>
- <item key="2">
       <item key="2">
- <field name="name">
- <6_array>Search stations</c8_array>
</field>
- <field name="type">
- <u8>2</u8>
</field>
- <field name="subtype">
- <u8>0</u8>
</field>
    </item>
- <item key="3">
         </ried>
</item>
- <item key="4">
        </item>
stend/>
```



# 'Open map: "Genre"

# 'Get nav.numitems



# 54 → # available items

# 'Get nav.list (first 3 radios)

```
D + € 6 192.168.0.87
        ### http://192.168.0.87/fsapi/LIST_GET_NEXT/netRemote.nav.list/-1?maxItems=3&pin=1234&Isid=1279442417
  <?xml version="1.0"?>
<c8_array>Alternative</c8_array>
</field>
- <field name="type">
      <u8>0</u8>
</field>
- <field name="subtype">
        <u8>0</u8></field>
     </item>
   - <item key="1">
- <field name="name">
      <u8>0</u8>
</field>
   </item>
- <item key="2">
      - <field name="subtype">
     <u8>0</u8>
</field>
     </item>
 </fsapiResponse>
```



# 'Select the second genre: "Ambient"



#### 'Get nav.numitems



#### 43 → # available items

# 'Get nav.list (first 3 maps)

```
(=) | Altp://192.168.0.87/(sapi/LIST_GET_NEXT/netRemote,nav.list/-17maxdtems=3&pin=1234&sid=1279442417
                                                                                                                          P - € @ 192.168.0.87
  <?xml version="1.0"?>
- <fsapiResponse>
  <status>FS_OK</status>
  - <item key="0">
        - <field name="name">
          <c8_array>All Stations</c8_array>
</field>
        - <field name="type">
         <u8>0</u8>
</field>
        - <field name="subtype">
         <u8>0</u8>
</field>
      </item>
    - <item key="1">
       </field>
        - <field name="type">
        <u8>0</u8>
</field>
- <field name="subtype">
         <u8>0</u8>
    </item>
- <item key="2">
        - <field name="name">
       <c8_array> Argentina</c8_array>
</field>
- <field name="type">
          <u8>0</u8></field>
        - <field name="subtype">
<u8>0</u8>
         </field>
      </item>
  </fsapiResponse>
```



# 'Select the first map: "All stations"

# 'Get nav.numitems



336 → # available items

# 'Get nav.list (first 3 stations)

```
Ø - ♂ <u>@</u> 192.168.0.87
             Mary / 192.168.0.87 / Sapi/LIST_GET_NEXT/netRemote.nav.list/-17max/ltems=3&pin=1234&zid=1279442417
    <?xml version="1.0"?>

<

</pre
      </item>
- <item key="1">
          - <field name="name">
  <c8_array>1.fm Chillout Lounge</c8_array>
  </field>
          <u8>1</u8></field>
      </item>
- <item key="2">
            - <field name="name":
           <c8_array>1.fm Costa Del Mar - Chillout</c8_array>
</field>
- <field name="type">
            <u8>1</u8>
</field>
- <field name="subtype">
             <u8>1</u8>
</field>
         </item>
   </fsapiResponse>
```



# 'Select the first radio: "1.fm Brazilian Birds Radio"

```
http://192.168.0.87/(sapi/SET/netRemote.nav.actioniselectItem?value=0&pin=1234&sid=1279442417

<?xml version="1.0"?>
<fsapiResponse>
<fstatus>FS_OK</status>
</fsapiResponse>
</fsapiResponse>
```

#### 'Get notifies

# developed

by

Audioprof nv Industriepark Brechtsebaan 8 bus 1 2900 Schoten - Belgium

Company names, product names and trademarks are property of their respective owners.

Apart-Audio specifications are subject to change without notice.

