









BF 350 DSA-TF PART LIST

Part No.	Description	Size No.	Q'ty	Part No.	Description	Size No.	Q'ty
1	Base (Bottom Plate)		1	48	Ball Bearing	6004Z	2
2	Base (Left Part)		1	48-1	C-Ring	S-20	2
2-1	Nut	M8	4	49	Roller Shaft	0.20	1
3	Base (Right Part)		1	50	Hex. Socket Cap Screw	M10x20	2
4	Base (Front Part)		i	51	Podal Plate	WITOXEO	1
4-1	Hex. Cap Bolt	M8x16	4	53	Pedal Switch		1
4-2	Washer	M8	- 8	53-1	Micro Switch		1
5	Hex. Cap Bolt	M12x40	2	54	THE RESIDENCE OF THE PROPERTY	344.000	- 22
6	Nut	M12	2	55	Round Head Screw	M4x10	4
8	Hex. Cap Bolt	M8x16	6	56A	Hex. Socket Cap Screw	M6x8	1
8-1	Washer	and the same of th	-	175350334	Emergency Switch Box		1
9	- 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1	M8	6	56-1	Pipe		1
	Plate	2/2	.1	57-1	Flat Head Cross Screw		4
10	Hex. Socket Cap Screw	M5x8	4	58	Round Head Screw	M4x10	4
11	Coolant Tank		31	58-1	Nut	M4	4
12	Hex. Cap Bolt	M8x16	2	59A	Emergency Switch		1
13	Coolant Gauge			60	Handle		1
14	Hex. Cap Bolt	M10x30	2	60-1	Hex. Socket Cap Screw	M8x20	2
15	Tank Cover		1	60-2	Nut	M8	2
16	Filter		1	61	Handle		1
17	Pump		1	61-1	Nut	M12	1
18	Hex. Socket Cap Screw	M6x25	2	63	Locking Lever		1
18-1	Washer	M6	2	63-1	Set Screw	M10x16	1
22	Hose Clamp	13mm	4	64	Hex. Socket Cap Screw	M10x35	1
23	Hose:	5/16"x235cm	1	64-1	Spring Washer	M10	1
23-1	Hase	1"x45cm	41	65	Shaft Nut		1
24A	Coolant and Chip Tray		A	65-1	Of Soal		
24-1	Piete		4	65-3	Disk		-
24-2	Flex. Socket Cap Screw	M10x20	4	85-4	Spring Washer	M8	1
24-3	Nut	MIO	7	85-5	Hex. Secket Cap Serew	M8x35	7
24-4A	Block Plate	110	1	58A	Shait Socket Gap Solew	WOXSS	1
25	Mounting Bracket		2	68	Swivel Arm		
28	Spring Washer	M10	4	68-1		1440.05	1
27	Hex. Socket Cap Screw	M10x20	7,75	69	Hex. Cap Bolt	M10x35	1
28	Washer	M10	4	-	Scale		1
29		The second secon	4	70	Rivet	2.3x4	3
29-1	Hex. Socket Cap Screw	M10x20	4	71	Pin		1
300000	Washer	M10	4	72	Hollow Pin	Ø 2.5x16	4
30	Hex. Cap Bolt	M12x40	2	73	Spring		1
31	Nut	M12	2	74	Bushing	The state of the s	1,
32	Scale	Me area religi	1	75	Bracket		1
33	Round Head Screw	M5x10	2	76	Spring Washer	M8	2
34	Nut		1	77	Hex. Socket Cap Screw	M8x25	2
35	Switch		1	78	Nut		1
36	Emergency Switch		1	79	Jam Nut	M40	1
37	Grommet		2	80	Star Washer	M40	1
38	Grommet		1	81	Anti-Dust Cover	M40	2
39	Track		1	82	Ball Bearing	32008	2
10	Hex. Socket Cap Screw	M8x35	2	83	Shaft	02000	1
0-1	Nut	M8	2	84	Hex. Cap Bolt	M10x45	1
0-2	Spring Washer	M8	2	85	Nut	The second secon	2
1	Set Screw	M6x12	4.	86A	Pointer	M10	2
2	Washer	MUXIZ	The Park Street	40000000		145.0	1
3	Handle	MO OF	1	87	Hex. Socket Cap Screw	M5x8	1
4	The state of the s	M8x25	1	88A	Cover		1
930	Roller Stand	TO SANTON	1	88-1	Hollow Pin	Ø 6x20	2
5	Hex. Cap Bolt	M12x25	2	88-2	Set Screw	M8x10	*
6	Spring Washer	M12	2	89	Hex. Socket Cap Screw	M8x35	5
6-1	Washer *	M12	2	89-1	Spring Washer	M8	5
7	Roller		- 1	92A	Table		100

BF 350 DSA-TF

PART LIST

	B1 000 B0/(11		7171	-	31		
Part No.	Description	Size No.	Q'ty	Part No.	Description	Size No.	Q'ty
32-1	Set Screw	M6x12	1	147-5	Speed Selector		1
2-2	Changeable Plate	1	1	151	Reduction Unit		1
2-3	Hex. Socket Cap Screw	M8×20	4	152	Key	8x8x30	1
14	Bar-Stop-Rod		1	152-1	Vent Screw		1
15A	Bar-Stop		1	153	Hex. Cap Bolt	M8x25	4
35-1	Hex. Cap Bolt	M10x50	1	153-1	Spring Washer	M8	4
5-2	Nut	M10	1	154	Motor		1
16	Handle	M10x35	1	155	Key	8x7x35	1
17	Scale		1	156	Anchoring Dowel	- Grand	1
8	Rivet		3	157	Hex. Socket Cap Screw	M8x25	4
19	Chip Gutter		1	157-1	Spring Washer	M8	4
00	Hex. Socket Cap Screw	M6x8	2	158	Hollow Pin	Ø6x20	2
102	No-Burr Jaw	MOAG	1	159	Coupling Fork	20120	1
03	Hex. Socket Cap Screw	M6x15	2	160	Pin on Fork		1
04	Counter Vise Jaw	WIOXTO	1	161	C-Ring	S-20	
05	Hex. Socket Cap Screw	M6x15	2	162		5-20	2
106	Vise Jaw	MIUX 13	1	163	Nut		1
07	Flat Head Machine Screw	140046		164	Rod Supporting Block	MALOWER	3
08A	Vise	M6x15	2	164-1	Hex. Socket Cap Screw	M10x35	1
09	Dovetail Plate			The state of the s	Spring Washer	M10	2
		145	1	165	Nut	M10	1
10	Nut	M5	3	166	Hex. Socket Cap Screw	M10x40	1
11	Set Screw	M5x25	3	167	Adjustable Stop		1
12A	Vise Screw for Hydraulic Drive	110 10	1	168	Handle	M8x25	1
12-1	Hex. Socket Cap Screw	M8x16	1	169	Stop Bar		1
12-1	Washer	M8		170	Adjustable Stop		1
13	Key	5x5x15	1	170-1	Set Screw	M8x10	1
14	Hydraulic Cylinder (Vise)		1	17	Hydraulic Cylinder (Arm)		1
15	Spring Washer	M8	4	172	Bushing	N V A	2
116	Hex. Socket Cap Screw	M8x25	4	178	Hex. Socket Cap Screw	M12x20	2
117	Hand Wheel		1	1745	Limit Switch Plate		1
117-1	Spring Washer	M6		175	Spring Washer	M8	4
	Hex. Socket Cap Screw	M6x25	1	176	Nut	M8	4
17-3	Bushing		1	177	Spring Washer	M6	2
118	Set Screw	M8x10	1	178	Hex. Socket Cap Screw	M6x12	2
120A	Vise Seat		1	179	Limit Switch		2
122	Vise Setting Plate		1	180	Hex. Socket Cap Screw	M6x25	4
123	Hex. Socket Cap Screw	M10x30	2	181	Spring Holder		1
124	Setting Washer		1	182	Nut	M8	2
25	Lock Lever Device		1	183	Hex. Cap Bolt	M12x25	2
27	Handle		1	183-1	Spring Washer	M12	2
28	Setting Plate		1	184	Cylinder Guard		1
29	Bushing		1	185	Hex. Socket Cap Screw	M6x60	2
30	Hex. Socket Cap Screw	M8x20	2	185-1	Hex. Socket Cap Screw	M5×8	1
30-1	Spring Washer	M8	2	186	Hex. Socket Cap Screw	M10x35	4
31	Electric Box Holder	1747	1	186-1	Spring Washer	M10	4
32	Spring Washer	M8	4	187	Cylinder Coupling	mile	- 1
33	Hex. Socket Cap Screw	M8x20	4	188	Spring Hook	3/8"	1
135	Hex. Socket Cap Screw	M10x25	2	189A	The state of the s	3/0	1
36	Spring Washer	M10	2	190	Spring Satting Bushing		
38	Hex. Socket Cap Screw			-	Setting Bushing	140	1
38-1	Washer	M6x25	2	191	Washer	M8	1
39	Nut	M6	2	192	Hex. Socket Cap Screw	M8x35	1
	\$1.0000	M6	2	193B	Saw Arm	1777300000	1
40-5	Magnetic Switch		2	194	Hex. Socket Cap Screw	M10x35	4
40-6	Overload Relay	10000000	1	194-1	Spring Washer	M10	4
140-8	Hex. Cap Bolt	M6x15	3	195	Limit Switch		1
40-11	Overload Relay		1	195-1	Switch Pin		1
	Hex. Socket Cap Screw	M5x8	10	196	Hex. Socket Cap Screw	M4x35	2
	10.17.5		6.00	100	Troite occitor oup ocion	1117 22100 0	
143	Nut	M5	4	197	Hex. Socket Cap Screw	M10x35	4
142 143 146 147-2	10.17.5			and the second	The state of the s		_

950713

BF 350 DSA-TF PART LIST

Part No.	Description	Size No.	Q'ty	Part No.	Description	Size No.	Q'ty
199	Hex. Socket Cap Screw	M5x30	2	260	Hex. Socket Cap Screw	M6x8	1
200	Coolant Switch		2	261	Blade Guard		1
201	Hose Clamp	13mm	- 31	262	Set Screw	M6x20	2
203	Pipe Fitting	1/4Px5/16	2	263	Nut	M6	2
204	Hose	5/16"x40cm	1	264	Centric Shaft		2
205	Hose	5/16"x90cm	1	265	Ball Bearing	608Z	8
208	Drive Flywheel		1	265-1	Ball Bearing	608Z	2
207	Washer		1	266	E-Ring	E-7	8
207-1	Spring Washer	M10	1	267	Blade Guide		2
208	Hex. Cap Bolt	M10x25	1	268	Hex. Socket Cap Screw	M6x25	2
209A	Idle Flywheel Shaft		1	269	Eccentric Shaft	MOZEO	2
210	Roller Bearing	32007	2	270	Hex. Socket Cap Screw	M6x8	2
211	Idle Flywheel	04.001	1	271	Blade Guard	IVIOXO	1
212	Star Washer	M35	1	272	Guide Bracket		1
212-1	Anti-dust Cover	M35	2	272-1	Hex. Socket Cap Screw	Mose	
213	Jam Nut	M35	1	273	Pipe Fitting	M6x8	2
214	Oil Inlet	1/16	1	274	Blade Guide		1
215A	Saw Blade	1710	1	275			2
216B	Blade Cover		- 33		Ball Bearing Bracket	100	1
216A-1	Extension		1	276	Set Screw	M6x12	4
216A-2	Round Head Screw	110.0	1	279	Hex. Socket Cap Screw	M8x20	2
217	Plum Screw	M6x8	2	280	Brush		1
-		M6x10	4	281	Brush Clamp		1
219	Round Head Screw	M4x8	2,	282	Set Screw	M5x5	. 1
220	Nut	M4	2	283	Set Buahing		Th
220-1	Spring Washer	M4	2	284	Hex. Cap Bolt	M6x12	5
222	Handle		2	285	Washer	M6	2
223	Handle Wheel		1	326A	Flow Control		1
223-1	nrust Bearing	51103	1	327A	Hose	2.5 meters	1
223-2	Blade Tension Gauge		1	328A	Hose	2.0 meters	11/
223-3	Plate		1	329A	Hose	2.0 meters	1
224	Special Spring Washer		10	330A	Hose	2.0 meters	1
225	Tension Shaft		1	331A	Hose	1.5 meters	1
229.	Plate	- 4	1	332A	Manifold		1
230	Hex. Socket Cap Screw	M6x12	2	333A	Motor		1
231	Limit Switch		1	334A	Pump		1
232	Hex. Socket Cap Screw	M4x25	2	335A	Oil Gauge		1
239	Nut	M16	1	336A	Solenoid	2D2	1
240A	Slide Bracket		1	337A	Solenoid	3C4	1
240A-1	Spring Washer	M10	3	337A-1	Pilot Check	304	1
240A-2	Hex. Socket Cap Screw	M10x45	3	338A	Reducing		1
240A-3	Set Screw	M10x25	1	339A	Oil Fill Port		
244	Cover Plate	WITOXES	1	340A	Tank Cover		1
45	Hex. Socket Cap Screw	M6x8	2	341A			1
246	Gib	IVIOXO		-	Tank		1_
247	Spring Washer	110	2	P01	Control Panel		1
248		M8	6	P01-1	Main Board		1
	Hex. Socket Cap Screw	M8x20	6	P02	Electrical Box Cover		1
249	Blade Guide Movable Rod		1	P03	Electric Box Platform		1
49-1	Hex. Socket Cap Screw	M6x8	1	PQ4	Electric Parts Plate		1
250	Sct Screw	M6x12	4	P04-1	Transformer		1
51	Hex. Socket Cap Screw	M8x20	2	P04-2	Fuse Block		3
252	Setting Bracket		1	P04-3	Power in Fuse		3
253	Hex. Socket Cap Screw	M12x50	1	P04-4	Grounding Plate		1
254	Handle		- 1	P05	Electric Parts Plate (Rear)		1
56	Guide Bracket		1	P05-1	Dual Terminal Connector		1
258	Nut	M10	2	P05-2	Connector PC Board	-	1
259	Balt		2		, o board		- 15