









BE 350 DSA-TE PART LIST

Part	BF 350 DSA-TF Description	Size No.	Q'ty	Part	Description	Size No.	Q'ty
No.	755-13-12-12-12-13-13-13-13-13-13-13-13-13-13-13-13-13-	OIZE NO.	2000	No.	Activities of Court Court	2000 200 100 200 100	
2	Base (Bottom Plate)		1	48	Ball Bearing	6004Z	2
2-1	Base (Left Part)		1	48-1	C-Ring	S-20	2
	Nut	M8	4	49	Roller Shaft		1
3	Base (Right Part)		1	50	Hex. Socket Cap Screw	M10x20	2
1	Base (Front Part)	110.70	1	51	Pedal Plate		1
1-1	Hex. Cap Bolt	M8x16	4	53	Pedal Switch		1
4-2	Washer	M8	8	53-1	Micro Switch		1
	Hex. Cap Bolt	M12x40	2	54	Round Head Screw	M4x10	4
3	Nut	M12	2	55	Hex. Socket Cap Screw	M6x8	1
3	Hex. Cap Bolt	M8×16	6	56A	Emergency Switch Box		- 1
3-1	Washer	M8	6	56-1	Pipe		1
9	Plate	1/5 0	1	57-1	Flat Head Cross Screw		4
10	Hex. Socket Cap Screw	M5x8	4	58	Round Head Screw	M4x10	4
11	Coolant Tank	110 (0	1	58-1	Nut	M4	4
12	Hex. Cap Bolt	M8x16	2	59A	Emergency Switch		1
13	Coolant Gauge	1140 00	1	60	Handle		1
	Hex. Cap Bolt	M10x30	2	60-1	Hex. Socket Cap Screw	M8x20	2
15	Tank Cover		1	60-2	Nut	M8	2
6 7	Filter		1	61	Handle		1
	Pump		1	61-1	Nut	M12	1
18	Hex. Socket Cap Screw	M6x25	2	63	Locking Lever		1
8-1	Washer	M6	2	63-1	Set Screw	M10x16	1
22	Hose Clamp	13mm	1	64	Hex. Socket Cap Screw	M10x35	1
23	Hose	5/16"x235cm	1	64-1	Spring Washer	M10	1
23-1	hose	1"x45cm		65	Shaft Nut		1
24A	Opolant and Chip Tray		1	0.5-1	C/I Soal		
24-1	Plate		4	65-3	Disk	A V A	1
24-2	Mex. Socket Cap Screw	M10x20	4	65-4	Spring Washer	M8	4
24-3	Die la Piana	Mid		85-5	Hex. Secket Cap Serew	M8x35	4
24-4A	Block Plate			58A	Shait		
25	Mounting Bracket	77777	2	68	Swivel Arm		1
0	Spring Washer	M10	4	68-1	Hex. Cap Bolt	M10x35	1
	Hex. Socket Cap Screw	M10x20	4	69	Scale		1
28	Washer	M10	4	70	Rivet	2.3x4	3
29	Hex. Socket Cap Screw	M10x20	4	71	Pin		1
29-1	Washer	M10	4	72	Hollow Pin	Ø 2.5x16	7
30	Hex. Cap Bolt	M12x40	2	73	Spring		1
31	Nut	M12	2	74	Bushing	EN CALL	1.
32	Scale		1	75	Bracket		1
33	Round Head Screw	M5x10	2	76	Spring Washer	M8	2
14 15	Nut	-	1	77	Hex. Socket Cap Screw	M8x25	2
	Switch		1	78	Nut		1
16 17	Emergency Switch		1	79	Jam Nut	M40	1
	Grommet		2	80	Star Washer	M40	1
8	Grommet		1	81	Anti-Dust Cover	M40	2
19	Track		1	82	Ball Bearing	32008	2
0	Hex. Socket Cap Screw	M8x35	2	83	Shaft		1
0-1	Nut	M8	2	84	Hex. Cap Bolt	M10x45	1
0-2	Spring Washer	M8	2	85	Nut	M10	2
1	Set Screw	M6x12	4.	86A	Pointer		1
2	Washer		1	87	Hex. Socket Cap Screw	M5x8	1
3	Handle	M8x25	1	88A	Cover		1
4	Roller Stand		1	88-1	Hollow Pin	Ø 6x20	2
5	Hex. Cap Bolt	M12x25	2	88-2	Set Screw	M8x10	1
8	Spring Washer	M12	2	89	Hex. Socket Cap Screw	M8x35	5
6-1	Washer	M12	2	89-1	Spring Washer	M8	5
7	Roller		1	92A	Table		110

BF 350 DSA-TF

PART LIST

	BF 350 DSA-TF	Р	ART	LI.	51		
Part No.	Description	Size No.	Q'ty	Part No.	Description	Size No.	Q'ty
92-1	Set Screw	M6x12	1	147-5	Speed Selector		1
92-2	Changeable Plate		1	151	Reduction Unit		1
92-3	Hex. Socket Cap Screw	M8x20	4	152	Key	8x8x30	1
94	Bar-Stop-Rod		1	152-1	Vent Screw		1
A5A	Bar-Stop		1	153	Hex. Cap Bolt	M8x25	4
95-1	Hex. Cap Bolt	M10x50	1	153-1	Spring Washer	M8	4
95-2	Nut	M10	1	154	Motor		1
96	Handle	M10x35	1	155	Key	8x7x35	1
97	Scale		1	156	Anchoring Dowel		1
98	Rivet		3	157	Hex. Socket Cap Screw	M8x25	4
99	Chip Gutter		1	157-1	Spring Washer	M8	4
100	Hex. Socket Cap Screw	M6x8	2	158	Hollow Pin	Ø6x20	2
102	No-Burr Jaw		1	159	Coupling Fork		1
103	Hex. Socket Cap Screw	M6x15	2	160	Pin on Fork		1
104	Counter Vise Jaw		- 1	161	C-Ring	S-20	2
105	Hex. Socket Cap Screw	M6x15	2	162	Nut		1
106	Vise Jaw		1	163	Rod Supporting Block		1
107	Flat Head Machine Screw	M6×15	2	164	Hex. Socket Cap Screw	M10x35	1
108A	Vise		1	164-1	Spring Washer	M10	2
109	Dovetail Plate		1	165	Nut	M10	1
110	Nut	M5	3	166	Hex. Socket Cap Screw	M10x40	1
111	Set Screw	M5x25	3	167	Adjustable Stop	11112112	1
112A	Vise Screw for Hydraulic Drive	1	1	168	Handle	M8x25	1
112-1	Hex. Socket Cap Screw	M8×16	1	169	Stop Bar	THOMES	1
112-1	Washer	M8	1	170	Adjustable Stop		-4
113	Kel	5x5x15	1	170-1	Set Screw	M8x10	
114	Hydraulic (Winder (Vise)		1	17	Hydraulic Cylinder (Arm)	WALK D	
115	Spring Washer	M8	4	172	Bushing		2
116	Hex. Socket Cap Screw	M8x25	4	173	Hex. Socket Cap Screw	M12x20	2
117	Hand Wheel	THE STATE OF THE S		1744	Limit Switch Plate	W112420	1
117-1	Spring Washer	M6		175	Spring Washer	M8	
117-2	Hex. Socket Cap Screw	M6x25	1	176	Nut	M8	4
117-8	Bushing	INOXEO	1	177	Spring Washer	M6	2
1/8	Set Screw	M8×10	1	178	Hex. Socket Cap Screw	M6x12	2
120A	Vise Seat	INIOXIO	1	179	Limit Switch	WOX12	2
122	Vise Setting Plate		1	180	Hex. Socket Cap Screw	M6x25	4
123	Hex. Socket Cap Screw	M10x30	2	181	Spring Holder	WOXZU	1
124	Setting Washer	IWIUXSU	1	182	Nut	M8	
125	Lock Lever Device	-	1	183	Hex. Cap Bolt	M12x25	2
127	Handle		1	183-1	Spring Washer		2
128	Setting Plate	-	1	184		M12	1
129	Bushing		1	185	Cylinder Guard	M6x60	-
130	Hex. Socket Cap Screw	M8x20	2	185-1	Hex. Socket Cap Screw	M5x8	2
130-1	Spring Washer			-	Hex. Socket Cap Screw		1
131		M8	2	186	Hex. Socket Cap Screw	M10x35	4
132	Electric Box Holder	1.00	1_1_	186-1	Spring Washer	M10	4
	Spring Washer	M8	4	187	Cylinder Coupling	7.00	1
133	Hex. Socket Cap Screw	M8x20	4	188	Spring Hook	3/8"	1
135	Hex. Socket Cap Screw	M10x25	2	189A	Spring		1
136	Spring Washer	M10	2	190	Setting Bushing	1100	1
138	Hex. Socket Cap Screw	M6x25	2	191	Washer	M8	1
138-1	Washer	M6	2	192	Hex. Socket Cap Screw	M8x35	1
139	Nut	M6	2	193B	Saw Arm		1
140-5	Magnetic Switch		2	194	Hex. Socket Cap Screw	M10x35	4
140-6	Overload Relay		1	194-1	Spring Washer	M10	4
140-8	Hex. Cap Bolt	M6x15	3	195	Limit Switch		1
140-11	Overload Relay		1	195-1	Switch Pin		1
142	Hex. Socket Cap Screw	M5x8	10	196	Hex. Socket Cap Screw	M4x35	2
143	Nut	M5	4	197	Hex. Socket Cap Screw	M10x35	4
	Round Head Screw	The State of	4	197-1	Spring Washer		4
146	Round Head Screw	M5x10	4	134-1	DOUBLE AVSISTIBLE	M10	- 51

BF 350 DSA-TF PART LIST

	BF 350 DSA-TF	P	ART	ᆜᆜ	ST		
Part No.	Description	Size No.	Q'ty	Part No.	Description	Size No.	Q'ty
199	Hex. Socket Cap Screw	M5x30	2	260	Hex. Socket Cap Screw	M6x8	1
200	Coolant Switch		2	261	Blade Guard		1
201	Hose Clamp	13mm	1	262	Set Screw	M6x20	2
203	Pipe Fitting	1/4Px5/16	2	263	Nut	M6	2
204	Hose	5/16"x40cm	1	264	Centric Shaft		2
205	Hose	5/16"x90cm	1	265	Ball Bearing	608Z	8
208	Drive Flywheel		1	265-1	Ball Bearing	608Z	2
207	Washer		1	266	E-Ring	E-7	8
207-1	Spring Washer	M10	1	267	Blade Guide		2
208	Hex. Cap Bolt	M10x25	1	268	Hex. Socket Cap Screw	M6x25	2
209A	Idle Flywheel Shaft		1	269	Eccentric Shaft	11101111111	2
210	Roller Bearing	32007	2	270	Hex. Socket Cap Screw	M6x8	2
211	Idle Flywheel		1	271	Blade Guard	1110230	1
212	Star Washer	M35	1	272	Guide Bracket		1
212-1	Anti-dust Cover	M35	2	272-1	Hex. Socket Cap Screw	M6x8	2
213	Jam Nut	M35	1	273	Pipe Fitting	11.07.0	1
214	Oil Inlet	1/16	1	274	Blade Guide		2
215A	Saw Blade		1	275	Ball Bearing Bracket		1
216B	Blade Cover		1	276	Set Screw	M6x12	4
216A-1	Extension		1	279	Hex. Socket Cap Screw	M8x20	2
216A-2	Round Head Screw	M6x8	2	280	Brush	100220	1
217	Plum Screw	M6x10	4	281	Brush Clamp		1
219	Round Head Screw	M4x8	2.	282	Set Screw	M5x5	1
220	Nut	M4	2	283	Set Buahing	IVIOAG	
220-1	Spring Washer	M4	2	284	Hex. Cap Bolt	M6x1/2	
222	Handle		2	283	Washer	M6	2
223	Handle Wheel		1	326A	Flow Control		
223-1	Fhrust Bearing	51103	1	327A	Hose	2.5 meters	
223-2	Blade Tension Gauge			328A	Hose	2.0 meters	47
223-3	Plate		1	329A	Hose	2.0 meters	1
224	Special Spring Washer		10	330A	Hose	2.0 meters	1
225	Tension Shaft		1	331A	Hose	1.5 meters	1
225	Plate		1	332A	Manifold	1.0 11101013	1
230	Hex. Socket Cap Screw	M6x12	2	333A	Motor		1
231	Limit Switch		1	334A	Pump		1
232	Hex. Socket Cap Screw	M4x25	2	335A	Oil Gauge		1
239	Nut	M16	1	336A	Solenoid	2D2	1
240A	Slide Bracket		1	337A	Solenoid	3C4	1
240A-1	Spring Washer	M10	3	337A-1	Pilot Check	1004	1
240A-2	Hex. Socket Cap Screw	M10x45	3	338A	Reducing		1
240A-3	Set Screw	M10x25	1	339A	Oil Fill Port		1
244	Cover Plate	111.141.44	1	340A	Tank Cover		1
245	Hex. Socket Cap Screw	M6x8	2	341A	Tank		1
246	Gib	mono	2	P01	Control Panel		1
247	Spring Washer	M8	6	P01-1	Main Board		1
248	Hex. Socket Cap Screw	M8x20	6	P02	Electrical Box Cover	-	1
249	Blade Guide Movable Rod	monay.	1	P03	Electric Box Platform	-	-
249-1	Hex. Socket Cap Screw	M6x8	1	P04	Electric Box Platform		1
250	Set Screw	M6x12	4	P04-1	Transformer		1
251	Hex. Socket Cap Screw	M8x20	2	P04-1	Fuse Block	-	1
252	Setting Bracket	IVIUAZU	1	P04-2	er Production and a second sec		3
253	Hex, Socket Cap Screw	M12vEC		-	Power in Fuse		3
254	Handle	M12x50	1	P04-4	Grounding Plate		1
		-	_!_	P05 P05-1	Electric Parts Plate (Rear)		1
	Guida Branket						1 4
256 258	Guide Bracket Nut	M10	1 2	P05-2	Dual Terminal Connector Connector PC Board		1