After cotton candy is made, the furnace still produces cotton candy strand

Type

Solution

Issue

The stove temperature for making sugar is too low

Enter the management background, click the parameter setting and adjust the sugar temperature of the furnace head higher by 5 degrees.

Created by



Jason Lopez