


MPLAB X IDE v3.45









































Generate initialization code for current configuration bit values. Copy and paste output to a project source file.

