

PRE-CRASH SAFETY SYSTEM

DESCRIPTION


- The pre-crash safety system is available as an option on all European models.
- The pre-crash safety system retracts the slack in the front seat belts when any of the conditions below are present to reduce injury to the driver and front passenger.

Operating Conditions	• When the brakes are suddenly applied. • When the front wheels lose grip in relation to the rear wheels (front wheel skid tendency). • When the rear wheels lose grip in relation to the front wheels (rear wheel skid tendency).
----------------------	--

- This system will not operate under the following conditions.

Non-operating Conditions	• The seat belt is not buckled. • The vehicle speed is approximately 30 km/h (20 mph) or less. • The engine switch is off or on (ACC). • Multi-information display in the combination meter assembly displays Check PCS System or PCS Not available now warning messages.
--------------------------	--

► System Diagram ◀



BE