

REAR FLOOR SIDE PANEL (ASSY)




F29245A

Symbol meaning

REMOVAL  : Remove Weld PointsINSTALLATION  : Plug Weld

F29245B

REMOVAL-INSTALLATION



F29245

INSTALLATION POINT

- 1 After welding, apply body sealer to the corresponding parts. (See the paint coating)
- 2 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.