

■ ACTUATION AREA

The special functions of the entry and start system only work when the key is in the actuation area formed by the eight oscillators.

- The in door electrical key oscillators (front, center and rear) form the actuation area of the push button start function.
- The door electrical key oscillators (four doors and outside back door) form the actuation area of the entry function.

