

■ SYSTEM OPERATION

The front wiper deicer system is turned on or off when the following conditions are met.

Operation	Conditions	Indicator Light
OFF to ON	The front wiper deicer switch is pressed to start deicing. The outside air temperature is 0°C (32°F) or below.	Illuminates
ON to OFF	When any of the following conditions is met: • The front wiper deicer switch is pressed to stop deicing. • The front wiper deicer has been operating for approximately 15 minutes. • The rear window defogger system is activated. For details about the rear defogger system, refer to page BE-262. • The outside air temperature is 5°C (41°F) or higher.	OFF