# 通讯协议

**Communications agreements** 

版本 V1.0

V1.0 version

#### 1. 版本修订记录(Revision records)

序号 Serial number	描述 Description	日期 Date	版本 Version	作者 Author
1.	初始版本 Initial	2019.06.11	V1.0	
	version			

# 1.物理层 physical layer

1.	物理接口 physical interface	CAN
2.	波特率 baud rate	250K

# 2.通讯格式 Communications Format

#### 2.1 基本时序 Basic timing

所有消息均由主机发送,所有从机收到消息后判断从机地址是否吻合,只有在从机地址吻合情况下才允许向主机返回数据。

All messages are sent by the host, all slave after receiving the message to determine whether the slave address match, only in the case of slave address match is allowed to return data to the host.

#### 2.2 地址分配 Address allocation

模块 Module	地址 Address
BMS 主控 BMS Master	0x01
蓝牙手机 APP Bluetooth APP	0x80
GPRS	0x20
上位机 Upper	0x40

### 2.3 CAN 通讯格式 CAN Communication formats

## 2.4.1 上位机发送 upper computer

CAN ID 4byte	数据内容 Data content Data	
优先级+数据 ID+BMS 地址+上位机地址	8 字节	
Priority + data ID+BMS address + PC address	8 bytes	
(0x18100180)	8 bytes	

## 2.4.2BMS 响应主机命令 BMS responds to host commands

CAN ID 4byte	数据内容 Data content Data	
优先级+数据 ID+上位机地址+BMS 地址		
Priority + data ID+ PC address +BMS address	8 字节 8 bytes	
(0x18108001)		

# 6. 通讯内容信息 Communications content information

数据 Data	数据	UPPER -	说明 Note
Message	ID	BMS	
	Data ID		Remark
	Messag		
	e ID		
总压电流 SOCSOC	0x90	发送 Send	Byte0~Byte7:Reserved
of Total Voltage		返回Return	Byte0~byte1: 累计总压 (0.1V) pressure (0.1 V)
			Byte2~byte3: 采集总压(0.1V) acquisition (0.1 V)

Current			Byte4~byte5: 电流(30000 Offset, 0.1A)current (Offset,0.1A 30000) Byte6-Byte7: SOC(0.1%)
单体最高最低电压	0x91	发送 Send	Byte0~Byte7:Reserved
Maximum Minimum Voltage of Monomer		返回Return	Byte0~byte1: 最高单体电压值(mV)maximum monomer voltage (mV) Byte2: 最高单体电压cell号 Maximum Unit Voltage cell No. Byte3~byte4: 最低单体电压值(mV)minimum monomer voltage (mV) Byte5: 最低单体电压cell号Minimum Unit Voltage cell No.
单体最高最低温度	0x92	发送 Send	Byte0~Byte7:Reserved
Maximum minimum temperature of monomer		返回Return	Byte0: 最高单体温度值(40 Offset, ° C) maximum monomer temperature (40 Offset, ° C) Byte1: 最高单体温度cell号 Maximum monomer temperature cell No. Byte2: 最低单体温度值(40 Offset, ° C) minimum monomer temperature (40 Offset, ° C) Byte3: 最低单体温度cell号Minimum Monomer Temperature cell No.
充放电、MOS 状态	0x93	发送 Send	Byte0~Byte7:Reserved
Charge/discharge, MOS status		返回Return	Byte0: 充放电状态(0静止,1充电,2放电)charge/discharge status (0 stationary ,1 charged ,2 discharged) Byte1: 充电MOS管状态charging MOS tube status Byte2: 放电MOS管状态discharge MOS tube state Byte3:BMS life(0~255循环)BMS life(0~255 cycles) Byte4~Byte7:剩余容量(mAH) residual capacity (mAH)
状态信息1	0x94	发送Send	Byte0~Byte7:Reserved
Status Information 1		返回Return	Byte0: 电池串数 battery string Byte1: 温度个数 temperature Byte2:充电器状态(0断开,1接入)charger status (0 disconnected,1 connected) Byte3: 负载状态(0断开,1接入)load status (0 disconnected,1 access)  Byte4: Bit 0: DI1 state Bit 1: DI2 state Bit 2: DI3 state Bit 2: DI3 state Bit 4: DO1 state Bit 4: DO1 state Bit 5: DO2 state Bit 6: DO3 state Bit 7: DO4 state

		Byte 5~Byte6 : 充放电循环次数charge/discharge cycles Byte7:Reserved
0x95	发送 Send	Byte0~Byte7:Reserved
	返回Return	每个单体电压占2byte,根据实际单体个数发送,最大96byte,分16帧发送Each unit voltage of 2 byte, according to the actual number of units sent, a maximum of 96 byte, divided into 16 frames sent Byte0: 帧序号,从0开始,0xFF为无效frame number, starting from 0,0 xFF invalid Byte1~byte6: 单体电压(1mV)monomer voltage (1 mV) Byte7:Reserved
0x96	发送 Send	Byte0~Byte7:Reserved
	返回Return	每个温度占1byte,根据实际使用温度个数发送,最大21byte,分3帧发送Each temperature is 1 byte, sent according to the actual number of temperature used, a maximum of 21 byte, divided into 3 frames
		Byte0: 帧序号,从0开始 frame number, starting at 0
		Byte1~byte7: 单体温度(40 Offset, ° C)monomer temperature (40 Offset, ° C)
0x97	发送 Send	Byte0~Byte7:Reserved
	返回Return	0: 关闭OFF 1: 开启ON
		Bit0: 单体1均衡状态 monomer 1 equilibrium state
		Bit47: 单体48均衡状态monomer 48 equilibrium state
000	4534 C 4	Bit48~Bit63: reserved Byte0~Byte7:Reserved
0X98		0 -> No error
	返回Return	1 -> Error
		Byte 0
		Bit 0: 单体电压过高一级告警one stage warning of unit over voltage
		Bit 1: 单体电压过高二级告警one stage warning of unit over voltage
		Bit 2: 单体电压过低一级告警 one stage warning of unit over voltage
		Bit 3: 单体电压过低二级告警two stage warning of unit over voltage
		Bit 4: 总压过高一级告警Total voltage is too high One alarm Bit 5: 总压过高二级告警Total voltage is too high Level two alarm
		Bit 6: 总压过低一级告警Total voltage is too low One alarm
		Bit 7: 总压过低二级告警Total voltage is too low Level two alarm
	0x96	返回Return  0x96 发送 Send 返回Return  0x97 发送 Send 返回Return

Byte 1 Bit 0: 充电温度过高一级告警Charging temperature too high. One alarm
Bit 1: 充电温度过高二级告警 Charging temperature too high. Level two alarm
Bit 2: 充电温度过低一级告警 Charging temperature too low. One alarm
Bit 3: 充电温度过低二级告警Charging temperature's too low. Level two alarm
Bit 4: 放电温度过高一级告警Discharge temperature is too high. One alarm
Bit 5: 放电温度过高二级告警Discharge temperature is too high. Level two alarm Bit 6: 放电温度过低一级告警Discharge temperature is too low. One alarm
Bit 6. 放电温度过低 级占警Discharge temperature is too low. One afaim  Bit 7: 放电温度过低二级告警Discharge temperature is too low. Level two alarm
Bit 7. 从名画/文是版————————————————————————————————————
Byte 2
Bit 0: 充电过流一级告警 Charge over current. Level one alarm
Bit 1: 充电过流二级告警Charge over current, level two alarm
Bit 2: 放电过流一级告警 Discharge over current. Level one alarm
Bit 3: 放电过流二级告警Discharge over current, level two alarm
Bit 4: SOC过高一级告警SOC is too high an alarm
Bit 5: SOC过高二级告警SOC is too high. Alarm Two
Bit 6: SOC过低一级告警 SOC is too low. level one alarm
Bit 7: SOC过低二级告警SOC is too low. level two alarm
Byte 3
Bit 0: 压差过大一级告警 Excessive differential pressure level one alarm
Bit 1: 压差过大二级告警 Excessive differential pressure level two alarm
Bit 2: 温差过大一级告警Excessive temperature difference level one alarm
Bit 3: 温差过大二级告警 Excessive temperature difference level two alarm
Byte 4
Bit 0: 充电MOS过温警告charging MOS overtemperature warning
Bit 1: 放电MOS过温警告 discharge MOS overtemperature warning
Bit 2: 充电MOS温度检测传感器故障charging MOS temperature detection sensor failure
Bit 3: 放电MOS温度检测传感器故障discharge MOS temperature detection sensor failure
Bit 4: 充电MOS粘连故障charging MOS adhesion failure
Bit 5: 放电MOS粘连故障discharge MOS adhesion failure
Bit 6: 充电MOS断路故障charging MOS breaker failure

	Bit 7: 放电MOS断路故障discharge MOS breaker failure
	Byte 5
	Bit 0: AFE采集芯片故障AFE acquisition chip malfunction
	Bit 1: 单体采集掉线 monomer collect drop off
	Bit 2: 单体温度传感器故障Single Temperature Sensor Fault
	Bit 3: EEPROM存储故障EEPROM storage failures
	Bit 4: RTC时钟故障RTC clock malfunction
	Bit 5: 预充失败 Precharge Failure
	Bit 6: 整车通信故障vehicle communications malfunction
	Bit 7: 内网通信模块故障intranet communication module malfunction
	Byte 6:
	Bit 0: 电流模块故障Current Module Failure
	Bit 1: 内总压检测模块故障main pressure detection module
	Bit 2: 短路保护故障 Short circuit protection failure
	Bit 3: 低压禁止充电故障Low Voltage No Charging
	Bit 4: GPS或软开关断开MOS GPS or soft switch MOS off
	Bit 5~Bit7: Reserved
	Byte7: 故障码(如0x03,则显示"故障码3",0不用显示)fault code (if 0 x 03, show "fault code 3",0 do
	not show)