```
// displey o'lchamini o'rnatish
led.begin(16, 2);
led.clear();
void loop(void)
int t=get_temp();
lcd.setCursor(0,1);lcd.print(" ");
lcd.setCursor(0,1);
led.print(t/16);lcd.print(".");lcd.print((t\%16)*100/16);
}
// DS18B20 datchikdan axborotlarni olish
intget temp()
byte i;
byte present = 0;
byte data[12];
byte addr[8];
int Temp;
if ( !ds.search(addr))
{Serial.print("No more addresses.\n");
ds.reset search();
return -1;
// 1-Wire qurilmasining noyob manzilini monitorga chiqarish
lcd.setCursor(0,0);
lcd.print("R=");
for (i = 0; i < 8; i++)
{lcd.print(addr[i], HEX);lcd.print("");}
if (OneWire:crc8( addr, 7) != addr[7])
Serial.print("CRC is not valid!\n");
return -1;
if ( addr[0] != 0x28)
Serial.print("Device is not a DS18S20 family device.\n");
return -1;
}
ds.reset();
// datchik orqali haroratni konvertatsiyasini boshlash
ds.write(0x44,l);
delay(750); // 750 ms kutiladi
```