

## 29.1 chizma. Ethernetshield moduli va yorugʻlik diodini ulanish sxemasi

```
// (port 80 is default for HTTP):
EthernetServer server(80);
int pins[] = { 7, 8}; // Yorug'lik diodlari uchun pinlar
int pinState[] = \{0, 0\}; // pin lar holati
String getData="";
boolean startGet=false;
void setup ()
Serial.begin(9600);
for(int i=0; i<2; i++)
pinMode(pins[i],OUTPUT); // Yorugʻlik diodlarini ulashga ulanish nuqtalar
digitalWrite(i,LOW); // Yorugʻlik diodlarini oʻchirish
// Ethernetserver kutubxonasini initsializatsiyalash
Ethernet.begin(mac, ip);
server.begin();
void loop()
// mijozlar ulanishini kutish
EthernetClient client = server.available();
if (client)
{
```